


SERVICE MANUAL

Telescopic axis size 3-5



Project / Order:

Bill of materials:

Serial number:

Year of manufacture:

© GÜDEL

Translation of the original instructions

This manual contains standard illustrations that may deviate from the original. In the case of special models, options, or technical changes, the scope of delivery may differ from the descriptions here. Reprinting the instructions, in whole or in part, requires our permission. Subject to change due to technical improvements.

Revision history

Version	Date	Description
5.0	07/08/2019	<p>New:</p> <ul style="list-style-type: none"> • Ratio of the belt frequency ➡ 📄 140 <p>Entire manual updated</p>
4.0	05/29/2018	<p>Modified:</p> <p>New gearbox unit with elastomer coupling</p> <ul style="list-style-type: none"> • Replacing gearbox unit ➡ 📄 116 • Maintenance schedules ➡ 📄 152 • Repairs ➡ 📄 172
3.0	11/20/2017	<p>Redesign sizes 3 and 5: Product version V4.xx</p> <p>Updated:</p> <ul style="list-style-type: none"> • Lubricating the bearing of the guide pulley ➡ Chapter 7.3.5.3, 📄 74 • Replacing the bearing of the guide pulley ➡ Chapter 7.3.8.1, 📄 135 • Setting the belt tension • Maintenance schedule ➡ 📄 153
2.0	08/17/2017	<p>Redesign size 4: Product version V4.xx</p> <p>Updated:</p> <ul style="list-style-type: none"> • Retrofitting telescope axis ➡ Chapter , 📄 13 • Design ➡ 📄 29 • Function ➡ 📄 30 • Installing locking bolts ➡ 📄 33 • Replacing the lubricating pinion ➡ 📄 75 • Replacing the cog belt • Replacing the ball-bearing cycle • Setting the belt tension
1.0	10/03/2016	Basic version

Table -I Revision history

360287971 90236171_v5.0_EN-US

Table of contents

I	General	13
1.1	Further applicable documentation	13
1.2	Purpose of the document	13
1.3	Explanation of symbols/abbreviations	14
2	Safety	15
2.1	General	15
2.1.1	Product safety	15
2.1.2	Personnel qualifications	16
2.1.2.1	Operating companies	17
2.1.2.2	Transport specialists	17
2.1.2.3	Fitters	17
2.1.2.4	Commissioning technicians	18
2.1.2.5	Manufacturer's technicians	18
2.1.2.6	Maintenance technicians	19
2.1.2.7	Service technicians	19
2.1.3	Disregarding safety regulations	20
2.1.4	Installation instructions	20
2.2	Hazard symbols in the manual	21
2.2.1	Hazard warnings	21
2.2.2	Explanation of warning symbol	22
2.3	Fundamentals of safety	23
2.3.1	Separating protective equipment, monitoring equipment	23
2.3.2	Product-specific hazards	24
2.3.3	Material safety data sheets (MSDS)	25

3	Product description	27
3.1	Use	27
3.1.1	Intended use	27
3.1.2	Non-intended use	27
4	Design, function	29
4.1	Design	29
4.2	Function	30
4.2.1	Moving the axis	31
4.2.2	Belt monitor	32
4.2.3	Installing locking bolts	33
5	Transport	35
5.1	Packaging symbols	36
5.2	Industrial trucks	37
5.3	Slings	38
5.3.1	Attaching the slings: Z-axis, sizes 2-5	38
5.4	Setting up or laying down the telescopic axis	39
6	Installing	43
6.1	Installing the Z-axis	43
6.1.1	Attaching the slings: Z-axis, sizes 2-5	43
6.1.2	Preparations	44
6.1.3	Inserting the Z-axis	45
6.1.4	Assembling the bumper unit	45
6.1.4.1	Bumper unit with limit stops	47
6.2	Güdel gearbox unit	48
6.2.1	Installing the motor	48
6.2.1.1	Information on initial assembly	48
6.2.1.2	Prerequisites	48

6.2.1.3	Aligning the gearbox flange	49
6.2.1.4	Aligning the input shaft to the gearbox flange	51
6.2.1.5	Positioning the coupling on the motor shaft	52
6.2.1.6	Installing the motor and coupling	56

7	Maintenance	59
---	-------------	----

7.1	Introduction	59
7.1.1	Safety	59
7.1.2	Personnel qualifications	60
7.2	Consumables and auxiliary agents	61
7.2.1	Cleaning agents	61
7.2.1.1	Table of cleaning agents	61
7.2.2	Lubricants	61
7.2.2.1	Lubrication	62
	Manual lubrication	62
	Automatic lubrication system	64
7.2.2.2	Lubricant table	66
7.3	Maintenance tasks	68
7.3.1	General prerequisites	68
7.3.2	Maintenance intervals	68
7.3.3	Special tools, testing and measuring instruments	70
7.3.4	Maintenance tasks after 150 hours	71
7.3.4.1	Lubricating guideways, racks and pinions	71
7.3.5	Maintenance tasks after 2,250 hours	72
7.3.5.1	General inspection	72
7.3.5.2	Lubricating the ball-bearing cycle	72
7.3.5.3	Lubricating bearing of the guide pulley	74
7.3.6	Maintenance tasks after 6,750 hours	75
7.3.6.1	Replacing the lubricating pinion	75
7.3.7	Maintenance tasks after 22,500 hours	76

7.3.7.1	Replacing the cog belt	76
	Installing locking bolts	78
	Cog belt right	79
	Cog belt left	81
	Replacing the cog belt	83
	Final tasks	83
7.3.7.2	Replacing the ball-bearing cycle	84
	Installing locking bolts	85
	Attaching the slings: Z-axis, sizes 2-5	86
	Preparations	86
	Moving out the vertical axis	87
	Setting up or laying down the telescopic axis	88
	Removing limit stop	91
	Remove locking bolt	92
	Replacing the guideway of the ball-bearing cycle	93
	Replacing guide carriage of the ball-bearing cycle	94
	Final tasks	95
7.3.7.3	Replacing the guideway	96
	Installing locking bolts	96
	Attaching the slings: Z-axis, sizes 2-5	98
	Preparations	98
	Moving out the vertical axis	99
	Setting up or laying down the telescopic axis	100
	Replace the guideway	102
	Installing the Z-axis	103
	Final tasks	107
7.3.7.4	Replacing the energy chain	107
	Removing the energy chain	107
	Laying the cables and lines	108
	Relieving the cables and lines of strain	111
	Installing the energy chain	114
	Final tasks	115

7.3.7.5	Replacing the gearbox unit	116
	Attaching the slings: Motor	116
	Attaching the slings: Güdel gearbox unit	117
	Removing the motor and coupling	119
	Removing the gearbox unit	121
	Replacing the gearbox unit	121
	Installing the gearbox unit	122
	Installing the motor	123
	Final tasks	134
7.3.7.6	Final tasks	134
7.3.8	Maintenance tasks after 31,500 hours	135
7.3.8.1	Replacing bearing of the guide pulley	135
	Installing locking bolts	136
	Attaching the slings: Z-axis, sizes 2-5	137
	Preparations	137
	Replacing bearing of the guide pulley	138
	Final tasks	139
7.3.9	Set the belt tension	140
7.3.10	Setting the tooth flank backlash	144
7.3.10.1	Eccentric marking	144
	Y-axis	144
	Z-axis	145
7.3.10.2	Blocking, unblocking the eccentric ring	145
7.3.10.3	Eccentric	146
7.3.10.4	Check the tooth flank backlash	147
	Blocking the drive pinions	147
	Rack quality and module	148
	Exact measuring method	148
	Alternative measuring method	150

7.4	Maintenance schedules	152
7.4.1	Maintenance schedule	153
7.4.2	Güdel gearbox unit maintenance schedule	155
7.5	Maintenance table	157
7.6	Intervention protocol: Maintenance	159
7.7	Feedback on the instructions	169
8	Repairs	170
8.1	Introduction	170
8.1.1	Safety	170
8.1.2	Personnel qualifications	171
8.2	Repairs	172
8.2.1	General prerequisites	172
8.2.2	Replacing lubricant	172
8.2.2.1	Attaching the slings: Motor	172
8.2.2.2	Attaching the slings: Güdel gearbox unit	174
8.2.2.3	Remove the motor	175
8.2.2.4	Removing the gearbox unit	177
8.2.2.5	Replacing lubricant	178
8.2.2.6	Installing the gearbox unit	181
8.2.2.7	Installing the motor	182
8.2.2.8	Final tasks	183
8.2.3	Replacing the motor	184
8.2.4	Replacing the motor flange and gearbox flange	186
8.2.5	Replacing pinion, bearing, and clamping set	188
8.2.6	Setting the gear backlash	191
8.2.7	Replacing the elastomer gear rim	193

8.3	Tasks to perform after a crash	194
8.3.1	Replacing the bumper unit	194
8.3.1.1	Bumper unit with shearing sleeves	195
8.3.1.2	Bumper unit with pins	196
8.3.1.3	Bumper unit with limit stops	197
8.3.2	Referencing the axes	198
8.4	Intervention report: Repairs	199
8.5	Other documentation	201
8.6	Service departments	201
9	Spare parts supply	202
9.1	Service departments	203
10	Torque tables	209
10.1	Tightening torques for screws	209
10.1.1	Zinc plated screws	210
10.1.2	Black screws	211
10.1.3	Stainless steel screws	212
10.2	Tightening torques for clamping sets	213
	Illustrations	215
	List of tables	219
	Index	223

I General

Read the entire manual before working with the product. The manual contains important information for your personal safety. The manual must be read and understood by all persons who work on the product in any of the product life phases.

This product is an option for a Güdel product. It is only sold in combination with a Güdel product.

This manual only describes work related to the option. For more information, please refer to the superordinate manual.



If the product is retrofitted, the complete carriage must be replaced. For more information, please refer to the superordinate manual.

I.1 Further applicable documentation

All documents delivered with this manual are further applicable documentation. They must be observed in addition to this operating manual for the safe handling of the product.

I.2 Purpose of the document

This manual describes the following product life phases of the product:

- Maintenance
- Service

The manual contains the information required for using the product as intended. It is an essential component of the product.

The manual must be available at the product site throughout the entire service life of the product. If the product is sold, the manual must be transferred to the new owner.

I.3 Explanation of symbols/abbreviations

The following symbols and abbreviations are used in this manual:




Symbol/Abbreviation	Use	Explanation
	For cross-reference	See
	Possibly for cross-reference	Page
Fig.	Designation of graphics	Figure
Table	Designation of tables	Table
	In the tip	Information or tip

Table I-1 Explanation of symbols/abbreviations

2 Safety

2.1 General

Read the entire manual before working with the product. The manual contains important information for your personal safety. The manual must be read and understood by all persons who work on the product in any of the product life phases.

2.1.1 Product safety

Residual danger

The product is built using state-of-the-art technology. It was designed and constructed in accordance with the accepted safety regulations. However, some residual danger remains during its operation.

There is danger to the personal safety of the operator as well as for the product and other property.

Operation

When operating the product, always observe this manual and ensure that the system is always in perfect working order.

2.1.2 Personnel qualifications



⚠ WARNING

Lack of safety training

Incorrect behavior of untrained or insufficiently trained technicians can result in severe or fatal injuries!

Before technicians work on safety-related aspects of the product:

- Ensure that the technicians are trained with regard to safety
- Train and instruct the technicians specifically for their area of responsibility

Only appropriately trained and authorized technicians are allowed to work on the product.

Persons are authorized if:

- they are familiar with the relevant safety regulations for their area of responsibility
- they have read and understood this manual
- they meet the requirements for an area of responsibility
- they were assigned an area of responsibility by the operator

The technician is responsible to third parties in his area of responsibility.

During a training session or instruction, the technician may only work on the product under the supervision of an experienced manufacturer's technician.

2.1.2.1 Operating companies

The operating company is responsible for ensuring that:

- the product is used as intended
- the product is sufficiently lubricated at all times
- all safety aspects are complied with
- the product is put out of operation if the functioning of the safety equipment is not fully guaranteed
- the technician working on the product is appropriately trained
- the technician is provided with personal protective equipment
- the operating manual is available to the technician at the operation site of the product at all times
- the technicians are kept up-to-date regarding best practice
- the technicians are informed about technical progress, modifications, and the like.
- the contracted cleaning staff only work under the supervision of a maintenance technician

2.1.2.2 Transport specialists

The transport specialist:

- is able to transport loads safely
- is able to use slings safely and properly
- is able to secure the load properly
- has experience in transportation

2.1.2.3 Fitters

The fitter:

- has very good mechanical and/or electrical knowledge
- is flexible
- has assembly experience

2.1.2.4 Commissioning technicians

The commissioning technician:

- has good programming knowledge
- has mechanical and/or electrical knowledge
- is flexible

The commissioning technician is responsible for the following tasks:

- commissioning the product
- testing the functions of the product

2.1.2.5 Manufacturer's technicians

The manufacturer's technician:

- is employed on site at the premises of the manufacturer or representative
- has very good mechanical and/or electrical knowledge
- has good software knowledge
- has maintenance, service and repair experience
- has experience with Güdel products

The manufacturer's technician is responsible for the following tasks:

- performing mechanical and electrical maintenance work in accordance with the manual
- performing mechanical and electrical service work in accordance with the manual
- cleaning the product
- replacing spare parts
- localizing and fixing malfunctions

2.1.2.6 Maintenance technicians

The maintenance technician:

- was trained by the operating company or the manufacturer
- has very good mechanical and/or electrical knowledge
- has software knowledge
- has maintenance experience
- bears responsibility for the safety of the cleaning staff

The maintenance technician is responsible for the following tasks:

- performing mechanical and electrical maintenance work in accordance with the manual
- cleaning the product
- replacing spare parts
- monitoring and instructing the cleaning staff in the safety zone during the cleaning process

2.1.2.7 Service technicians

The service technician:

- was trained by the operating company or the manufacturer
- has very good mechanical and/or electrical knowledge
- has software knowledge
- has service and repair experience
- is flexible

The service technician is responsible for the following tasks:

- performing mechanical and electrical service work in accordance with the manual
- replacing spare parts

2.1.3 Disregarding safety regulations



⚠ DANGER

Disregarding safety regulations

Disregarding safety regulations can result in damage to property, severe or fatal injuries.

- Always comply with the safety regulations

Liability

Güdel shall not be held liable under any of the following circumstances:

- The installation regulations were disregarded
- Included protective equipment was not installed
- Included protective equipment was modified
- Included monitoring equipment was not installed
- Included monitoring equipment was modified
- The product was not used as intended
- The maintenance work was not performed in the specified intervals, or was carried out incorrectly.

2.1.4 Installation instructions

Protective measures

The operating company is responsible for ensuring safe conditions in the vicinity of the product. In particular, he must ensure compliance with the general safety regulations, guidelines and standards. Before commissioning the system the operating company must check whether all the protective measures have been implemented. These must cover all hazards. This is the only way to ensure that application of the product conforms to CE regulations.

As stipulated by the Machinery Directive, the protective measures must:

- Correspond to best practices
- Comply with the required safety category

Modifications

The product must never be modified or used in a manner contrary to its intended use. 🔄 📄 27

General rules for occupational safety

The generally accepted occupational safety rules must be observed and implemented.

2.2 Hazard symbols in the manual

2.2.1 Hazard warnings

The hazard warnings are defined for the following four types of danger levels:

DANGER



DANGER

DANGER refers to hazards with a high risk of severe physical injury or immediate fatality.

WARNING



WARNING

WARNING refers to hazards with a moderate risk of severe physical injury or potential fatality.

CAUTION



CAUTION

CAUTION refers to hazards with a slight risk of moderate physical injury.











NOTE



NOTE

NOTE refers to hazards that can lead to property damage.

2.2.2 Explanation of warning symbol

Hazard warnings for personal injuries contain the symbol of the corresponding hazard.

Symbol	Explanation of symbols
	Hazards due to general causes
	Hazards due to loose connecting elements
	Hazards resulting from automatic startup
	Hazards due to falling axles
	Hazards due to heat
	Hazards due to heavy components
	Hazards due to environmental pollution
	Hand injury hazards
	Hazards due to suspended loads
	Hazards due to sharp edges of the rack

Symbol	Explanation of symbols
	Hazards due to dangerous electrical voltage
	Hazards from falling

2.3 Fundamentals of safety

2.3.1 Separating protective equipment, monitoring equipment



⚠ WARNING

Missing separating protective equipment and monitoring equipment

Missing or modified separating protective equipment and monitoring equipment may result in damage to property or serious injuries!

- Do not remove or modify separating protective equipment and monitoring equipment
- After commissioning the system, correctly attach all the separating protective equipment and monitoring equipment

For more information on separating safety and monitoring equipment, refer to the documentation on the complete system.

2.3.2 Product-specific hazards



⚠ DANGER

Hazardous voltage

The product contains components that are energized with hazardous voltages. Touching these components will cause an electric shock. Electric shocks can be fatal!

Before working in the danger area:

- Switch off the superordinate main power supply
- Secure the superordinate power supply against being switched on again (main switch of complete system)
- Ground the equipment.



⚠ WARNING

Falling axes, workpieces

Falling axes or workpieces can cause physical damage, serious or fatal injuries!

- Set down any workpieces before working in the danger area
- Never enter the area below suspended axes and workpieces
- Secure suspended axes using the stipulated equipment
- Check the belts of the telescope axes for signs of breakage and tears



⚠ WARNING

Danger of falling

There is a risk of falling when working at greater heights. Carelessness can lead to severe or fatal injuries!

- Secure yourself with appropriate personal falling protection systems when working in the danger area.

2.3.3 Material safety data sheets (MSDS)

Safety data sheets contain safety information about the materials. They are country-specific. Safety data sheets are issued, for example, for materials such as oils, greases, cleaning agents, etc. The operating company is responsible for obtaining safety data sheets for all materials used.

Safety data sheets can be obtained as follows:

- Suppliers of chemicals usually supply their substances together with safety data sheets
- Safety data sheets are available on the Internet.
(Enter "msds" and the name of the material in a search engine. Safety information about the material will be displayed.)

Read the safety data sheets carefully. Follow all the instructions. We recommend that you store the safety data sheets for future reference.



The safety data sheet for Güdel HI can be found in the download area of our company Web site <http://www.gudel.com>

3 Product description

3.1 Use

3.1.1 Intended use

The product is intended exclusively for moving and positioning workpieces and tools as well as devices.

Any other or additional use is not considered to be use in the intended manner. The manufacturer assumes no liability for any resulting damage. All risks are borne solely by the user!

3.1.2 Non-intended use

The product is not intended:

- for the movement of toxic goods
- for the movement of explosive goods
- for operation in potentially explosive areas
- for operation outside of the performance data specified by Güdel

Any use other than the specified intended use will be considered improper use and is prohibited!

Do not make any modifications to the product.

4 Design, function

4.1 Design




Fig. 4-1

Design sizes 3-5

A	Y-carriage plate	I	Telescope 1st level
B	Energy chain	J	Plate
C	Z-drive (Güdel gearbox unit)	K	Telescope 2nd level
D	Guide pulley, top	L	Guideway of the ball-bearing cycle
E	Cog belt	M	Belt monitor
F	Bumper unit (limit stop)	N	Synchronization mark
G	Lubricating pinion unit	O	Guide pulley, bottom
H	Locking bolt		

4.2 Function

The telescopic axis is driven in the first level by the rack and drive pinion. The second level is operated by a cog belt running on guide pulleys.

The telescopic axis can be moved in the following axes:




Fig. 4-2

Axis names

- Z1 Telescopic axis 1st level
- Z2 Telescopic axis 2nd level

4.2.1 Moving the axis

Incremental movements are a load on the ball-bearing cycle. We recommend moving the axis only axially. This applies to manual movements as well as during operation.




Fig. 4-3

Moving the axis

4.2.2 Belt monitor

The 2nd level of the telescopic axis is held only by the two upper cog belts.

⚠ WARNING



Tearing of the cog belt

There are two cog belts on the product. If a cog belt tears, the 2nd level and the payload will be carried by the intact cog belt. If the intact cog belt also tears, this can result in serious or fatal injuries!

- Make sure that the axis can no longer be moved when a cog belt has torn
- Take appropriate measures
- Immediately replace torn cog belts

There is belt monitoring. If the cog belt tears, the bolt of the stop screw moves. Use the signal of your initiator to warn maintenance and service personnel early. The stop screw and sensor holder are pre-assembled on both sides as shown in the following illustration:




Fig. 4-4

Belt monitor

- A Stop bolt
- B Cog belt
- C Stop pin with sensor

4.2.3 Installing locking bolts



⚠ WARNING

Falling axes

The 2nd level of the telescope axis is held only by the cog belt. After removing the belt anchorage, it drops down. This can lead to severe or fatal injuries!

- Secure the 2nd level against falling before loosening the belt anchorage.




Fig. 4-5

Installing locking bolts

- A Telescopic axis
- B Locking bolt
- C Screw

Install the locking bolt as follows:

- 1 Use telescope axis to move to one of the end positions
- 2 Push locking bolt through hole
- 3 Install the screws

The locking bolt is fitted.

5 Transport

The product is transported by air, land, or water. The packaging depends on the mode of transport.

Truck	=	Shipped on a transport pallet
Aircraft	=	Shipped in a crate
Ship	=	Shipped in a case or container

Only perform the tasks described in this chapter after you have read and understood the chapter "Safety". ➔ 15
It concerns your personal safety!

⚠ WARNING



Ripping of lifting belts

The sharp edges cut the lifting belts. This can lead to severe or fatal injuries!

- Always protect the lifting belts with an edge guard

⚠ WARNING



Suspended loads

Improper handling of suspended loads can lead to severe injuries or death!

- Use appropriate lifting units
- Wear appropriate protective clothing
- Always keep sufficient distance from suspended loads
- Never enter the area below a suspended load

NOTE

Improper transport

Improper handling of the crates can lead to transport damage!

- Do not tip over the crates
- Avoid heavy vibrations and shocks
- Observe the symbols on the packaging

5.1 Packaging symbols

When moving the transport pallets / crates / cases, observe the following symbols:




Fig. 5-1

Attaching slings

- A Center of gravity
- B Fastening point

Depending on the contents, the packaging units are marked with the symbols shown below. Observe these at all times.




Fig. 5-2

Packaging symbols

- A Fragile
- B This side up
- C Keep dry
- D Handle with care

Remove the packaging only to the degree necessary for company-internal transport.

Transport the pallet, crate, or case to the intended installation location. Use appropriate transport devices.

5.2 Industrial trucks

Industrial trucks have to be capable of handling the size and weight of the crate. The driver of the industrial truck must be authorized to drive the vehicle.

5.3 Slings

Slings, chains, ropes or belts must be suitable for the load of weight of the crate. Fasten the slings to stable parts. Secure the slings against slipping. Make sure that no attachments are damaged by the slings.

5.3.1 Attaching the slings: Z-axis, sizes 2-5




Fig. 5-3 Attaching the slings: Z-axis, sizes 2-5

A	Hook	C	Shackle
B	Lifting belts	D	Z-axis

Product size	Shackle bolt diameter [mm]	Shackle payload [kg]
2 + 3	10	400
4 + 5	16	1000

Table 5-1 Z-axis slings: Sizes

Attach the slings as follows:

- 1 Mount the shackle and lifting belts as illustrated
- 2 Hang the lifting belts into the hooks

The slings are in place.

5.4 Setting up or laying down the telescopic axis

⚠ WARNING



Ripping of lifting belts

The sharp edges of the rack cut the lifting belts. This can lead to severe or fatal injuries!

- Always protect the lifting belts with the guard plate

⚠ WARNING



Falling axes

The 2nd level of the telescopic axis is held by the drive or the locking bolt. After removing the drive or the locking bolt, it drops down. This can lead to severe or fatal injuries!

- Mount the safety bolt

⚠ WARNING



Suspended loads

Improper handling of suspended loads can lead to severe injuries or death!

- Use appropriate lifting units
- Wear appropriate protective clothing
- Always keep sufficient distance from suspended loads
- Never enter the area below a suspended load

NOTE

Overloading the ball-bearing cycle

If the telescopic axis is supported on the 2nd level against the direction of the axis, the ball-bearing cycles will be overloaded. The ball-bearing cycles will be destroyed.

- Never support the telescopic axis on the 2nd level during set-up
- Never attach the sling to the 2nd level
- Use two lifting units to bring the telescopic axis from a horizontal to a vertical position
- Use two lifting units to bring the telescopic axis from a vertical to a horizontal position




Fig. 5-4

Setting up or laying down the telescopic axis: Sizes 3-5

A Telescope 2nd level

Set up or lay down the telescopic axis as follows:

Prerequisite: The sling is attached to the 1st level

Prerequisite: The locking bolt is fitted

- 1** Position the lifting belts as shown in the illustration
- 2** Attach the lifting belt to a second lifting unit
- 3** Set up or lay down the telescopic axis as shown in the illustration

The telescopic axis is set up or laid down.

6 Installing

6.1 Installing the Z-axis

In some cases, the Z-axis is not yet mounted on delivery. Depending on the available space, the Z-axis can be inserted into the carriage from the top or the bottom.

6.1.1 Attaching the slings: Z-axis, sizes 2-5




Fig. 6-1

Attaching the slings: Z-axis, sizes 2-5

- | | | | |
|---|---------------|---|---------|
| A | Hook | C | Shackle |
| B | Lifting belts | D | Z-axis |

Product size	Shackle bolt diameter [mm]	Shackle payload [kg]
2 + 3	10	400
4 + 5	16	1000

Table 6-1

Z-axis slings: Sizes

Attach the slings as follows:

- 1 Mount the shackle and lifting belts as illustrated
- 2 Hang the lifting belts into the hooks

The slings are in place.

6.1.2 Preparations

Prepare the retraction of the Z-axis as follows:

- 1 Remove the upper or lower bumper unit of the Z-axis
- 2 Remove the wiper at the Z-carriage
- 3 Remove the rotary axis if necessary
- 4 Remove the motor if necessary
- 5 Vent the safety brake system if necessary
(Power connection according to the type place of the safety brake)

The retraction of the Z-axis has been prepared.

6.1.3 Inserting the Z-axis



⚠ WARNING

Suspended loads

Improper handling of suspended loads can lead to severe injuries or death!

- Use appropriate lifting units
- Wear appropriate protective clothing
- Always keep sufficient distance from suspended loads
- Never enter the area below a suspended load

Retract the Z-axis as follows:

- 1 Attach the slings to the Z-axis
- 2 Retract the Z-axis into the carriage
- 3 Install the components:
 - 3.1 Wiper
 - 3.2 Rotary axis if present
 - 3.3 Motor if present
- 4 De-energize the safety brake system if necessary
- 5 Secure the Z-axis against falling

The Z-axis has been retracted.

6.1.4 Assembling the bumper unit

Some bumper units cannot be shipped in a properly assembled state for assembly and packaging reasons. In such cases, the entire bumper unit is shipped unassembled. The assembly site is designated with a danger label. Find the correct assembly site on the layout.

⚠ WARNING



Incorrectly installed safety component

The bumper unit is a safety component. Incorrectly installed bumper units may lead to severe injury or death!

- Drill the pinhole into the mating part of the bumper unit if necessary
- Install all associated components
- Tighten all screws with a torque wrench to the specified tightening torques
- Check if the shearing sleeves and/or pins are fully and correctly assembled




Fig. 6-2

Danger label "Provisionally assembled bumper unit"

- A Assembly site of the bumper unit
- B Danger label "Provisionally assembled bumper unit"

The danger label "Provisionally assembled bumper unit" warns against

- Provisionally assembled or non-assembled bumper units
- Moving the axes before proper assembly of the bumper unit

6.1.4.1 Bumper unit with limit stops




Fig. 6-3

Bumper unit with mechanical limit stops

A	"Loctite 7414, blue" threadlocker	D	Bumper block / bumper bracket
B	Screw	E	Mating part
C	Bumpers		

Install the bumper unit as follows:

- 1 Install the bumper on the bumper block / bracket
- 2 Remove the warning sticker from the installation site if necessary
- 3 Clean the contact surface of the mating part meticulously
- 4 Position the pre-assembled bumper unit on the mating part
- 5 Tighten the screws
- 6 Check the bumper unit for correct fit
- 7 Seal all screws with "Loctite 7414, blue" threadlocker

The bumper unit has now been installed.

6.2 Güdel gearbox unit

6.2.1 Installing the motor

6.2.1.1 Information on initial assembly

The range of motors for the gearbox unit is very broad. The same applies to the dimensions of the motor shafts. A design solution was selected that allowed for the greatest variety of motor to be mounted on the gearbox unit. The increased expense for the initial assembly was consciously taken into account. It normally occurs only once during the entire service life of the gearbox unit. For maintenance tasks and repair, the motor is simply disassembled and remounted with one half of the elastomer coupling.

6.2.1.2 Prerequisites

Three conditions must be fulfilled simultaneously to allow you to install the motor on the gearbox unit:

- The gearbox flange is aligned to allow the coupling screws to be tightened through the drill holes of the gearbox flange with a torque wrench
- The input shaft with installed wedge must be positioned with the coupling attached to allow the coupling screws to be tightened through the drill holes of the gearbox flange
- In the event of angled motor flanges, the motor must be aligned to the motor flange to allow the motor screws to be fitted and tightened

6.2.1.3 Aligning the gearbox flange

You can align the gearbox flange. When correctly aligned, the motor and coupling can be installed.




Fig. 6-4 Aligning the gearbox flange

- | | | | |
|---|--------------------|---|-----------------------|
| A | Articulated socket | G | Coupling |
| B | Torque wrench | H | Screw |
| C | Gearbox | I | Motor flange |
| D | Plug | J | Gearbox flange |
| E | Drill hole | K | Fastening screw |
| F | Coupling screw | L | Adjacent construction |

Align the gearbox flange as follows:

Prerequisite: The gearbox unit has been installed on the adjacent construction

- 1** Switch off the system and secure it with a padlock against being switched on again
- 2** Remove the plug
- 3** Check whether the coupling screws can be reached through the drill hole and tightened with a torque wrench
- 4** If there are deviations:
 - 4.1** Remove the coupling
 - 4.2** Remove the fastening screws, screws and motor flange
 - 4.3** Align the gearbox flange
 - 4.4** Install and tighten the fastening screws
 - 4.5** Install the motor flange
 - 4.6** Install and tighten the screws
 - 4.7** Place the coupling on the input shaft
- 5** Install the plug

The gearbox flange has now been aligned.

6.2.1.4 Aligning the input shaft to the gearbox flange

⚠ WARNING



Moving the axis

The work requires moving the axis. This can lead to severe or fatal injuries!

- Ensure that no persons are in the danger area while the axis is moving




Fig. 6-5

Aligning the input shaft to the gearbox flange

- | | | | |
|---|-------------|---|----------------|
| A | Drill hole | E | Coupling screw |
| B | Wedge | F | Coupling |
| C | Input shaft | G | Gearbox flange |
| D | Plug | | |

Align the input shaft to the gearbox flange as follows:

Prerequisite: The gearbox unit has been installed on the adjacent construction

Prerequisite: The gearbox flange has been aligned correctly

Prerequisite: The wedge has been installed on the gearbox side

Prerequisite: The coupling has been placed correctly on the input shaft

- 1 Check whether the coupling screws can be reached through the drill holes
- 2 If there are deviations: Traverse the axis until the coupling screws can be reached through the drill holes
- 3 Switch off the system and secure it with a padlock against being switched on again

The input shaft has been aligned to the gearbox flange.

6.2.1.5 Positioning the coupling on the motor shaft

NOTE

Defective coupling

The coupling is destroyed if the coupling screws are tightened and the coupling is not installed on the shaft.

- Tighten the coupling screws only when the coupling is installed on the shaft.



The tightening torque TA and the type of coupling are engraved on the motor and gearbox sides in the coupling.




Fig. 6-6 Positioning the coupling on the motor shaft: Elastomer coupling

- | | | | |
|---|----------------------|---|----------------------|
| A | Gearbox | E | Installation surface |
| B | Motor flange | F | Coupling screw |
| C | Measuring instrument | G | Motor shaft |
| D | Coupling | H | Motor |

$$X = Z - Y$$

Fig. 6-7 X dimension calculation formula

Güdel HPG gearbox unit size	Coupling type	L dimension [mm]	L dimension tolerance [mm]	Y dimension [mm]	X dimension tolerance [mm]
030	GWE 5103-19-SP	50	$L^{+1}_{+0.5}$	8.5	$X^{+0.5}_{-1}$
	GWE 5103-14-SP	32	$L^{+1}_{+0.5}$	15.5	$X^{+0.5}_0$

Güdel HPG gearbox unit size	Coupling type	L dimension [mm]	L dimension tolerance [mm]	Y dimension [mm]	X dimension tolerance [mm]
045	GWE 5103-24-SP	54	$L^{+1}_{+0.5}$	11	$X^{+0.5}_0$
	GWE 5103-19-SP	50	$L^{+1}_{+0.5}$	10	$X^{+0.5}_0$
060	GWE 5103-28-SP	62	$L^{+1}_{+0.5}$	16.5	X^{+1}_{-3}
	GWE 5103-24-SP	54	$L^{+1}_{+0.5}$	18.5	X^{+1}_{-2}
090	GWE 5103-38-SP	76	$L^{+1.2}_{+0.5}$	25	X^{+1}_{-2}
	GWE 5103-28-SP	62	$L^{+1}_{+0.5}$	29	X^{+1}_{-2}
120	GWE 5103-42-SP	102	$L^{+1.2}_{+0.5}$	24	X^{+1}_{-3}
	GWE 5103-38-SP	76	$L^{+1.2}_{+0.5}$	36	X^{+1}_{-1}

Table 6-3 Weight and tolerances for the elastomer coupling




Fig. 6-8 Position the coupling on the motor shaft: Make use of X dimension tolerance

Cleaning agents

mild universal cleaner free from aromatic compounds (e.g. Motorex OPAL 5000)

Table 6-3 Cleaning agents: Gearbox unit Güdel: Coupling and motor shaft

Tool	Use	Item number
Corrosion protection agent MOTOREX In-tact XD 20	Installing the coupling Applying corrosion protection to the product	0502037

Table 6-4 Special tools, testing and measuring instruments

Position the coupling on the motor shaft as follows:

Prerequisite: The transport securing device in effect at the gearbox is disassembled

- 1 Clean the coupling and motor shaft to ensure that they are free of grease
- 2 If desired by the customer, mount the wedge on the motor shaft (wedge on motor shaft not essentially necessary)
- 3 Apply corrosion protection agent to the motor shaft with a brush
- 4 Measure the distance Z
- 5 Push the coupling onto the motor shaft (set L dimension according to table)
- 6 Position the coupling on the motor shaft:
 - 6.1 Calculate dimension X and position coupling according to the calculated dimension
 - 6.2 Coupling rest a little on the motor shaft: Make use of X dimension tolerance
- 7 Tighten the coupling screws:
 - 7.1 Tighten alternately to 50% of the tightening torque TA
 - 7.2 Tighten alternately with 100% of the tightening torque TA

The coupling is positioned.

6.2.1.6 Installing the motor and coupling



⚠ WARNING

Heavy components

Components can be very heavy. Improper handling can cause severe or fatal injuries!

- Use appropriate lifting equipment
- Use suitable means to secure the parts against tipping over or falling down
- Remove the safety devices only after the product has been completely installed



Vent the motor brake according to the specifications of the motor manufacturer



The tightening torque TA and the type of coupling are engraved on the motor and gearbox sides in the coupling.




Fig. 6-9

Installing the motor and coupling

A	Coupling screw	E	Motor
B	Drill hole	F	Coupling
C	Plug	G	Motor screw
D	Motor flange		

Cleaning agents

mild universal cleaner free from aromatic compounds (e.g. Motorex OPAL 5000)

Table 6-5

Cleaning agents: Gearbox unit Güdel: coupling, input shaft and wedge

Tool	Use	Item number
Corrosion protection agent MOTOREX In-tact XD 20	Installing the coupling Applying corrosion protection to the product	0502037

Table 6-6 Special tools, testing and measuring instruments



Install the motor and coupling as follows:

Prerequisite: The gearbox unit has been installed on the adjacent construction

Prerequisite: The gearbox flange has been aligned correctly

Prerequisite: The input shaft has been aligned correctly to the gearbox flange

Prerequisite: The coupling has been positioned correctly on the motor shaft

- 1 Switch off the system and secure it with a padlock against being switched on again
- 2 Attach slings to the motor if necessary   I 16
- 3 Clean the coupling, input shaft and wedge to remove any grease
- 4 Install the wedge on the input shaft
- 5 Apply corrosion protection agent to the wedge and input shaft with a brush
- 6 Push the motor with installed coupling onto the gearbox unit
- 7 Install and tighten the motor screws
- 8 If the motor screws cannot be fitted:
 - 8.1 Vent the motor brake if necessary
 - 8.2 Turn the motor into the correct installation position
 - 8.3 Repeat the procedure from step 7
- 9 Tighten the coupling screws:
 - 9.1 Tighten alternately to 50% of the tightening torque TA
 - 9.2 Tighten alternately with 100% of the tightening torque TA
- 10 Install the plug

The motor and the coupling have been installed.

7 Maintenance

7.1 Introduction

<i>Work sequences</i>	Perform the work sequences in the order described. Perform the described tasks at the specified times. This ensures a long service life for your product.
<i>Original spare parts</i>	Only use original spare parts. ➔ 📄 202
<i>Third-party products</i>	For information on third-party products, read the appropriate documents in the appendix.
<i>Tightening torques</i>	Unless otherwise indicated, adhere to the tightening torques of Güdel. ➔ Chapter 10, 📄 209

7.1.1 Safety

Only perform the tasks described in this chapter after you have read and understood the chapter "Safety". ➔ 📄 15
It concerns your personal safety!



⚠️ WARNING

Automatic startup

During work on the product, there is danger of the machine starting up automatically. This can lead to severe or fatal injuries!

Before working in the danger area:

- Secure vertical axes (if equipped) against falling.
- Switch off the superordinate main power supply. Secure it against being switched on again (main switch for the complete system)
- Before switching on the system again, make sure that no one is in the danger area



⚠ WARNING

Falling axes, workpieces

Falling axes or workpieces can cause physical damage, serious or fatal injuries!

- Set down any workpieces before working in the danger area
- Never enter the area below suspended axes and workpieces
- Secure suspended axes using the stipulated equipment
- Check the belts of the telescope axes for signs of breakage and tears



⚠ WARNING

Heavy components

Components can be very heavy. Improper handling can cause severe or fatal injuries!

- Use appropriate lifting equipment
- Use suitable means to secure the parts against tipping over or falling down
- Remove the safety devices only after the product has been completely installed

7.1.2 Personnel qualifications

Only appropriately trained and authorized technicians are allowed to work on the product.

7.2 Consumables and auxiliary agents

7.2.1 Cleaning agents

Use a soft rag or cloth for cleaning tasks. Only use permissible cleaning agents.

7.2.1.1 Table of cleaning agents

Cleaning agents	Location of application
mild universal cleaner free from aromatic compounds (e.g. Motorex OPAL 5000)	Gearbox unit Güdel: Coupling and motor shaft
	Gearbox unit Güdel: coupling, input shaft and wedge

This table does not purport to be exhaustive.

Table 7-1 Table of cleaning agents

7.2.2 Lubricants

NOTE

Unsuitable lubricants

Using unsuitable lubricants can cause damage to the machine!

- Only use the lubricants listed
- If uncertain, please contact our service departments

For more information on the lubricants, refer to the tables below. For further information, refer to the chapter "Maintenance tasks" and the respective third party documentation.

Special Güdel lubricants

If special lubricants have been delivered ex-works at the request of the customer, you can find the relevant specifications in the spare parts list.

Alternative manufacturers

The following tables show the specifications of the lubricants. Please inform your manufacturer accordingly. They will then suggest an alternative from their product range.

Low temperatures / food grade

Observe the application range limits of lubricants according to the safety data sheet.

7.2.2.1 Lubrication

Manual / automatic lubrication system

The guideways, racks and pinions of the product are lubricated either manually or automatically.

Lubrication cycle

Güdel recommends a lubrication cycle of 150 h or 100 km, whichever occurs first. With automatic lubrication it may not be possible to set this lubrication cycle exactly. In this case, select the nearest lubrication cycle. Perform lubrication work as soon as the first signs of tribocorrosion (reddish discoloration of the track) are visible.

Manual lubrication

The following lubrication systems and lubricants are intended for the manual lubrication of the product:



Fig. 7-1

Lubricating manually with grease

Lubrication ex works	Specification	Lubrication quantity	Location of application	Category
Mobil Mobilux EP 2	KP2K-30 in accordance with DIN 51502	As per instructions	Guideways, racks, and pinions	grease

Table 7-2

Lubricants: Guideways, racks, and pinions



Fig. 7-2

Lubricating manually with oil

Lubrication ex works	Specification	Lubrication quantity	Location of application	Category
Güdel HI NSF no. I4662 I	cannot be found	As per instructions	Guideways, racks, and pinions	oil

Table 7-3

Lubricants: Guideways, racks, and pinions



Fig. 7-3 Lubricating manually with oil

Lubrication ex works	Specifica-tion	Lubrica-tion quantity	Location of appli-cation	Cate-gory
Elkalub FLC 8 HI	Cannot be determined		Pre-lubricate guide-ways and racks	Oil

Table 7-4 Lubricants: Pre-lubricate guideways and racks

Markings at the lubrication points

The markings apply to manual lubrication of the following Güdel components:

- Roller support
- Lubricating pinion unit
- Wiper and lubrication unit




Fig. 7-4 Markings at the lubrication points

- A Identification disc
- B Grease nipple

Yellow identification disc: Grease
 Red identification disc: Oil

Automatic lubrication system

The following lubrication systems and lubricants are provided for the automatic lubrication of the product:



Fig. 7-5 Automatic lubrication system FlexxPump

Lubrication ex works	Specification	Lubrication quantity	Location of application	Category
Güdel HI NSF no. I4662I	cannot be found		Automatic lubrication system FlexxPump	oil

Table 7-5 Lubricants: Automatic lubrication system FlexxPump



Fig. 7-6 Automatic lubrication system FlexxPump

Lubrication ex works	Specification	Lubrication quantity	Location of application	Category
Elkalub FLC 8 HI	Cannot be determined		Automatic lubrication system FlexxPump: Prelubricate guideways and racks	Oil

Table 7-6 Lubricants: Automatic lubrication system FlexxPump: Prelubricate guideways and racks



Fig. 7-7 Automatic lubrication system Memolub

Lubrication ex works	Specifica-tion	Lubrica-tion quantity	Location of appli-cation	Cate-gory
Castrol Longtime PD	2KP2K-30 in accordance with DIN 51502		Automatic lubrica-tion system Memolub	grease

Table 7-7 Lubricants: Automatic lubrication system Memolub



Fig. 7-8 Automatic lubrication system Memolub

Lubrication ex works	Specifica-tion	Lubrica-tion quantity	Location of appli-cation	Cate-gory
Mobil Gly-goyle 460 NSF no.136467	CLP PG 460 in accor-dance with DIN 51502		Automatic lubrica-tion system Memolub	oil

Table 7-8 Lubricants: Automatic lubrication system Memolub



Fig. 7-9 SKF-Vogel automatic lubrication system

Lubrication ex works	Specifica-tion	Lubrica-tion quantity	Location of appli-cation	Cate-gory
Shell Gadus S2 V220 00	GP00G-20 in accordance with DIN 51502	1000 ml	SKF-Vogel automatic lubrication system	grease

Table 7-9 Lubricants: SKF-Vogel automatic lubrication system

7.2.2.2 Lubricant table

Lubrication ex works	Specification	Lubrication quantity	Location of application	Category
Aral Arcanol LOAD 150	KP2N-20 in accordance with DIN 51825 high-quality lithium complex soap grease	20: 1.3g 25: 1.7g 30: 3.6g 35: 5g 55: 12g	Ball-bearing cycle	grease
	KP2N-20 in accordance with DIN 51825 high-quality lithium complex soap grease		Bearing of the guide pulley	grease
Castrol Longtime PD	2KP2K-30 in accordance with DIN 51502		Automatic lubrication system Memolub	grease
Elkalub FLC 8 HI	Cannot be determined		Automatic lubrication system FlexxPump: Prelubricate guideways and racks	Oil
	Cannot be determined		Pre-lubricate guideways and racks	Oil
Güdel HI NSF no.146621	cannot be found		Automatic lubrication system FlexxPump	oil
	cannot be found		Guideways, racks, and pinions	oil

Lubrication ex works	Specification	Lubrication quantity	Location of application	Category
Mobil Glygoyle 460 NSF no.136467	CLP PG 460 in accordance with DIN 51502		Automatic lubrication system Memolub	oil
	CLP PG 460 in accordance with DIN 51502		Gearbox unit Güdel	oil
Mobil Mobilux EP 2	KP2K-30 in accordance with DIN 51502	As per instructions	Guideways, racks, and pinions	grease
Shell Gadus S2 V220 00	GP00G-20 in accordance with DIN 51502	1000 ml	SKF-Vogel automatic lubrication system	grease
Technical Vaseline	Cannot be determined		Gearbox unit Güdel: elastomer gear rim of the coupling	Grease



This table does not purport to be exhaustive.

Table 7-10 Lubricant table

7.3 Maintenance tasks

7.3.1 General prerequisites

Prior to performing repair and maintenance tasks, do the following:

- If vertical axes are present, secure them against falling
- Switch off the system and padlock it to secure it against being switched on again
- Make sure that all necessary spare parts and wearing parts are at hand
  202

7.3.2 Maintenance intervals

The product is subject to natural wear and tear. It wears out, which can cause unscheduled downtimes of your system. Güdel defines the service life and maintenance intervals of the product to ensure safe, uninterrupted operation. The maintenance intervals apply to the effective operating hours of the product at a duty cycle (ED) of 100%. Normal operating conditions are assumed, which correspond to the parameters defined by Güdel when designing the product. If the conditions are rougher than assumed, products may fail earlier. Adjust the maintenance intervals to your operating conditions if necessary.

Duty cycle				
100%	80%	60%	40%	20%
2'250	2'750	3'750	5'625	11'250
6'750	8'250	11'250	16'875	33'750
11'250	13'750	18'750	28'125	56'250
22'500	27'500	37'500	56'250	112'500

Table 7-11

Conversion table: Operating hours at the respective duty cycle



The definition is based on 5/7 working days per week.

Operating hours	1-shift operation	2-shift operation	3-shift operation
150	every 4 weeks	every 2 weeks	Weekly
2'250	yearly	every 6 months	every 4 months
6'750	every 3 years	every 1.5 years	yearly
11'250	every 5 years	every 2.5 years	every 20 months
13'500	every 6 years	every 3 years	every 2 years
22'500	every 10 years	every 5 years	every 3.3 years
31'500	every 14 years	every 7 years	every 4.5 years
54'000	every 24 years	every 12 years	every 8 years

Table 7-12 Maintenance intervals in shift operation (5 days a week)

Operating hours	1-shift operation	2-shift operation	3-shift operation
150	every 18 days	every 9 days	every 6 days
2'250	every 9 months	every 4.5 months	every 3 months
6'750	every 2.5 years	every 15 months	every 10 months
11'250	every 4 years	every 2 years	every 16 months
13'500	every 4.5 years	every 3 years	every 1.5 years
22'500	every 7.75 years	every 3.8 years	every 2.5 years
31'500	every 11 years	every 5.5 years	every 3.5 years
54'000	every 18.5 years	every 9.25 years	every 6.25 years

Table 7-13 Maintenance intervals in shift operation (7 days a week)

7.3.3 Special tools, testing and measuring instruments

Ensure that you have the following special tools, testing and measuring instruments at hand:

Tool	Use	Item number
Belt tension measuring instrument	Tensioning the cog belt	0214960
Test pin	Checking rack transition	
Dial gauge	Setting the tooth flank backlash Checking the circular run-out of the motor shaft	
Screw clamps	Installing the racks	
Mounting aid	Installing the rack: Module 4, helical	902284
Mounting aid	Installing the rack: Module 6, helical	902286
Mounting aid	Installing the guideway/ rack: Module 1.5915, straight toothed	902401
Mounting aid	Installing the guideway/ rack: Module 2.3873, straight toothed	902402
Mounting aid	Installing the guideway/ rack: Module 3.1831, straight toothed	902403

Table 7-14 Special tools, testing and measuring instruments

7.3.4 Maintenance tasks after 150 hours

7.3.4.1 Lubricating guideways, racks and pinions

Lubricate the guideways, racks, and pinions according to the superordinate operating manual.

7.3.5 Maintenance tasks after 2,250 hours

7.3.5.1 General inspection

Perform the general inspection according to superordinate operating manual.

7.3.5.2 Lubricating the ball-bearing cycle

⚠ WARNING



Moving the axis

The work requires moving the axis. This can lead to severe or fatal injuries!

- Ensure that no persons are in the danger area while the axis is moving

D003492




Fig. 7-10

Ball-bearing cycle (image source: INA)

Lubrication ex works	Specification	Lubrication quantity
Aral Arcanol LOAD 150	KP2N-20 in accordance with DIN 51825 high-quality lithium complex soap grease	20: 1.3g 25: 1.7g 30: 3.6g 35: 5g 55: 12g

Table 7-15

Lubricants: Ball-bearing cycle

Lubricate the ball-bearing cycle as follows:

- 1** Press lubricant into the respective lubrication point by hand using a grease gun
- 2** Move the axle along the entire path four times

The ball-bearing cycle has been lubricated.

7.3.5.3 Lubricating bearing of the guide pulley




Fig. 7-11 Lubricating bearing of the guide pulley

- A Belt
- B Guide pulley
- C Lubrication nipple

Lubrication ex works	Specification	Lubrication quantity
Aral Arcanol LOAD 150	KP2N-20 in accordance with DIN 51825 high-quality lithium complex soap grease	

Table 7-16 Lubricants: Bearing of the guide pulley

Lubricate all the guide pulley bearings as follows:

- 1 Switch off the system and padlock it to secure it against being switched on again
 - 2 Lubricating all bearings of the guide pulleys
- The bearings of the guide pulleys are lubricated.

7.3.6 Maintenance tasks after 6,750 hours

7.3.6.1 Replacing the lubricating pinion



Replace the lubricating pinion according to superordinate operating manual.




Fig. 7-12

Replacing the lubricating pinion

- A Telescopic axis
- B Lubricating pinion unit
- C Y-carriage




Replace the lubricating pinion as follows:

- 1 Switch off the system and secure it against being switched back on again with a padlock
- 2 Secure the telescope axis against falling
- 3 Replace the lubricating pinion according to superordinate operating manual
- 4 Remove the padlock

The lubricating pinion has been replaced.

7.3.7 Maintenance tasks after 22,500 hours

7.3.7.1 Replacing the cog belt

Distinguishing characteristics of wear	Figure
<p>Fabric at the tooth head and tooth root is worn.</p>	
<p>Cracks visible on tooth foot when tooth pressed. It is not considered wear if the fabric loosens from the tooth base without cracks on the tooth foot.</p>	
<p>Cog belt has swollen and draw heads become visible on the side of back</p>	




Distinguishing characteristics of wear	Figure
<p>The base material has become brittle due to natural aging or high temperatures</p>	
<p>Teeth are damaged or are missing</p>	
<p>Cog belt is torn</p>	

Table 7-17 Wear characteristics of the cog belt

Installing locking bolts



⚠ WARNING

Falling axes

The 2nd level of the telescope axis is held only by the cog belt. After removing the belt anchorage, it drops down. This can lead to severe or fatal injuries!

- Secure the 2nd level against falling before loosening the belt anchorage.




Fig. 7-13

Installing locking bolts

- A Telescopic axis
- B Locking bolt
- C Screw

Install the locking bolt as follows:

- 1 Use telescope axis to move to one of the end positions
- 2 Push locking bolt through hole
- 3 Install the screws

The locking bolt is fitted.

Cog belt right



⚠ WARNING

Falling axes

The 2nd level of the telescope axis is held only by the cog belt. After removing the belt anchorage, it drops down. This can lead to severe or fatal injuries!

- Secure the 2nd level against falling before loosening the belt anchorage.

Removing the belt anchorage: 2nd level, rotating




Fig. 7-14

Removing the belt anchorage: 2nd level, rotating

- | | | | |
|---|----------------|---|----------------|
| A | Screw | C | Cog belt |
| B | Clamping plate | D | Telescope axis |

Remove the rotating belt anchorage of the 2nd level as follows:

- 1 Mark the position of the clamping plate on the cog belt
- 2 Remove the screws
- 3 Remove clamping plate

The rotating belt anchorage of the 2nd level is removed.

Removing the belt anchorage: 2nd level, fixed




Fig. 7-15

Removing the belt anchorage: 2nd level, fixed, right

- | | | | |
|---|----------------|---|----------------|
| A | Clamping plate | C | Belt tensioner |
| B | Cog belt | D | Screw |

Remove the fixed belt anchorage as follows:

- 1 Mark the position of the clamping plates on the cog belts
- 2 Remove the screws
- 3 Remove clamping plates

The fixed belt anchorage is removed.

Cog belt left



⚠ WARNING

Falling axes

The 2nd level of the telescope axis is held only by the cog belt. After removing the belt anchorage, it drops down. This can lead to severe or fatal injuries!

- Secure the 2nd level against falling before loosening the belt anchorage.

Removing the belt anchorage: 2nd level, rotating




Fig. 7-16

Removing the belt anchorage: 2nd level, rotating

- | | | | |
|---|----------------|---|----------------|
| A | Screw | C | Cog belt |
| B | Clamping plate | D | Telescope axis |

Remove the rotating belt anchorage of the 2nd level as follows:

- 1 Mark the position of the clamping plate on the cog belt
- 2 Remove the screws
- 3 Remove clamping plate

The rotating belt anchorage of the 2nd level is removed.

Removing the belt anchorage: 2nd level, fixed




Fig. 7-17

Removing the belt anchorage: 2nd level, fixed, left

- | | | | |
|---|----------|---|------------------|
| A | Screw | E | Clamping plate |
| B | Sheet | F | Belt tensioner |
| C | Holder | G | Fastening screws |
| D | Cog belt | | |

Remove the fixed belt anchorage of the 2nd level as follows:

Prerequisite: The rotating belt anchorage of the 2nd level is removed

- 1 Mark the position of the clamping plate on the cog belt
- 2 Remove screws and sheet
- 3 Remove belt tensioner downwards
- 4 Remove the fastening screws
- 5 Remove clamping plate

The fixed belt anchorage of the 2nd level is removed.

Replacing the cog belt

Replace the cog belts as follows:

Prerequisite: The telescope axis is in the upper end position

- 1 Remove the old cog belt
- 2 Transfer the markings of the old cog belt to the new cog belt
- 3 Right:
 - 3.1 Insert new cog belt
 - 3.2 Install belt anchorages (observe markings)
- 4 Left:
 - 4.1 Install the fixed belt anchorage of the 2nd level on the new cog belt (observe marking)
 - 4.2 Insert new cog belt
 - 4.3 Install the rotating belt anchorage of the 2nd level on the new cog belt (observe marking)
- 5 Checking tightening torques of the screws ➡ 📄 209
- 6 Setting the belt tension ➡ Chapter 7.3.9, 📄 140

The cog belts have been replaced.

Final tasks

Perform these final tasks as follows:

- 1 Calibrate the axis using the synchronization mark
- 2 Calibrate the shaft encoder if necessary

The final tasks have been performed.

7.3.7.2 Replacing the ball-bearing cycle



Replace the components together.

Advantages:

- You avoid repeated repairs
- You avoid unnecessary downtimes

The components are designed for continuous use. Their wear depends on the duration of operation of the product and the ambient conditions. Güdel recommends preventatively replacing components as soon as their service life has been reached. Components may fail before expiry of the service life however. Replace worn components immediately.

Distinguishing characteristics of wear

- Guideway sticks or jams
- Excessive noise is audible

Table 7-18

Distinguishing characteristics of wear: Guide unit

The term "ball-bearing cycle" includes:

- Guideway of the ball-bearing cycle
- Guide carriage of the ball-bearing cycle

Installing locking bolts

⚠ WARNING



Falling axes

The 2nd level of the telescope axis is held only by the cog belt. After removing the belt anchorage, it drops down. This can lead to severe or fatal injuries!

- Secure the 2nd level against falling before loosening the belt anchorage.




Fig. 7-18

Installing locking bolts

- A Telescopic axis
- B Locking bolt
- C Screw

Install the locking bolt as follows:

- 1 Use telescope axis to move to one of the end positions
- 2 Push locking bolt through hole
- 3 Install the screws

The locking bolt is fitted.

Attaching the slings: Z-axis, sizes 2-5




Fig. 7-19

Attaching the slings: Z-axis, sizes 2-5

- | | | | |
|---|---------------|---|---------|
| A | Hook | C | Shackle |
| B | Lifting belts | D | Z-axis |

Product size	Shackle bolt diameter [mm]	Shackle payload [kg]
2 + 3	10	400
4 + 5	16	1000

Table 7-19

Z-axis slings: Sizes

Attach the slings as follows:

- 1 Mount the shackle and lifting belts as illustrated
- 2 Hang the lifting belts into the hooks

The slings are in place.

Preparations

Make the following preparations:

- 1 Removing fixed belt anchorage of the 2nd level
Removing the belt anchorage

The preparation steps have been performed.

Moving out the vertical axis



Güdel gearbox units with a ratio $i \leq 24$ do not prevent the Z-axis being removed when mounted. In the case of larger ratios remove the Güdel gearbox unit.

Move out the vertical axis as follows:

- 1** Switch off the system and padlock it to secure it against being switched on again
- 2** Install locking bolts
- 3** Disassemble the rotary axis if necessary
- 4** Disassemble the energy chain
- 5** Attach the slings
- 6** Remove the upper bumper unit
- 7** Remove the wipers
- 8** Vent the motor brake or remove the motor
- 9** Vent the safety brake system if necessary
- 10** Remove the vertical axis

The vertical axis has been moved out.

Setting up or laying down the telescopic axis



⚠ WARNING

Ripping of lifting belts

The sharp edges of the rack cut the lifting belts. This can lead to severe or fatal injuries!

- Always protect the lifting belts with the guard plate



⚠ WARNING

Falling axes

The 2nd level of the telescopic axis is held by the drive or the locking bolt. After removing the drive or the locking bolt, it drops down. This can lead to severe or fatal injuries!

- Mount the safety bolt



⚠ WARNING

Suspended loads

Improper handling of suspended loads can lead to severe injuries or death!

- Use appropriate lifting units
- Wear appropriate protective clothing
- Always keep sufficient distance from suspended loads
- Never enter the area below a suspended load

NOTE**Overloading the ball-bearing cycle**

If the telescopic axis is supported on the 2nd level against the direction of the axis, the ball-bearing cycles will be overloaded. The ball-bearing cycles will be destroyed.

- Never support the telescopic axis on the 2nd level during set-up
- Never attach the sling to the 2nd level
- Use two lifting units to bring the telescopic axis from a horizontal to a vertical position
- Use two lifting units to bring the telescopic axis from a vertical to a horizontal position




Fig. 7-20

Setting up or laying down the telescopic axis: Sizes 3-5

A Telescope 2nd level

Set up or lay down the telescopic axis as follows:

Prerequisite: The sling is attached to the 1st level

Prerequisite: The locking bolt is fitted

- 1** Position the lifting belts as shown in the illustration
- 2** Attach the lifting belt to a second lifting unit
- 3** Set up or lay down the telescopic axis as shown in the illustration

The telescopic axis is set up or laid down.

Removing limit stop



Use flat head screws or fitting screw ISO 7379 as auxiliary agents to center the holes. The fitting screws may need to be modified.




Fig. 7-21

Removing limit stop

- A Limit stop
- B Screw
- C Telescope axis

Remove the limit stop as follows:

- 1 Remove the screws
- 2 Remove limit stop

The limit stop has been removed.

Remove locking bolt



⚠ WARNING

Falling axes

After removing the transport securing device, brakes or motors, the vertical axes fall downwards. Carriages may run off to the side. This can lead to severe or fatal injuries!

- If necessary, secure the vertical axes and the carriages before removing transport securing devices, brakes or motors

Remove the locking bolt as follows:

- I Remove locking bolt

The locking bolt has been removed.

Replacing the guideway of the ball-bearing cycle



Use flat head screws or fitting screw ISO 7379 as auxiliary agents to center the holes. The fitting screws may need to be modified.




Fig. 7-22

Replacing the guideway of the ball-bearing cycle: Extending the 2nd level

Replace the guideway as follows:

- 1 Remove the 2nd level (the bearing balls of the guide carriage fall out!)
- 2 Replace guideway according to INA assembly instructions
- 3 Removing the guide carriage ☞ 94
- 4 Retract the 2nd level
- 5 Install the stop of the 2nd level

The guideways have been replaced.

Replacing guide carriage of the ball-bearing cycle

Check the guideway of the ball-bearing cycle if the ball-bearing cycles show damage.

⚠ CAUTION



Danger of being crushed by moving axes

The product is not self-locking without motors. It buckles or may turn. Extremities may be crushed. This leads to minor injuries.

Observe the following points:

- Keep extremities away from the danger area
 - Ensure that no persons are in the danger area when lifting the Z-axis
-
- Size 3:
Check tightening torques of the screws. Have the replacement lids ready before removing the lids.
 - Sizes 4-5:
Check the seating of the guideway on the 2nd level with a feeler gauge (gap dimension < 0.05 mm). If there is a deviation, check the tightening torque of the screws. Have the replacement lids ready before removing the lids.




Fig. 7-23

Replacing guide carriage

- | | | | |
|---|-----------|---|-------------------------------|
| A | Screw | C | Guide carriage mounting plate |
| B | 2nd level | D | Guide carriage |

Replace the guide carriages as follows:

- 1 Unscrew the guide carriage from the plate
- 2 Remove old guide carriages
- 3 Check the lubrication nipple (90° angular offset)
- 4 Insert the new guide carriage (if necessary, use a protective rail according to INA assembly instructions in the appendix)
- 5 Screw the guide carriage to the plate
- 6 Lubricate the ball-bearing cycle ➡ 📄 72

The guide carriages have been replaced.

Final tasks

Perform these final tasks as follows:

- 1 Assembling the cog belt
- 2 Install the cables and lines if necessary
- 3 Set the belt tension ➡ Chapter 7.3.9, 📄 140
- 4 Calibrate the axis using the synchronization mark
- 5 Calibrate the shaft encoder if necessary

The final tasks have been performed.

7.3.7.3 Replacing the guideway



⚠ WARNING

Falling axes

After removing the transport securing device, brakes or motors, the vertical axes fall downwards. Carriages may run off to the side. This can lead to severe or fatal injuries!

- If necessary, secure the vertical axes and the carriages before removing transport securing devices, brakes or motors

Installing locking bolts



⚠ WARNING

Falling axes

The 2nd level of the telescope axis is held only by the cog belt. After removing the belt anchorage, it drops down. This can lead to severe or fatal injuries!

- Secure the 2nd level against falling before loosening the belt anchorage.




Fig. 7-24

Installing locking bolts

- A Telescopic axis
- B Locking bolt
- C Screw

Install the locking bolt as follows:

- 1** Use telescope axis to move to one of the end positions
- 2** Push locking bolt through hole
- 3** Install the screws

The locking bolt is fitted.

Attaching the slings: Z-axis, sizes 2-5




Fig. 7-25

Attaching the slings: Z-axis, sizes 2-5

- | | | | |
|---|---------------|---|---------|
| A | Hook | C | Shackle |
| B | Lifting belts | D | Z-axis |

Product size	Shackle bolt diameter [mm]	Shackle payload [kg]
2 + 3	10	400
4 + 5	16	1000

Table 7-20

Z-axis slings: Sizes

Attach the slings as follows:

- 1 Mount the shackle and lifting belts as illustrated
- 2 Hang the lifting belts into the hooks

The slings are in place.

Preparations

Make the following preparations:

- 1 Removing fixed belt anchorage of the 2nd level
Removing the belt anchorage

The preparation steps have been performed.

Moving out the vertical axis



Güdel gearbox units with a ratio $i \leq 24$ do not prevent the Z-axis being removed when mounted. In the case of larger ratios remove the Güdel gearbox unit.

Move out the vertical axis as follows:

- 1** Switch off the system and padlock it to secure it against being switched on again
- 2** Install locking bolts
- 3** Disassemble the rotary axis if necessary
- 4** Disassemble the energy chain
- 5** Attach the slings
- 6** Remove the upper bumper unit
- 7** Remove the wipers
- 8** Vent the motor brake or remove the motor
- 9** Vent the safety brake system if necessary
- 10** Remove the vertical axis

The vertical axis has been moved out.

Setting up or laying down the telescopic axis



⚠ WARNING

Ripping of lifting belts

The sharp edges of the rack cut the lifting belts. This can lead to severe or fatal injuries!

- Always protect the lifting belts with the guard plate



⚠ WARNING

Falling axes

The 2nd level of the telescopic axis is held by the drive or the locking bolt. After removing the drive or the locking bolt, it drops down. This can lead to severe or fatal injuries!

- Mount the safety bolt



⚠ WARNING

Suspended loads

Improper handling of suspended loads can lead to severe injuries or death!

- Use appropriate lifting units
- Wear appropriate protective clothing
- Always keep sufficient distance from suspended loads
- Never enter the area below a suspended load

NOTE

Overloading the ball-bearing cycle

If the telescopic axis is supported on the 2nd level against the direction of the axis, the ball-bearing cycles will be overloaded. The ball-bearing cycles will be destroyed.

- Never support the telescopic axis on the 2nd level during set-up
- Never attach the sling to the 2nd level
- Use two lifting units to bring the telescopic axis from a horizontal to a vertical position
- Use two lifting units to bring the telescopic axis from a vertical to a horizontal position




Fig. 7-26

Setting up or laying down the telescopic axis: Sizes 3-5

A Telescope 2nd level

Set up or lay down the telescopic axis as follows:

Prerequisite: The sling is attached to the 1st level

Prerequisite: The locking bolt is fitted

- 1 Position the lifting belts as shown in the illustration
- 2 Attach the lifting belt to a second lifting unit
- 3 Set up or lay down the telescopic axis as shown in the illustration

The telescopic axis is set up or laid down.

Replace the guideway

Replace the guideway as follows:

- 1 Replace the guideway according to superordinate operating manual

The guideway has been replaced.

Installing the Z-axis

In some cases, the Z-axis is not yet mounted on delivery. Depending on the available space, the Z-axis can be inserted into the carriage from the top or the bottom.

Attaching the slings: Z-axis, sizes 2-5




Fig. 7-27

Attaching the slings: Z-axis, sizes 2-5

- | | | | |
|---|---------------|---|---------|
| A | Hook | C | Shackle |
| B | Lifting belts | D | Z-axis |

Product size	Shackle bolt diameter [mm]	Shackle payload [kg]
2 + 3	10	400
4 + 5	16	1000

Table 7-21

Z-axis slings: Sizes

Attach the slings as follows:

- 1 Mount the shackle and lifting belts as illustrated
- 2 Hang the lifting belts into the hooks

The slings are in place.

Preparations

Prepare the retraction of the Z-axis as follows:

- 1 Remove the upper or lower bumper unit of the Z-axis
- 2 Remove the wiper at the Z-carriage
- 3 Remove the rotary axis if necessary
- 4 Remove the motor if necessary
- 5 Vent the safety brake system if necessary
(Power connection according to the type place of the safety brake)

The retraction of the Z-axis has been prepared.

Inserting the Z-axis



⚠ WARNING

Suspended loads

Improper handling of suspended loads can lead to severe injuries or death!

- Use appropriate lifting units
- Wear appropriate protective clothing
- Always keep sufficient distance from suspended loads
- Never enter the area below a suspended load

Retract the Z-axis as follows:

- 1 Attach the slings to the Z-axis
- 2 Retract the Z-axis into the carriage
- 3 Install the components:
 - 3.1 Wiper
 - 3.2 Rotary axis if present
 - 3.3 Motor if present
- 4 De-energize the safety brake system if necessary
- 5 Secure the Z-axis against falling

The Z-axis has been retracted.

Assembling the bumper unit

Some bumper units cannot be shipped in a properly assembled state for assembly and packaging reasons. In such cases, the entire bumper unit is shipped unassembled. The assembly site is designated with a danger label. Find the correct assembly site on the layout.



⚠ WARNING

Incorrectly installed safety component

The bumper unit is a safety component. Incorrectly installed bumper units may lead to severe injury or death!

- Drill the pinhole into the mating part of the bumper unit if necessary
- Install all associated components
- Tighten all screws with a torque wrench to the specified tightening torques
- Check if the shearing sleeves and/or pins are fully and correctly assembled




Fig. 7-28

Danger label "Provisionally assembled bumper unit"

- A Assembly site of the bumper unit
- B Danger label "Provisionally assembled bumper unit"

The danger label "Provisionally assembled bumper unit" warns against

- Provisionally assembled or non-assembled bumper units
- Moving the axes before proper assembly of the bumper unit

Bumper unit with
limit stops




Fig. 7-29

Bumper unit with mechanical limit stops

A	"Loctite 7414, blue" threadlocker	D	Bumper block / bumper bracket
B	Screw	E	Mating part
C	Bumpers		

Install the bumper unit as follows:

- 1 Install the bumper on the bumper block / bracket
- 2 Remove the warning sticker from the installation site if necessary
- 3 Clean the contact surface of the mating part meticulously
- 4 Position the pre-assembled bumper unit on the mating part
- 5 Tighten the screws
- 6 Check the bumper unit for correct fit
- 7 Seal all screws with "Loctite 7414, blue" threadlocker

The bumper unit has now been installed.

Final tasks

Perform these final tasks as follows:

- 1 Set the tooth flank backlash as described in the "Setting the roller and tooth flank backlash" chapter of the superordinate operating manual
- 2 Install the wiper
- 3 Set the belt tension ➡ Chapter 7.3.9, 📄 140
- 4 Calibrate the axis using the synchronization mark
- 5 Calibrate the shaft encoder if necessary

The final tasks have been performed.

7.3.7.4 Replacing the energy chain**Removing the energy chain**

Remove the energy chain as follows:

- 1 Switch off the system and secure it with a padlock against being switched on again
- 2 Loosen the plug connections of cables and lines
- 3 Remove the fastening screws
- 4 Remove the complete energy chain

The energy chain is removed.

Laying the cables and lines

NOTE

Cable damage

Incorrectly laid cables and lines wear prematurely and will be destroyed. This results in operational failure.

- Only use highly flexible lines suitable for use with energy chains
- Only use lines whose minimum bending radius is smaller than the smallest radius of the energy chain
- Güdel shall only be liable for internal divisions which are found in spare parts lists in the appendix of this manual as a document. If you are laying your own cables and lines, ensure symmetrical load distribution. Have IGUS technicians check your own internal divisions of the energy chain
- Roll the cable off evenly. Never take the cables off in loops



Lay out cables without twisting for at least 24 hours before putting them into energy chains. Use the cable description to assist you. The wires of the cable are thus aligned without twisting and can have a positive influence on the service life of the cable



Observe the following points:

- Cables are separated by vertical dividers; cables are not permitted to be laid next to each other
- Cables laid over each other with different jacket materials need to be separated from each other (risk of sticking)
- The vertical dividers are not allowed to be positioned in an offset manner in the roll-off direction
- The cable must have play on all sides of the cable divider. At its minimum, it should be 10% of the cable diameter. However, it should not be less than one millimeter.




Fig. 7-30

Laying cables and lines (image source: IGUS)

- A Screwdriver
- B Energy chain
- C Opening bar
- D Vertical divider

360287971 90236171_v5.0_EN-US

Lay the cables and lines as follows:

Prerequisite: You have read and understood the IGUS assembly instructions

- 1** Open the opening bar of the energy chain
 - 1.1** Place the screwdriver on the opening bar
 - 1.2** Tilt the screwdriver backwards until the opening bar is released
 - 1.3** Repeat the procedure for the opposite side
 - 1.4** Remove the opening bar manually
- 2** Lay the cables and lines in accordance with the IGUS internal division document
- 3** Close the opening bars without force in reverse order
- 4** Check that the position of the cables and lines is correct
- 5** If there are deviations: repeat process as of step 1
- 6** Check opening bars: correctly latched and intact
- 7** If there are deviations: repeat process as of step 1
- 8** Check vertical dividers: exactly positioned vertically and not installed in an offset manner in the roll-off direction of the energy chain

The cables and lines are laid.

Relieving the cables and lines of strain

NOTE

Incorrectly implemented strain relief

Lack of strain relief or incorrectly implemented strain relief on cables and lines in energy chains leads to damage. Cables and lines will be destroyed. This results in operational failure.

- Relieve the strain on every cable and every line individually. Never bunch together several cables and lines into one strain relief. (Exception: IGUS Chainfix multi-clamps)
- For traverse paths of the energy chain that are less than 50 m: Relieve the strain on the cables and lines on both the driver and fixed side. (Exception: Lines which extend under pressure e.g. hydraulic or pneumatic lines must only be relieved of strain on the driver side)
- For traverse paths of the energy chain longer than 50 m: Relieve the strain on the cables and lines on the driver side.

NOTE

Protruding strain relief

The energy chain becomes hooked in if metal sleeves and protruding strain relief are used. The energy chain can break or become prematurely worn!

- Do not install strain relief at a higher level than the connection element
- Remove the metal sleeves on the upper side of the connection element

NOTE

Damage to the sheaths of the cables

Cable fittings which are too tight damage the sheaths of the cables.

- Do not tighten the cable fittings too firmly.

NOTE

Excessively high tightening torques

Special cables such as FOC (fiber optic cables) or similar can be destroyed by the torque of 1 Nm at ChainFix strain reliefs!

- It is essential to comply with the cable specifications
- Consult with the manufacturer of the energy chain




Fig. 7-31 Relieving the strain on cables and lines (image source: IGUS)

- A Fixed side connection element
- B Metal sleeve



Versions	Explanation	Figure
Cable fittings	Two cable fittings 4.5 mm wide on the appropriate holders	
ChainFix	Tightening torque: 1 Nm	

Table 7-22 Strain relief: Cable fitting / ChainFix version

Attach the strain relief as follows:

- 1** Position cables and lines in the correct position in accordance with the illustration
- 2** For traverse paths of the energy chain that are less than 50 m:
 - 2.1** Relieve cable strain at the driver and the fixed side.
(distance between the end of the bending movement and strain relief of 10-30 times the diameter of the cable)
 - 2.2** Ensure cable runs straight for at least 20 cm after the strain relief
- 3** For traverse paths of the energy chain longer than 50 m:
 - 3.1** Relieve cable strain at the driver.
(distance between the end of the bending movement and strain relief of 10-30 times the diameter of the cable)
 - 3.2** Ensure cable runs straight for at least 50 cm after the strain relief
- 4** Check the height of the strain relief on the fixed side
If there are deviations:
Correct the strain relief
- 5** Check the metal sleeves on the fixed side connection element
If there are deviations:
Remove the metal sleeves on the upper side of the connection element

The cables and lines are relieved of strain.

Installing the energy chain

NOTE

Connection elements installed at an angle

If the connection elements are installed at an angle, the energy chain rolls away at an angle. The energy chain grinds on the guide channel. This results in increased wear.

- Install the connection elements in parallel

NOTE

Material damage

Stepping on energy chains leads to material damage.

- Do not step on energy chains.



The orange flag denotes the driver side. The manufacturer turns the first three chain links on the driver side. This makes the energy chain slide better.




Fig. 7-32

Installing the energy chains

- | | | | |
|---|-----------------|---|----------------------------------|
| A | Nut | E | Orange flag |
| B | Fastening screw | F | Driver's side connection element |
| C | Mounting angle | G | Fixed side connection element |
| D | Energy chain | H | Guide chute |

Install the energy chain as follows:



Prerequisite: You have read and understood the IGUS assembly instructions

- 1 Install the mounting angle on the fixed side connection element using fastening screws and nuts
- 2 Place the energy chain in the guide chute
- 3 Install fixed side on the guide chute
- 4 Install the driver side using fastening screws
- 5 Remove the orange flag

The energy chain has been installed.

Final tasks

Perform the following final tasks:

- 1 Connect the cables and lines in accordance with the electrical scheme
- 2 Relieve the cables and lines from strain   III

The final tasks have been performed.

7.3.7.5 Replacing the gearbox unit

This chapter describes the steps for replacing the Güdel gearbox unit. Replace the gearbox as follows:

Attaching the slings: Motor



⚠ WARNING

Suspended loads

Improper handling of suspended loads can lead to severe injuries or death!

- Use appropriate lifting units
- Wear appropriate protective clothing
- Always keep sufficient distance from suspended loads
- Never enter the area below a suspended load




Fig. 7-33

Attaching the slings: Motor

Attach the slings as follows:

- 1 Remove fan from motor if necessary
- 2 Mount lifting screw if necessary
- 3 Attach the slings as shown in the illustration
- 4 Carefully lift the load
- 5 Check horizontal alignment of the load
- 6 If the load tilts: Repeat process from step 3

The slings are in place.

Attaching the slings: Güdel gearbox unit

Use lifting units to transport gearbox units from size 090 upwards.



⚠ WARNING

Heavy components

Components can be very heavy. Improper handling can cause severe or fatal injuries!

- Use appropriate lifting units
- Use suitable means to secure the components against tipping over
- Only remove the safety devices after the product has been completely assembled




Fig. 7-34

Attaching the slings: Güdel gearbox unit

- A Belt harness
 B Lifting screw
 C Thread hole

Size	Size of lifting screw
090	M10
120	M12
180	M16

Table 7-23

Size of lifting screw

Attach the slings as follows:

- 1** Insert lifting screws into threaded holes on desired side
(Diagonal arrangement according to illustration)
- 2** Attach the slings as shown in the illustration

The slings are in place.

Removing the motor and coupling

⚠ WARNING



Moving the axis

The work requires moving the axis. This can lead to severe or fatal injuries!

- Ensure that no persons are in the danger area while the axis is moving

⚠ WARNING



Falling axes

After removing the transport securing device, brakes or motors, the vertical axes fall downwards. Carriages may run off to the side. This can lead to severe or fatal injuries!

- If necessary, secure the vertical axes and the carriages before removing transport securing devices, brakes or motors

⚠ CAUTION



Hot parts/surfaces

Hot surfaces present a burn hazard during work on this product!

- Protect yourself by wearing heat-resistant gloves
- Allow the parts to cool down first




Fig. 7-35

Remove motor and coupling

A	Plug	D	Coupling screw
B	Drill hole	E	Motor
C	Coupling	F	Motor screw

Remove the motor and coupling as follows:

- 1 Switch off the system and secure it with a padlock against being switched on again
- 2 Remove the plug
- 3 Check whether the coupling screws can be reached through the drill holes
- 4 If there are deviations: Adjust axis until the coupling screws can be reached through the drill hole
- 5 Switch off the system and secure it with a padlock against being switched on again
- 6 Attach slings to the motor ➡ 116
- 7 Undoing the coupling screws on the gearbox unit side
- 8 Remove the motor screws
- 9 Remove motor and coupling
- 10 Undoing the coupling screws on the motor side
- 11 Remove the coupling from the motor shaft
- 12 Remove the slings

The motor and coupling have now been removed.

Removing the gearbox unit




Fig. 7-36

Removing the gearbox unit

- A Adjacent construction
- B Gearbox unit
- C Gearbox screws

Remove the gearbox unit as follows:

- 1 Attach slings to the gearbox unit ➡ 117
- 2 Remove the gearbox screws
- 3 Remove the gearbox unit
- 4 Remove the transport securing device or slings

The gearbox unit has now been removed.

Replacing the gearbox unit

Replace the gearbox unit as follows:

- 1 Replace the complete gearbox unit and coupling

The gearbox unit has been replaced.

Installing the gearbox unit

NOTE

Breakage of cast casing

Excessively high tightening torques destroy the cast casing!

- Observe the tightening torques




Fig. 7-37

Installing the gearbox unit

- A Adjacent construction
- B Gearbox unit
- C Gearbox screws

Size	030	045	060	090	120	180
Thread size	M6	M8	M10	M12	M16	M20
Tightening torque [Nm]	9	22	42	50	120	240

Table 7-24

Tightening torques for gearbox screws: Güdel gearbox unit

Install the gearbox unit as follows:

- 1 Attach slings to the gearbox unit ➡ 117
- 2 Install the gearbox unit
- 3 Install and tighten the gearbox screws
- 4 Remove the transport securing device or slings

The gearbox unit has now been installed.

Installing the motor

Information on initial assembly

The range of motors for the gearbox unit is very broad. The same applies to the dimensions of the motor shafts. A design solution was selected that allowed for the greatest variety of motor to be mounted on the gearbox unit. The increased expense for the initial assembly was consciously taken into account. It normally occurs only once during the entire service life of the gearbox unit. For maintenance tasks and repair, the motor is simply disassembled and remounted with one half of the elastomer coupling.

Prerequisites

Three conditions must be fulfilled simultaneously to allow you to install the motor on the gearbox unit:

- The gearbox flange is aligned to allow the coupling screws to be tightened through the drill holes of the gearbox flange with a torque wrench
- The input shaft with installed wedge must be positioned with the coupling attached to allow the coupling screws to be tightened through the drill holes of the gearbox flange
- In the event of angled motor flanges, the motor must be aligned to the motor flange to allow the motor screws to be fitted and tightened

Aligning the gearbox flange

You can align the gearbox flange. When correctly aligned, the motor and coupling can be installed.




Fig. 7-38

Aligning the gearbox flange

- | | | | |
|---|--------------------|---|-----------------------|
| A | Articulated socket | G | Coupling |
| B | Torque wrench | H | Screw |
| C | Gearbox | I | Motor flange |
| D | Plug | J | Gearbox flange |
| E | Drill hole | K | Fastening screw |
| F | Coupling screw | L | Adjacent construction |

Align the gearbox flange as follows:

Prerequisite: The gearbox unit has been installed on the adjacent construction

- 1** Switch off the system and secure it with a padlock against being switched on again
- 2** Remove the plug
- 3** Check whether the coupling screws can be reached through the drill hole and tightened with a torque wrench
- 4** If there are deviations:
 - 4.1** Remove the coupling
 - 4.2** Remove the fastening screws, screws and motor flange
 - 4.3** Align the gearbox flange
 - 4.4** Install and tighten the fastening screws
 - 4.5** Install the motor flange
 - 4.6** Install and tighten the screws
 - 4.7** Place the coupling on the input shaft
- 5** Install the plug

The gearbox flange has now been aligned.

Aligning the input shaft to the gearbox flange



⚠ WARNING

Moving the axis

The work requires moving the axis. This can lead to severe or fatal injuries!

- Ensure that no persons are in the danger area while the axis is moving




Fig. 7-39

Aligning the input shaft to the gearbox flange

- | | | | |
|---|-------------|---|----------------|
| A | Drill hole | E | Coupling screw |
| B | Wedge | F | Coupling |
| C | Input shaft | G | Gearbox flange |
| D | Plug | | |

Align the input shaft to the gearbox flange as follows:

Prerequisite: The gearbox unit has been installed on the adjacent construction

Prerequisite: The gearbox flange has been aligned correctly

Prerequisite: The wedge has been installed on the gearbox side

Prerequisite: The coupling has been placed correctly on the input shaft

- 1 Check whether the coupling screws can be reached through the drill holes
- 2 If there are deviations: Traverse the axis until the coupling screws can be reached through the drill holes
- 3 Switch off the system and secure it with a padlock against being switched on again

The input shaft has been aligned to the gearbox flange.

*Positioning the
coupling on the
motor shaft*

NOTE

Defective coupling

The coupling is destroyed if the coupling screws are tightened and the coupling is not installed on the shaft.

- Tighten the coupling screws only when the coupling is installed on the shaft.



The tightening torque TA and the type of coupling are engraved on the motor and gearbox sides in the coupling.




Fig. 7-40

Positioning the coupling on the motor shaft: Elastomer coupling

- | | | | |
|---|----------------------|---|----------------------|
| A | Gearbox | E | Installation surface |
| B | Motor flange | F | Coupling screw |
| C | Measuring instrument | G | Motor shaft |
| D | Coupling | H | Motor |

$$X = Z - Y$$

Fig. 7-41

X dimension calculation formula

Güdel HPG gearbox unit size	Coupling type	L dimension [mm]	L dimension tolerance [mm]	Y dimension [mm]	X dimension tolerance [mm]
030	GWE 5103-19-SP	50	$L^{+1}_{+0.5}$	8.5	$X^{+0.5}_{-1}$
	GWE 5103-14-SP	32	$L^{+1}_{+0.5}$	15.5	$X^{+0.5}_0$

Güdel HPG gearbox unit size	Coupling type	L dimension [mm]	L dimension tolerance [mm]	Y dimension [mm]	X dimension tolerance [mm]
045	GWE 5103-24-SP	54	$L^{+1}_{+0.5}$	11	$X^{+0.5}_0$
	GWE 5103-19-SP	50	$L^{+1}_{+0.5}$	10	$X^{+0.5}_0$
060	GWE 5103-28-SP	62	$L^{+1}_{+0.5}$	16.5	X^{+1}_{-3}
	GWE 5103-24-SP	54	$L^{+1}_{+0.5}$	18.5	X^{+1}_{-2}
090	GWE 5103-38-SP	76	$L^{+1.2}_{+0.5}$	25	X^{+1}_{-2}
	GWE 5103-28-SP	62	$L^{+1}_{+0.5}$	29	X^{+1}_{-2}
120	GWE 5103-42-SP	102	$L^{+1.2}_{+0.5}$	24	X^{+1}_{-3}
	GWE 5103-38-SP	76	$L^{+1.2}_{+0.5}$	36	X^{+1}_{-1}

Table 7-26 Weight and tolerances for the elastomer coupling




Fig. 7-42 Position the coupling on the motor shaft: Make use of X dimension tolerance

Cleaning agents

mild universal cleaner free from aromatic compounds (e.g. Motorex OPAL 5000)

Table 7-26 Cleaning agents: Gearbox unit Güdel: Coupling and motor shaft

Tool	Use	Item number
Corrosion protection agent MOTOREX In-tact XD 20	Installing the coupling Applying corrosion protection to the product	0502037

Table 7-27 Special tools, testing and measuring instruments

Position the coupling on the motor shaft as follows:

Prerequisite: The transport securing device in effect at the gearbox is disassembled

- 1 Clean the coupling and motor shaft to ensure that they are free of grease
- 2 If desired by the customer, mount the wedge on the motor shaft (wedge on motor shaft not essentially necessary)
- 3 Apply corrosion protection agent to the motor shaft with a brush
- 4 Measure the distance Z
- 5 Push the coupling onto the motor shaft (set L dimension according to table)
- 6 Position the coupling on the motor shaft:
 - 6.1 Calculate dimension X and position coupling according to the calculated dimension
 - 6.2 Coupling rest a little on the motor shaft: Make use of X dimension tolerance
- 7 Tighten the coupling screws:
 - 7.1 Tighten alternately to 50% of the tightening torque TA
 - 7.2 Tighten alternately with 100% of the tightening torque TA

The coupling is positioned.

Installing the motor and coupling



⚠ WARNING

Heavy components

Components can be very heavy. Improper handling can cause severe or fatal injuries!

- Use appropriate lifting units
- Use suitable means to secure the components against tipping over
- Only remove the safety devices after the product has been completely assembled



Vent the motor brake according to the specifications of the motor manufacturer



The tightening torque TA and the type of coupling are engraved on the motor and gearbox sides in the coupling.




Fig. 7-43

Installing the motor and coupling

- | | | | |
|---|----------------|---|-------------|
| A | Coupling screw | E | Motor |
| B | Drill hole | F | Coupling |
| C | Plug | G | Motor screw |
| D | Motor flange | | |

Cleaning agents

mild universal cleaner free from aromatic compounds (e.g. Motorex OPAL 5000)

Table 7-28

Cleaning agents: Gearbox unit Güdel: coupling, input shaft and wedge

Tool	Use	Item number
Corrosion protection agent MOTOREX In-tact XD 20	Installing the coupling Applying corrosion protection to the product	0502037

Table 7-29 Special tools, testing and measuring instruments

Install the motor and coupling as follows:

Prerequisite: The gearbox unit has been installed on the adjacent construction

Prerequisite: The gearbox flange has been aligned correctly

Prerequisite: The input shaft has been aligned correctly to the gearbox flange

Prerequisite: The coupling has been positioned correctly on the motor shaft

- 1** Switch off the system and secure it with a padlock against being switched on again
- 2** Attach slings to the motor if necessary I 16
- 3** Clean the coupling, input shaft and wedge to remove any grease
- 4** Install the wedge on the input shaft
- 5** Apply corrosion protection agent to the wedge and input shaft with a brush
- 6** Push the motor with installed coupling onto the gearbox unit
- 7** Install and tighten the motor screws
- 8** If the motor screws cannot be fitted:
 - 8.1** Vent the motor brake if necessary
 - 8.2** Turn the motor into the correct installation position
 - 8.3** Repeat the procedure from step 7
- 9** Tighten the coupling screws:
 - 9.1** Tighten alternately to 50% of the tightening torque TA
 - 9.2** Tighten alternately with 100% of the tightening torque TA
- 10** Install the plug

The motor and the coupling have been installed.

Final tasks

Perform the following final tasks:

- 1 Set the tooth flank backlash ➡ 📄 I 44
- 2 Calibrate the reference plane of the motor (procedure is described in the documentation for the complete system or the motor)

The final tasks have been performed.

7.3.7.6 Final tasks

Perform these final tasks as follows:

- 1 Calibrate the axis using the synchronization mark
- 2 Calibrate the shaft encoder if necessary

The final tasks have been performed.

7.3.8 Maintenance tasks after 31,500 hours

7.3.8.1 Replacing bearing of the guide pulley

WARNING



Falling axes

After removing the transport securing device, brakes or motors, the vertical axes fall downwards. Carriages may run off to the side. This can lead to severe or fatal injuries!

- If necessary, secure the vertical axes and the carriages before removing transport securing devices, brakes or motors



Replace the components together.

Advantages:

- You avoid repeated repairs
- You avoid unnecessary downtimes

Installing locking bolts



⚠ WARNING

Falling axes

The 2nd level of the telescope axis is held only by the cog belt. After removing the belt anchorage, it drops down. This can lead to severe or fatal injuries!

- Secure the 2nd level against falling before loosening the belt anchorage.




Fig. 7-44

Installing locking bolts

- A Telescopic axis
- B Locking bolt
- C Screw

Install the locking bolt as follows:

- 1 Use telescope axis to move to one of the end positions
- 2 Push locking bolt through hole
- 3 Install the screws

The locking bolt is fitted.

Attaching the slings: Z-axis, sizes 2-5




Fig. 7-45 Attaching the slings: Z-axis, sizes 2-5

- | | | | |
|---|---------------|---|---------|
| A | Hook | C | Shackle |
| B | Lifting belts | D | Z-axis |

Product size	Shackle bolt diameter [mm]	Shackle payload [kg]
2 + 3	10	400
4 + 5	16	1000

Table 7-30 Z-axis slings: Sizes

Attach the slings as follows:

- 1 Mount the shackle and lifting belts as illustrated
- 2 Hang the lifting belts into the hooks

The slings are in place.

Preparations

Make the following preparations:

- 1 Removing fixed belt anchorage of the 2nd level
Removing the belt anchorage

The preparation steps have been performed.

Replacing bearing of the guide pulley




Fig. 7-46

Replacing bearing of the guide pulley

A	Thrust washer	F	Headless set screw
B	Shaft	G	Identification disc
C	Bearing	H	Lubrication nipple
D	Pin	I	Guide pulley
E	Holder	J	Screw

Replace the bearings as follows:

Prerequisite: The cog belt is removed

- 1 Remove screws and holder
- 2 Remove the pins
- 3 Remove the headless set screws
- 4 Remove shaft
- 5 Remove guide pulley from holder
- 6 Remove thrust washer
- 7 Replace bearings
- 8 To install the components, reverse the disassembly steps
- 9 Assembling the cog belt
- 10 Setting the belt tension ➡ 📄 140

The bearings have been replaced.

Final tasks

Perform these final tasks as follows:

- 1 Set the tooth flank backlash as described in the "Setting the roller and tooth flank backlash" chapter of the superordinate operating manual
- 2 Install the wiper
- 3 Set the belt tension ➡ Chapter 7.3.9, 📄 140
- 4 Calibrate the axis using the synchronization mark
- 5 Calibrate the shaft encoder if necessary

The final tasks have been performed.

7.3.9 Set the belt tension



⚠ WARNING

Moving the axis

The work requires moving the axis. This can lead to severe or fatal injuries!

- Ensure that no persons are in the danger area while the axis is moving

NOTE

Incorrect belt tension

Incorrectly tensioned belts can cause damage to the drive.

- Check the pre-tension of the belt before operating the product. The frequency has to match the frequency on the layout or the drawings.
- Correctly tension belts that are tensioned incorrectly




Fig. 7-47

Setting the belt tension

- A Belt tension measuring instrument
- B Straining screw

$$f_1 = \sqrt{\frac{F_v}{4 \times m \times l_{T1}^2}}$$

Fig. 7-48 Formula: Setting the belt tension: Left belt

$$f_2 = \sqrt{\frac{F_v}{4 \times m \times l_{T2}^2}}$$

Fig. 7-49 Formula: Setting the belt tension: Right belt

$$f_1 = f_2 \times q$$

Fig. 7-50 Formula: Setting the belt tension: Ratio of the frequencies

Size	3	4	5
Belt type	PCC 8MGT	PCC 8MGT	PCC 8MGT
Belt width [mm]	21	21	50
Belt mass m [kg/m]	0.1	0.1	0.23
Ratio factor q [-]	0.84	0.88	0.77
Pre-tension force Fv [N]	Own weight of the 2nd level + gripper + workpiece		

Table 7-31 Cog belt values

Tension the cog belts as follows:

Prerequisite: The locking bolt has been removed

- 1** Move the telescope axis under load to the upper end position
- 2** Switch off the system and secure it with a padlock against being switched on again
- 3** Position the belt tension measuring instrument at a distance of 1...20 mm to the cog belt in the middle of the frequency length L_T
- 4** Strike the cog belt to set it in vibration
- 5** Interpret the measurement result according to the preceding calculation
- 6** If there are deviations:
 - 6.1** Set the belt tension using straining screw
 - 6.2** Repeat procedure starting from point 3
- 7** Check ratio of the frequencies
- 8** If there are deviations:
 - 8.1** Repeat procedure starting from point 6.1

The cog belts are tensioned.

7.3.10 Setting the tooth flank backlash

Reset the rollers and the tooth flank backlash after each replacement of the following components:

- Roller
- Guideway
- Rack
- Pinion
- Gearbox

7.3.10.1 Eccentric marking

The eccentric ring has a marking of the eccentric maximum position:

Y-axis




Fig. 7-51

Eccentric marking: Countersink separate

- A Countersink
- B Eccentric ring

Z-axis




Fig. 7-52 Eccentric marking: Drill hole

- A Drill hole
- B Eccentric ring

7.3.10.2 Blocking, unblocking the eccentric ring

The eccentric ring is blocked as follows:




Fig. 7-53 Blocking the eccentric ring: Hexagonal screw

- A Eccentric ring
- B Hexagonal screw

7.3.10.3 Eccentric





Fig. 7-54

Setting the tooth flank backlash: Eccentric

A	Fastening screw	D	Eccentric ring
B	Eccentric marking (if present)	E	Pinion
C	Rack		

Set the tooth flank backlash as follows:

- 1 Switch off the system and secure it with a padlock against being switched on again
- 2 Check the tooth flank backlash  147
- 3 If there are deviations:
 - 3.1 Unblocking the eccentric ring
 - 3.2 Slightly loosen fastening screws
 - 3.3 Backlash too large: Turn the eccentric ring away from the rack
 - 3.4 Backlash too small: Turn the eccentric ring towards the rack
 - 3.5 Tighten the fastening screws
 - 3.6 Blocking the eccentric ring
 - 3.7 Repeat process from step 2

The tooth flank backlash has been set.

7.3.10.4 Check the tooth flank backlash

Blocking the drive pinions

Block the drive pinion to check the tooth flank backlash. Remove the block once you have completed the check. For this purpose, remove the fastening device and place the plug back onto the gearbox unit.




Fig. 7-55

Blocking the drive pinions: Güdel gearbox unit

A	Motor	D	Fastening device
B	Carriage	E	Plug
C	Gearbox unit		

Block the drive pinion as follows:

- 1 Switch off the system and padlock it to secure it against being switched on again
- 2 Remove the plug
- 3 Attach fastening device to gearbox unit

The drive pinion is blocked.

Rack quality and module

The quality and module are found in the following table:

Exact measuring method

Rack quality and module ↻ 📄 148

Rack quality	Tooth flank backlash [mm]		
	Module $m \leq 3$	Module $3 < m \leq 8$	Module $8 < m \leq 12$
Q4 h21	0.010	0.012	0.016
Q5 h22	0.016	0.019	0.025
Q6 h23	0.025	0.03	0.04
Q7 h25	0.059	0.079	0.099
Q8 h27	0.158	0.198	0.247
Q9 h27	0.158	0.198	0.247

Table 7-32 Tooth flank backlash: Güdel gearbox unit




Fig. 7-56

Checking the tooth flank backlash: Dial gauge (exact method)

A	Rack	E	Gearbox
B	Guideway	F	Drive pinion
C	Axis	G	Dial gauge
D	Carriage		

Check the tooth flank backlash as follows:

Prerequisite: The drive pinion is blocked ☞ I 147

- 1 Switch off the system and secure it with a padlock against being switched on again
- 2 Mount the dial gauge to the guideway
- 3 Mount dial gauge in the direction of travel aligned with the center of the drive pinion
- 4 Zero the dial gauge
- 5 Move the carriage or axis in the direction of travel
- 6 Read the tooth flank backlash off the dial gauge
- 7 Interpret the tooth flank backlash according to the previous table

The tooth flank backlash has been checked.

Alternative measuring method

Rack quality and module ↻ 📄 148

NOTE

Consequential damage due to alternative measuring method

The alternative measurement method described here can lead to incorrect interpretations and subsequent damage of every kind!

- Use it only when the exact method is not possible

Rack quality	Tooth flank backlash [mm]		
	Module $m \leq 3$	Module $3 < m \leq 8$	Module $8 < m \leq 12$
Q4 h21	0.010	0.012	0.016
Q5 h22	0.016	0.019	0.025
Q6 h23	0.025	0.03	0.04
Q7 h25	0.059	0.079	0.099
Q8 h27	0.158	0.198	0.247
Q9 h27	0.158	0.198	0.247

Table 7-33 Tooth flank backlash: Paper strip (alternative method)




Fig. 7-57 Checking the tooth flank backlash: Paper strip (alternative method)

- A Drive pinion
- B Paper strip
- C Rack

Check the tooth flank backlash as follows:

- 1 Switch off the system and secure it with a padlock against being switched on again
- 2 Insert paper strip of 0.08 mm thickness and width b between drive pinion and rack (e.g. DIN A4 80 gsm paper).
- 3 Move carriage or axis (Paper strip is "turned through")
- 4 Interpreting the result:
 - 4.1 Paper strip worn:
Tooth flank backlash <math><0.05\text{ mm}</math>
 - 4.2 Paper strip cut, partially disconnected pieces:
Tooth flank backlash $\sim 0.05\text{ mm}$
 - 4.3 Paper strips mildly cut, no disconnected pieces:
Tooth flank backlash $\sim 0.07\text{ mm}$
 - 4.4 Paper strip wavy:
Tooth flank backlash $\sim 0.1\text{ mm}$
 - 4.5 Paper strip undamaged:
Tooth flank backlash $>0.1\text{ mm}$
- 5 Interpret tooth flank backlash according to the previous table
The tooth flank backlash has now been checked.

7.4 Maintenance schedules

7.4.1 Maintenance schedule




Fig. 7-58 Telescopic axis maintenance schedule



Greasing



Replacing



Cleaning



Visual inspection



Lubrication at the customer



Maintain in accordance with separate instructions

7.4.2 Güdel gearbox unit maintenance schedule








Fig. 7-59 Maintenance schedule for Güdel gearbox unit

-  Grease
-  Oil

-  Replacing
-  Clean

-  Replacing lubricant
-  Visual inspection

7.5 Maintenance table

Maintenance work	Maintenance cycle [h]	Duration [min]	Target readership	Lubricants Cleaning agents	Further information
Lubricating guideways, racks and pinions	150		Maintenance technicians The manufacturer's technicians		➔ Chapter 7.3.4.1, 71
General inspection			Maintenance technicians The manufacturer's technicians		➔ Chapter 7.3.5.1, 72
Lubricating the ball-bearing cycle	2,250		The manufacturer's technicians Maintenance technicians Service technicians	Aral Arcanol LOAD 150	➔ Chapter 7.3.5.2, 72
Lubricating bearing of the guide pulley			Service technicians Maintenance technicians The manufacturer's technicians	Aral Arcanol LOAD 150	➔ Chapter 7.3.5.3, 74
Replacing the lubricating pinion	6,750		Maintenance technicians The manufacturer's technicians		➔ Chapter 7.3.6.1, 75
Replacing the energy chain		30	Maintenance technicians The manufacturer's technicians		➔ Chapter 7.3.7.4, 107
Replacing the gearbox unit		60	Service technicians The manufacturer's technicians Maintenance technicians		➔ Chapter 7.3.7.5, 116
Replacing the cog belt	22,500		Maintenance technicians The manufacturer's technicians		➔ Chapter 7.3.7.1, 76
Replacing the ball-bearing cycle			Maintenance technicians The manufacturer's technicians		➔ Chapter 7.3.7.2, 84
Replacing the guideway			The manufacturer's technicians Maintenance technicians		➔ Chapter 7.3.7.3, 96
Replacing bearing of the guide pulley	31,500		The manufacturer's technicians Service technicians Maintenance technicians		➔ Chapter 7.3.8.1, 135

This table does not purport to be exhaustive.

Table 7-34 Maintenance table

7.6 Intervention protocol: Maintenance

SERVICE MANUAL Telescopic axis size 3-5

Project / Order:
 Bill of materials:
 Serial number:
 Year of manufacture:

Company :
 Address :
 Location :
 Country :

Complete the intervention report after every intervention. You can overwrite the data each time you complete the report. Send the intervention report to Güdel electronically. Use the "Send" button. Sending only works if you have completed the operator details in the intervention report as specified in the Maintenance chapter. Save the generated XML file as a backup. Copy the empty intervention report and scan it in after completing it if you are not working electronically. Send it to service@ch.gudel.com after every intervention.

Maintenance work	Maintenance cycle [h]	Effective operating hours ¹	Name ²	Comments ³	Date
Lubricating guideways, racks and pinions	150				


Effective operating hours¹ :
 Name² :
 Comments³ :

Service hours [h] of the entire system according to service hour counter in the control panel / Service hours [h] or kilometers [km] of the corresponding axis
 First and last name of the service or maintenance technician
 Amount of contamination, anomalies, defects, replaced components

Intervention protocol: Maintenance

SERVICE MANUAL Telescopic axis size 3-5

Project / Order:
 Bill of materials:
 Serial number:
 Year of manufacture:



Complete the intervention report after every intervention. You can overwrite the data each time you complete the report. Send the intervention report to Güdel electronically. Use the "Send" button. Sending only works if you have completed the operator details in the intervention report as specified in the Maintenance chapter. Save the generated XML file as a backup. Copy the empty intervention report and scan it in after completing it if you are not working electronically. Send it to service@ch.gudel.com after every intervention.

Maintenance work	Maintenance cycle [h]	Effective operating hours ¹	Name ²	Comments ³	Date
General inspection	2,250				
Lubricating the ball-bearing cycle					
Lubricating bearing of the guide pulley					


Effective operating hours¹ :
 Name² :
 Comments³ :

Service hours [h] of the entire system according to service hour counter in the control panel / Service hours [h] or kilometers [km] of the corresponding axis
 First and last name of the service or maintenance technician
 Amount of contamination, anomalies, defects, replaced components

Intervention protocol: Maintenance

SERVICE MANUAL Telescopic axis size 3-5

Project / Order:
 Bill of materials:
 Serial number:
 Year of manufacture:



Complete the intervention report after every intervention. You can overwrite the data each time you complete the report. Send the intervention report to Güdel electronically. Use the "Send" button. Sending only works if you have completed the operator details in the intervention report as specified in the Maintenance chapter. Save the generated XML file as a backup. Copy the empty intervention report and scan it in after completing it if you are not working electronically. Send it to service@ch.gudel.com after every intervention.

Maintenance work	Maintenance cycle [h]	Effective operating hours ¹	Name ²	Comments ³	Date
Replacing the lubricating pinion	6,750				


Effective operating hours¹ :
 Name² :
 Comments³ :

Service hours [h] of the entire system according to service hour counter in the control panel / Service hours [h] or kilometers [km] of the corresponding axis
 First and last name of the service or maintenance technician
 Amount of contamination, anomalies, defects, replaced components

Intervention protocol: Maintenance

SERVICE MANUAL Telescopic axis size 3-5

Project / Order:
 Bill of materials:
 Serial number:
 Year of manufacture:



Complete the intervention report after every intervention. You can overwrite the data each time you complete the report. Send the intervention report to Güdel electronically. Use the "Send" button. Sending only works if you have completed the operator details in the intervention report as specified in the Maintenance chapter. Save the generated XML file as a backup. Copy the empty intervention report and scan it in after completing it if you are not working electronically. Send it to service@ch.gudel.com after every intervention.

Maintenance work	Maintenance cycle [h]	Effective operating hours ¹	Name ²	Comments ³	Date
Replacing the energy chain	22,500				
Replacing the gearbox unit					
Replacing the cog belt					
Replacing the ball-bearing cycle					
Replacing the guideway					


Effective operating hours¹ :
 Name² :
 Comments³ :

Service hours [h] of the entire system according to service hour counter in the control panel / Service hours [h] or kilometers [km] of the corresponding axis
 First and last name of the service or maintenance technician
 Amount of contamination, anomalies, defects, replaced components

Intervention protocol: Maintenance

SERVICE MANUAL Telescopic axis size 3-5

Project / Order:
 Bill of materials:
 Serial number:
 Year of manufacture:



Complete the intervention report after every intervention. You can overwrite the data each time you complete the report. Send the intervention report to Güdel electronically. Use the "Send" button. Sending only works if you have completed the operator details in the intervention report as specified in the Maintenance chapter. Save the generated XML file as a backup. Copy the empty intervention report and scan it in after completing it if you are not working electronically. Send it to service@ch.gudel.com after every intervention.

Maintenance work	Maintenance cycle [h]	Effective operating hours ¹	Name ²	Comments ³	Date
Replacing bearing of the guide pulley	31,500				

This table does not purport to be exhaustive.

Effective operating hours¹ :
 Name² :
 Comments³ :

Service hours [h] of the entire system according to service hour counter in the control panel / Service hours [h] or kilometers [km] of the corresponding axis
 First and last name of the service or maintenance technician
 Amount of contamination, anomalies, defects, replaced components

7.7 Feedback on the instructions


Your feedback helps us to keep improving these instructions. Thank you!

[mailto: docufeedback@ch.gudel.com](mailto:docufeedback@ch.gudel.com)

Please provide the following information with your feedback:

- Identification number of the instructions
- Product, type
- Project number, order number
- Material number / serial number
- Year of manufacture
- Location of the product (country, ambient conditions, etc.)
- Photos, comments, feedback with clear reference to the section in the instructions
- Your contact data for clarifications if necessary

You can find most of the information on the type plate or the title page of the instructions. The identification number of the instructions is given on each page, as shown here:



45035996409887627_v3.1_EN-US

Fig. 7-60

Identification number of the instructions

8 Repairs

8.1 Introduction

Work sequences

Perform the work sequences in the order described. Perform the described tasks at the specified times. This ensures a long service life for your product.

Original spare parts

Only use original spare parts. ➔ 📄 202

Options

For information on the available options, read the corresponding documentation in the appendix.

Third-party products

For information on third-party products, read the appropriate documents in the appendix.

Tightening torques

Unless otherwise indicated, adhere to the tightening torques of Güdel.
➔ Chapter 10, 📄 209

8.1.1 Safety

Only perform the tasks described in this chapter after you have read and understood the chapter "Safety". ➔ 📄 15
It concerns your personal safety!



⚠️ WARNING

Automatic startup

During work on the product, there is danger of the machine starting up automatically. This can lead to severe or fatal injuries!

Before working in the danger area:

- Secure vertical axes (if equipped) against falling.
- Switch off the superordinate main power supply. Secure it against being switched on again (main switch for the complete system)
- Before switching on the system again, make sure that no one is in the danger area

**⚠ WARNING****Falling axes, workpieces**

Falling axes or workpieces can cause physical damage, serious or fatal injuries!

- Set down any workpieces before working in the danger area
- Never enter the area below suspended axes and workpieces
- Secure suspended axes using the stipulated equipment
- Check the belts of the telescope axes for signs of breakage and tears

**⚠ WARNING****Heavy components**

Components can be very heavy. Improper handling can cause severe or fatal injuries!

- Use appropriate lifting equipment
- Use suitable means to secure the parts against tipping over or falling down
- Remove the safety devices only after the product has been completely installed

8.1.2 Personnel qualifications

Only appropriately trained and authorized technicians are allowed to work on the product.

8.2 Repairs

8.2.1 General prerequisites

Prior to performing repair and maintenance tasks, do the following:

- If vertical axes are present, secure them against falling
- Switch off the system and padlock it to secure it against being switched on again
- Make sure that all necessary spare parts and wearing parts are at hand
➔ 202

8.2.2 Replacing lubricant

8.2.2.1 Attaching the slings: Motor



⚠ WARNING

Suspended loads

Improper handling of suspended loads can lead to severe injuries or death!

- Use appropriate lifting units
- Wear appropriate protective clothing
- Always keep sufficient distance from suspended loads
- Never enter the area below a suspended load




Fig. 8-1

Attaching the slings: Motor

Attach the slings as follows:

- 1 Remove fan from motor if necessary
- 2 Mount lifting screw if necessary
- 3 Attach the slings as shown in the illustration
- 4 Carefully lift the load
- 5 Check horizontal alignment of the load
- 6 If the load tilts: Repeat process from step 3

The slings are in place.

8.2.2.2 Attaching the slings: Güdel gearbox unit

Use lifting units to transport gearbox units from size 090 upwards.

⚠ WARNING



Heavy components

Components can be very heavy. Improper handling can cause severe or fatal injuries!

- Use appropriate lifting equipment
- Use suitable means to secure the parts against tipping over or falling down
- Remove the safety devices only after the product has been completely installed




Fig. 8-2 Attaching the slings: Güdel gearbox unit

- A Belt harness
- B Lifting screw
- C Thread hole

Size	Size of lifting screw
090	M10
120	M12
180	M16

Table 8-1 Size of lifting screw

Attach the slings as follows:

- 1 Insert lifting screws into threaded holes on desired side (Diagonal arrangement according to illustration)
- 2 Attach the slings as shown in the illustration

The slings are in place.

8.2.2.3 Remove the motor

⚠ WARNING



Falling axes

After removing the transport securing device, brakes or motors, the vertical axes fall downwards. Carriages may run off to the side. This can lead to severe or fatal injuries!

- If necessary, secure the vertical axes and the carriages before removing transport securing devices, brakes or motors

⚠ CAUTION



Hot parts/surfaces

Hot surfaces present a burn hazard during work on this product!

- Protect yourself by wearing heat-resistant gloves
- Allow the parts to cool down first



If the elastomer gear rim remains stuck on the gearbox side, remove it manually. This is necessary only if you wish to replace the elastomer gear rim.




Fig. 8-3

Removing the motor: Güdel gearbox unit

A	Motor	D	Gearbox unit
B	Motor screw	E	Forcing screw
C	Elastomer gear rim		

Remove the motor as follows:

- 1 Switch off the system and secure it with a padlock against being switched on again
- 2 Secure the carriage or axis with the transport securing device or lifting equipment
- 3 Attach slings to the motor ➡ 172
- 4 Remove the motor screws
- 5 Force the motor off the gearbox unit with the forcing screws
- 6 Remove the motor, together with the elastomer gear rim, from the gearbox unit

The motor has now been removed.

8.2.2.4 Removing the gearbox unit




Fig. 8-4

Removing the gearbox unit

- A Adjacent construction
- B Gearbox unit
- C Gearbox screws

Remove the gearbox unit as follows:

- 1 Attach slings to the gearbox unit ➡ 174
- 2 Remove the gearbox screws
- 3 Remove the gearbox unit
- 4 Remove the transport securing device or slings

The gearbox unit has now been removed.

8.2.2.5 Replacing lubricant



⚠ WARNING

Hot gearbox oil

Working on the gearbox carries the risk of severe injury due to burns!

- Let the gearbox cool before commencing any work

⚠ CAUTION



Oil, greases

Oils and greases are harmful to the environment!

- The oils and greases must not get into the drinking water supply. Take appropriate measures
- Observe the country-specific safety data sheets
- Oils and greases must be disposed of as hazardous waste, even if the total quantity is small




Fig. 8-5 Replacing lubricant: Güdel gearbox unit

- A Bleed screw
- B Filler screw
- C Drain screw

Lubrication ex works	Specification	Lubrication quantity
Mobil Glygoyle 460 NSF no. I36467	CLP PG 460 in accordance with DIN 51502	AE/HPG030: 40cm ³ AE/HPG045: 100cm ³ AE/HPG060: 250cm ³ AE/HPG090: 700cm ³ AE/HPG120: 1400cm ³ AE/HPG180: as per type plate

Table 8-2 Lubricants: Gearbox unit Güdel

360287971 90236171_v5.0_EN-US

Replace the lubricant as follows:

- 1** Position the gearbox:
Drain screw at the bottom
Filler and bleed screw at the top
- 2** Position a suitable container below the drain screw
- 3** Remove the bleed, filler, and drain screws
- 4** Drain the lubricant
- 5** Rinse the gearbox with fresh lubricant
- 6** Allow the gearbox to drain
- 7** Screw in the drain screw
- 8** Fill up the gearbox through the filler screw
- 9** Screw in the bleed and filler screws

The lubricant is replaced.

8.2.2.6 Installing the gearbox unit

NOTE

Breakage of cast casing

Excessively high tightening torques destroy the cast casing!

- Observe the tightening torques




Fig. 8-6

Installing the gearbox unit

- A Adjacent construction
- B Gearbox unit
- C Gearbox screws

Size	030	045	060	090	120	180
Thread size	M6	M8	M10	M12	M16	M20
Tightening torque [Nm]	9	22	42	50	120	240

Table 8-3

Tightening torques for gearbox screws: Güdel gearbox unit

Install the gearbox unit as follows:

- 1 Attach slings to the gearbox unit ➡ 174
- 2 Install the gearbox unit
- 3 Install and tighten the gearbox screws
- 4 Remove the transport securing device or slings

The gearbox unit has now been installed.

8.2.2.7 Installing the motor




Fig. 8-7

Installing the motor: Güdel gearbox unit

- | | | | |
|---|--------------------|---|---------------|
| A | Motor | D | Gearbox unit |
| B | Motor screw | E | Forcing screw |
| C | Elastomer gear rim | | |

Lubrication ex works	Specification	Lubrication quantity
Technical Vaseline	Cannot be determined	

Table 8-4

Lubricants: Gearbox unit Güdel: elastomer gear rim of the coupling

Install the motor as follows:

- 1 Switch off the system and secure it with a padlock against being switched on again
- 2 Remove the forcing screws if necessary
- 3 Lubricate the elastomer gear rim
- 4 Attach slings to the motor ➡ 📄 172
- 5 Install the motor, together with the elastomer gear rim, on the gearbox unit
- 6 Install and tighten the motor screws

The motor has now been installed.

8.2.2.8 Final tasks

Perform the following final tasks:

- 1 Set the tooth flank backlash ➡ 📄 144
- 2 Calibrate the reference plane of the motor (procedure is described in the documentation for the complete system or the motor)

The final tasks have been performed.

8.2.3 Replacing the motor

⚠ CAUTION



Hot parts/surfaces

Hot surfaces present a burn hazard during work on this product!

- Protect yourself by wearing heat-resistant gloves
- Allow the parts to cool down first



Mark the position of the coupling on the motor shaft. The marking makes it easier for you to re-install the coupling.



The tightening torque TA and the type of coupling are engraved on the motor and gearbox sides in the coupling.




Fig. 8-8

Replacing the motor: Positioning the coupling half on the motor shaft

- | | | | |
|---|--------------------|---|-------------|
| A | Elastomer gear rim | D | Motor shaft |
| B | Coupling half | E | Motor |
| C | Coupling screw | | |

Tool	Use	Item number
Corrosion protection agent MOTOREX In-tact XD 20	Installing the coupling Applying corrosion protection to the product	0502037

Table 8-5 Special tools, testing and measuring instruments

Replace the motor as follows:

- 1 Switch off the system and padlock it to prevent it from being switched on again
- 2 Remove the cables and lines
- 3 Remove motor → Chapter 8.2.2.3, 175
- 4 Remove the elastomer gear rim if necessary
- 5 Measuring the Y distance
- 6 Release the coupling screws
- 7 Remove the coupling half
- 8 Replacing the motor
- 9 Apply corrosion protection agent to the motor shaft with a brush
- 10 Push the coupling half onto the motor shaft
- 11 Set the Y distance
- 12 Tighten the coupling screws:
 - 12.1 Tighten alternately to 50% of the tightening torque TA
 - 12.2 Tighten alternately with 100% of the tightening torque TA
- 13 Installing the motor and coupling → Chapter 8.2.2.7, 182
- 14 Connect the cables and lines in accordance with the electrical schematics
- 15 Calibrate the reference plane of the motor (this procedure is described in the documentation for the complete system or the motor)

The motor has been replaced.

8.2.4 Replacing the motor flange and gearbox flange



Mark the position of the drill holes of the gearbox flange. Install the new gearbox flange identically



Do not change the position of the input shaft



Do not change the position of the coupling on the motor shaft!




Fig. 8-9

Replacing the motor flange and gearbox flange

- | | | | |
|---|-----------------|---|--------------|
| A | Drill hole | D | Motor flange |
| B | Gearbox flange | E | Screw |
| C | Fastening screw | | |

Replace the motor flange and gearbox flange as follows:

- 1 Switch off the system and secure it with a padlock against being switched on again
- 2 Remove the motor and coupling ➡ 119
- 3 Remove the fastening screws, screws and motor flange
- 4 Remove the gearbox flange
- 5 Replacing the motor flange and gearbox flange
- 6 Install the components in the reverse order
- 7 Install the motor ➡ 48

The motor flange and gearbox flange have now been replaced.

8.2.5 Replacing pinion, bearing, and clamping set

The components are designed for continuous use. Their wear depends on the duration of operation of the product and the ambient conditions. Güdel recommends preventatively replacing components as soon as their service life has been reached. Components may fail before expiry of the service life however. Replace worn components immediately.

Distinguishing characteristics of pinion wear

- Defective teeth
- Process inaccuracies
- Discoloration due to heat present

Table 8-6 Distinguishing characteristics of wear: Pinion

Distinguishing characteristics of bearing wear

- Excessive noise audible
- Discoloration due to heat
- Uneven running due to vibrations perceptible

Table 8-7 Distinguishing characteristics of wear: Bearing

Distinguishing characteristics of clamping set wear

- Defective screws
- Process inaccuracies
- Slippage

Table 8-8 Distinguishing characteristics of wear: Clamping set



⚠ WARNING

Loose components

Vibrations can loosen connecting elements. Persons are surprised by unexpected situations and seriously injured as a result.

Observe the following points:

- Secure the connection elements by appropriate means
- Check the tightening torques regularly



The O-ring will be destroyed if you remove the centering flange. Always replace the O-ring when you have removed the centering flange.





Fig. 8-10

Replacing pinion, bearing, and clamping set: Güdel gearbox unit

- | | | | |
|---|--------------------|---|---------------|
| A | Pinion | E | O-ring |
| B | Bearing | F | Clamping set |
| C | Centering flange | G | Spacing strip |
| D | Headless set screw | | |

Replace the pinion, bearing, and clamping set as follows:

- 1** Switch off the system and padlock it to secure it against being switched on again
- 2** Remove the drive if necessary
- 3** Remove the spacing strips
- 4** Remove the headless set screws
- 5** Remove the centering flange in axis direction
- 6** Loosen the clamping set screws
- 7** Replace pinion, bearing, O-ring and clamping set
- 8** Install the pinion, bearing, O-ring and clamping set in reverse order
 - 8.1** Tightening torque of clamping set → Chapter 10.2,  213
 - 8.2** Install headless set screws according to the illustration (secure with Loctite 243)
 - 8.3** Check the tooth flank backlash

Pinion, bearing, and clamping set have been replaced.

8.2.6 Setting the gear backlash

The gear backlash is set ex works. Reset the gear backlash to ensure reliable function.

NOTE

Incorrect assembly of the casing cover

The gearbox oil runs out. The worm shaft engages incorrectly with the worm gear.

- Do not remove the casing cover
- Align both casing covers in the identical position




Fig. 8-11 Setting the gear backlash: Güdel gearbox unit

- A Worm shaft
- B Casing cover
- C Screw

Size	030	045	060	090	120	180
Tightening torque [Nm]	6	7	8	19	36	36

Table 8-9 Tightening torques of screws of casing cover

Set the gear backlash as follows:

- 1** Switch off the system and padlock it to secure it against being switched on again
- 2** Disassemble the drive
- 3** Remove all screws on both sides
- 4** Rotate both covers toward the next higher, cast-in number
- 5** Tighten four screws on each of the two sides
- 6** Checking the gear backlash: Rotate the worm shaft 360° by hand
 - 6.1** The shaft does not resist rotation: Repeat from step 3
 - 6.2** The shaft resists rotation: Remove the screws, set both gearbox covers one level lower
 - 6.3** The shaft always resists rotation: Replace gearbox unit immediately
- 7** Insert all screws on both sides and tighten crosswise
- 8** Checking the gear backlash: Rotate the worm shaft 360° by hand
The shaft resists rotation: Repeat from step 3

The gear backlash has been set.

8.2.7 Replacing the elastomer gear rim

The elastomer gear rim is designed for a service life of 3 years or 22,500 operating hours. The wear depends on the duration of operation of the product and the ambient conditions. However, components may fail before expiry of the service life. Replace worn components immediately.




Fig. 8-12

Elastomer gear rim

Distinguishing characteristics of wear

- Teeth broken out
- Teeth frayed
- Material brittle

Table 8-10

Distinguishing characteristics of wear: Elastomer gear rim

8.3 Tasks to perform after a crash



Güdel strongly recommends that the work be performed by Güdel technicians. Damage to the product can often only be found by experience. For this reason, the following tasks should not be regarded as conclusive.

Carry out the following tasks after a crash:

- I Perform a general inspection in the form of a fine check, in accordance with the Maintenance chapter

The tasks have been performed.

8.3.1 Replacing the bumper unit

The bumper unit is a safety component. Replace the entire bumper unit after a crash has occurred.

WARNING



Weakened safety component

After a crash, it is not immediately apparent whether bumper unit components have been weakened or are defective. A further crash can lead to severe or fatal injuries!

- Replace the entire bumper unit after a crash has occurred.

The bumper unit consists of the following components:

- Bumper
- Bumper block or bumper bracket
- Screws
- Shearing sleeves and/or pins

8.3.1.1 Bumper unit with shearing sleeves




Fig. 8-13

Bumper unit with shearing sleeves

A	Bumper block / bumper bracket	D	Bumper
B	Screw	E	Mating part
C	Loctite Blue Threadlocker 7414	F	Shearing sleeve

Assemble the bumper unit with shearing sleeves as follows:

- 1 Assemble the bumper on the bumper block / bumper bracket
- 2 Remove the danger label from the assembly site if necessary
- 3 Install the shearing sleeves at the assembly site
- 4 Check if the shearing sleeves have been fully and correctly installed
- 5 Assemble the pre-assembled bumper unit
- 6 Seal all screws with Loctite Blue Threadlocker 7414

The bumper unit with shearing sleeves has been assembled.

8.3.1.2 Bumper unit with pins




Fig. 8-14

Bumper unit with pins

A	Loctite Blue Threadlocker 7414	D	Bumper
B	Screw	E	Bumper block / bumper bracket
C	Pin	F	Mating part

Assemble the bumper unit with pins as follows:

- 1 Assemble the bumper on the bumper block / bumper bracket
- 2 Remove the danger label from the assembly site if necessary
- 3 Install pre-assembled bumper unit along with the mating part using pins
- 4 Tighten the screws
- 5 Check if the pins have been fully and correctly installed
- 6 Seal all screws with Loctite Blue Threadlocker 7414

The bumper unit with pins has been assembled.

8.3.1.3 Bumper unit with limit stops




Fig. 8-15

Bumper unit with mechanical limit stops

A	"Loctite 7414, blue" threadlocker	D	Bumper block / bumper bracket
B	Screw	E	Mating part
C	Bumpers		

Install the bumper unit as follows:

- 1 Install the bumper on the bumper block / bracket
- 2 Remove the warning sticker from the installation site if necessary
- 3 Clean the contact surface of the mating part meticulously
- 4 Position the pre-assembled bumper unit on the mating part
- 5 Tighten the screws
- 6 Check the bumper unit for correct fit
- 7 Seal all screws with "Loctite 7414, blue" threadlocker

The bumper unit has now been installed.


8.3.2 Referencing the axes

Reference the axes in accordance with the documentation for the complete system.

8.4 Intervention report: Repairs

SERVICE MANUAL Telescopic axis size 3-5

Project / Order:
 Bill of materials:
 Serial number:
 Year of manufacture:



Complete the intervention report after every intervention. You can overwrite the data each time you complete the report. Send the intervention report to Güdel electronically. Use the "Send" button. Sending only works if you have completed the operator details in the intervention report as specified in the Maintenance chapter. Save the generated XML file as a backup. Copy the empty intervention report and scan it in after completing it if you are not working electronically. Send it to service@ch.gudel.com after every intervention.

Work ¹	Component ²	Effective operating hours ³	Name ⁴	Comments ⁵	Date

Work¹ : Work carried out during the unplanned maintenance
 Component² : Affected component/assembly
 Effective operating hours³ : Service hours [h] of the entire system according to service hour counter in the control panel / Service hours [h] or kilometers [km] of the corresponding axis
 Name⁴ : First and last name of the service or maintenance technician
 Comments⁵ : Amount of contamination, anomalies, defects, replaced components

8.5 Other documentation

For information on the available options, read the corresponding documentation in the appendix.

8.6 Service departments

If you have questions, please contact the service departments. ➞ 📄 203

9 Spare parts supply

9.1 Service departments



Have the following information available for service inquiries:

- Product, type (as per type plate)
- Project number, order number (as per type plate)
- Serial number (as per type plate)
- Material number (as per type plate)
- Location of the system
- Contact person at the operating company
- Description of the issue
- Drawing number (if applicable)

Regular inquiries

If you have questions relating to service, please use the service form at www.gudel.com or contact the responsible service department:



For all other countries not included in the following list, please contact the service department in Switzerland.



Customer with special agreements should contact the service department specified in the contract.

Americas

Country	Relevant service department	Phone	E-mail
Brazil	Güdel Lineartec Comércio de Automação Ltda. Rua Américo Brasiliense nº 2170, cj. 506 Chácara Santo Antonio CEP 04715-005 São Paulo Brazil	+55 11 99590 8223	info@br.gudel.com
Argentina	Güdel TSC S.A. de C.V. Gustavo M. Garcia 308 Col. Buenos Aires N.L. 64800 Monterrey Mexico	+52 81 8374 2500 107	service@mx.gudel.com
Mexico			

Country	Relevant service department	Phone	E-mail
Canada	Güdel Inc. 4881 Runway Blvd. Ann Arbor, Michigan 48108 United States	+1 734 214 0000	service@us.gudel.com
United States			

Table 9-1 Service departments Americas

Asia

Country	Relevant service department	Phone	E-mail
China	Güdel International Trading Co. Ltd. Block A, 8 Floor, C2 BLDG, No. 1599 New Jin Qiao Road Pudong 201206 Shanghai China	+86 21 5055 0012	info@cn.gudel.com
China press automation	Güdel Jier Automation Ltd. A Zone 16th Floor JIER Building 21th Xinxi Road 250022 Jinan China	+86 531 81 61 6465	service@gudeljier.com
India	Güdel India Pvt. Ltd. Gat No. 458/459 Mauje Kasar Amboli Pirangut, Tal. Mulshi 412 111 Pune India	+91 20 679 10200	service@in.gudel.com
Korea	Güdel Lineartec Inc. 11-22 Songdo-dong Yeonsu-Ku Post no. 406-840 Incheon City South Korea	+82 32 858 05 41	gkr.service@gudel.co.kr
Taiwan	Güdel Lineartec Co. Ltd. No. 99, An-Chai 8th St. Hsin-Chu Industrial Park TW-Hu-Ko 30373 Hsin-Chu Taiwan	+88 635 97 8808	info@tw.gudel.com

Country	Relevant service department	Phone	E-mail
Thailand	Güdel Lineartec Co. Ltd. 19/28 Private Ville Hua Mak Road Hua Mak Bang Kapi 10240 Bangkok Thailand	+66 2 374 0709	service@th.gudel.com

Table 9-2 Service departments in Asia

Europe

Country	Relevant service department	Phone	E-mail
Denmark	Güdel AG Gaswerkstrasse 26 Industrie Nord 4900 Langenthal Switzerland	+41 62 916 91 70	service@ch.gudel.com
Finland			
Greece			
Norway			
Sweden			
Switzerland			
Turkey			
Bosnia and Herzegovina	Güdel GmbH Schöneringer Strasse 48 4073 Wilhering Austria	+43 7226 20690 0	service@at.gudel.com
Croatia			
Austria			
Romania			
Serbia			
Slovenia			
Hungary			
Slovakia	Güdel a.s. Holandská 4 63900 Brno Czech Republic	+420 602 309 593	info@cz.gudel.com
Czech Republic			

Country	Relevant service department	Phone	E-mail
Portugal	Güdel Spain Avinguda de Catalunya 49B 1º 3ª 08290 Cerdanyola del Vallés Spain	+34 644 347 058	info@es.gudel.com
Spain			
France	Güdel SAS Tour de l'Europe 213 3 Bd de l'Europe 68100 Mulhouse France	+33 1 6989 80 16	info@fr.gudel.com
Germany	Güdel Germany GmbH Industriepark 107 74706 Osterburken Germany	+49 6291 6446 792	service@de.gudel.com
Germany intralogistics	Güdel Intralogistics GmbH Gewerbegebiet Salzhub 11 83737 Irschenberg Germany	+49 8062 7075 0	service-intralogistics@de.gudel.com
Italy	Güdel S.r.l. Via per Cernusco, 7 20060 Bussero (Mi) Italy	+39 02 92 17 021	info@it.gudel.com
Belgium	Güdel Benelux Eertmansweg 30 7595 PA Weerselo The Netherlands	+31 541 66 22 50	info@nl.gudel.com
Luxembourg			
The Netherlands			
Estonia	Gudel Sp. z o.o. ul. Legionów 26/28 43-300 Bielsko-Biała Poland	+48 33 819 01 25	serwis@pl.gudel.com
Latvia			
Lithuania			
Poland			
Ukraine			

Country	Relevant service department	Phone	E-mail
Russia	Gudel Russia Yubileynaya 40 Office 1902 445057 Togliatti Russia	+7 848 273 5544	info@ru.gudel.com
Belarus			
Ireland	Güdel Lineartec (U.K.) Ltd. Unit 5 Wickmans Drive, Banner Lane Coventry CV4 9XA West Midlands United Kingdom	+44 24 7669 5444	service@uk.gudel.com
United Kingdom			

Table 9-3 Service departments in Europe

All other countries

Country	Relevant service department	Phone	E-mail
All other countries	Güdel AG Gaswerkstrasse 26 Industrie Nord 4900 Langenthal Switzerland	+41 62 916 91 70	service@ch.gudel.com

Table 9-4 Service departments for all other countries

Inquiries outside of business hours

If you have service inquiries outside of business hours, please contact the following service departments:

Europe	Güdel AG Gaswerkstrasse 26 Industrie Nord 4900 Langenthal Switzerland	+41 62 916 91 70	service@ch.gudel.com
Americas	Güdel Inc. 4881 Runway Blvd. Ann Arbor, Michigan 48108 United States	+1 734 214 0000	service@us.gudel.com

Table 9-5 Service departments outside of business hours

10 Torque tables

10.1 Tightening torques for screws

NOTE

Vibrations

Screws without screw lock can come loose.

- Secure screw connections on moving parts with Loctite medium strength 243.
 - Apply the adhesive on the nut thread, not on the screw!
-

10.1.1 Zinc plated screws

Unless otherwise specified, the following tightening torques apply for zinc-plated screws lubricated with Molykote (MoS₂) grease or secured with Loctite 243:

Thread size	Tightening torque [Nm]		
	8.8	10.9	12.9
M3	1.1	1.58	1.9
M4	2.6	3.9	4.5
M5	5.2	7.6	8.9
M6	9	13.2	15.4
M8	21.6	31.8	37.2
M10	43	63	73
M12	73	108	126
M14	117	172	201
M16	180	264	309
M20	363	517	605
M22	495	704	824
M24	625	890	1041
M27	915	1304	1526
M30	1246	1775	2077
M36	2164	3082	3607

Table 10-1 Torque table for zinc-plated screws lubricated with Molykote (MoS₂) grease

10.1.2 Black screws

Unless otherwise specified, the following tightening torques apply for black oiled and non-lubricated screws, or screws secured with Loctite 243:

Thread size	Tightening torque [Nm]		
	8.8	10.9	12.9
M4	3	4.6	5.1
M5	5.9	8.6	10
M6	10.1	14.9	17.4
M8	24.6	36.1	42.2
M10	48	71	83
M12	84	123	144
M14	133	195	229
M16	206	302	354
M20	415	592	692
M22	567	804	945
M24	714	1017	1190
M27	1050	1496	1750
M30	1420	2033	2380
M36	2482	3535	4136

Table 10-2 Torque table for black oiled and non-lubricated screws

10.1.3 Stainless steel screws

Unless otherwise specified, the following tightening torques apply for stainless steel screws lubricated with Molykote (MoS₂) grease or secured with Loctite 243:

Thread size	Tightening torque [Nm]		
	50	70	80
M3	0.37	0.8	1.1
M4	0.86	1.85	2.4
M5	1.6	3.6	4.8
M6	2.9	6.3	8.4
M8	7.1	15.2	20.3
M10	14	30	39
M12	24	51	68
M14	38	82	109
M16	58	126	168
M20	115	247	330
M22	157	337	450
M24	198	426	568
M27	292	—	—
M30	397	—	—
M36	690	—	—

Table 10-3 Torque table for stainless steel screws lubricated with Molykote (MoS₂) grease

10.2 Tightening torques for clamping sets

Normally, the tightening torque will be stamped onto the clamping set by the manufacturer. If you have conflicting values, always use the manufacturer's information.

The following tightening torques are applicable for clamping sets on Güdel gearbox units:

Gearbox unit size	Tightening torque T_A [Nm]
030	5
045 / 060	6.5
090 / 120	12
180	59

Table 10-4 Torque table for clamping sets

Properly tighten and loosen clamping sets

Properly tighten clamping sets. Do not remove any screws!




Fig. 10-1 Tightening the clamping set




Fig. 10-2 Releasing the clamping set

Illustrations

Fig. 4 -1	Design sizes 3-5	29
Fig. 4 -2	Axis names	30
Fig. 4 -3	Moving the axis	31
Fig. 4 -4	Belt monitor	32
Fig. 4 -5	Installing locking bolts	33
Fig. 5 -1	Attaching slings	36
Fig. 5 -2	Packaging symbols	36
Fig. 5 -3	Attaching the slings: Z-axis, sizes 2-5	38
Fig. 5 -4	Setting up or laying down the telescopic axis: Sizes 3-5	40
Fig. 6 -1	Attaching the slings: Z-axis, sizes 2-5	43
Fig. 6 -2	Danger label "Provisionally assembled bumper unit"	46
Fig. 6 -3	Bumper unit with mechanical limit stops	47
Fig. 6 -4	Aligning the gearbox flange	49
Fig. 6 -5	Aligning the input shaft to the gearbox flange	51
Fig. 6 -6	Positioning the coupling on the motor shaft: Elastomer coupling	53
Fig. 6 -7	X dimension calculation formula	53
Fig. 6 -8	Position the coupling on the motor shaft: Make use of X dimension tolerance	55
Fig. 6 -9	Installing the motor and coupling	57
Fig. 7 -1	Lubricating manually with grease	62
Fig. 7 -2	Lubricating manually with oil	62
Fig. 7 -3	Lubricating manually with oil	63
Fig. 7 -4	Markings at the lubrication points	63
Fig. 7 -5	Automatic lubrication system FlexxPump	64
Fig. 7 -6	Automatic lubrication system FlexxPump	64
Fig. 7 -7	Automatic lubrication system Memolub	65
Fig. 7 -8	Automatic lubrication system Memolub	65
Fig. 7 -9	SKF-Vogel automatic lubrication system	65
Fig. 7 -10	Ball-bearing cycle (image source: INA)	72
Fig. 7 -11	Lubricating bearing of the guide pulley	74
Fig. 7 -12	Replacing the lubricating pinion	75

Fig. 7 -13	Installing locking bolts	78
Fig. 7 -14	Removing the belt anchorage: 2nd level, rotating	79
Fig. 7 -15	Removing the belt anchorage: 2nd level, fixed, right	80
Fig. 7 -16	Removing the belt anchorage: 2nd level, rotating	81
Fig. 7 -17	Removing the belt anchorage: 2nd level, fixed, left	82
Fig. 7 -18	Installing locking bolts	85
Fig. 7 -19	Attaching the slings: Z-axis, sizes 2-5	86
Fig. 7 -20	Setting up or laying down the telescopic axis: Sizes 3-5	89
Fig. 7 -21	Removing limit stop	91
Fig. 7 -22	Replacing the guideway of the ball-bearing cycle: Extending the 2nd level	93
Fig. 7 -23	Replacing guide carriage	94
Fig. 7 -24	Installing locking bolts	96
Fig. 7 -25	Attaching the slings: Z-axis, sizes 2-5	98
Fig. 7 -26	Setting up or laying down the telescopic axis: Sizes 3-5	101
Fig. 7 -27	Attaching the slings: Z-axis, sizes 2-5	103
Fig. 7 -28	Danger label "Provisionally assembled bumper unit"	105
Fig. 7 -29	Bumper unit with mechanical limit stops	106
Fig. 7 -30	Laying cables and lines (image source: IGUS)	109
Fig. 7 -31	Relieving the strain on cables and lines (image source: IGUS)	112
Fig. 7 -32	Installing the energy chains	114
Fig. 7 -33	Attaching the slings: Motor	116
Fig. 7 -34	Attaching the slings: Güdel gearbox unit	117
Fig. 7 -35	Remove motor and coupling	120
Fig. 7 -36	Removing the gearbox unit	121
Fig. 7 -37	Installing the gearbox unit	122
Fig. 7 -38	Aligning the gearbox flange	124
Fig. 7 -39	Aligning the input shaft to the gearbox flange	126
Fig. 7 -40	Positioning the coupling on the motor shaft: Elastomer coupling	128
Fig. 7 -41	X dimension calculation formula	128
Fig. 7 -42	Position the coupling on the motor shaft: Make use of X dimension tolerance	130
Fig. 7 -43	Installing the motor and coupling	132

Fig. 7 -44	Installing locking bolts	136
Fig. 7 -45	Attaching the slings: Z-axis, sizes 2-5	137
Fig. 7 -46	Replacing bearing of the guide pulley	138
Fig. 7 -47	Setting the belt tension	141
Fig. 7 -48	Formula: Setting the belt tension: Left belt	142
Fig. 7 -49	Formula: Setting the belt tension: Right belt	142
Fig. 7 -50	Formula: Setting the belt tension: Ratio of the frequencies .	142
Fig. 7 -51	Eccentric marking: Countersink separate	144
Fig. 7 -52	Eccentric marking: Drill hole	145
Fig. 7 -53	Blocking the eccentric ring: Hexagonal screw	145
Fig. 7 -54	Setting the tooth flank backlash: Eccentric	146
Fig. 7 -55	Blocking the drive pinions: Güdel gearbox unit	147
Fig. 7 -56	Checking the tooth flank backlash: Dial gauge (exact method)	149
Fig. 7 -57	Checking the tooth flank backlash: Paper strip (alternative method)	151
Fig. 7 -58	Telescopic axis maintenance schedule	153
Fig. 7 -59	Maintenance schedule for Güdel gearbox unit	155
Fig. 7 -60	Identification number of the instructions	169
Fig. 8 -1	Attaching the slings: Motor	173
Fig. 8 -2	Attaching the slings: Güdel gearbox unit	174
Fig. 8 -3	Removing the motor: Güdel gearbox unit	176
Fig. 8 -4	Removing the gearbox unit	177
Fig. 8 -5	Replacing lubricant: Güdel gearbox unit	179
Fig. 8 -6	Installing the gearbox unit	181
Fig. 8 -7	Installing the motor: Güdel gearbox unit	182
Fig. 8 -8	Replacing the motor: Positioning the coupling half on the motor shaft	184
Fig. 8 -9	Replacing the motor flange and gearbox flange	187
Fig. 8 -10	Replacing pinion, bearing, and clamping set: Güdel gearbox unit	189
Fig. 8 -11	Setting the gear backlash: Güdel gearbox unit	191
Fig. 8 -12	Elastomer gear rim	193
Fig. 8 -13	Bumper unit with shearing sleeves	195
Fig. 8 -14	Bumper unit with pins	196

Fig. 8 -15	Bumper unit with mechanical limit stops	197
Fig. 10 -1	Tightening the clamping set	213
Fig. 10 -2	Releasing the clamping set	213

List of tables

Table -I	Revision history.....	3
Table I-I	Explanation of symbols/abbreviations.....	14
Table 5-1	Z-axis slings: Sizes.....	38
Table 6-1	Z-axis slings: Sizes.....	43
Table 6-2	Cleaning agents: Gearbox unit Güdel: Coupling and motor shaft.....	52
Table 6-3	Weight and tolerances for the elastomer coupling.....	53
Table 6-4	Special tools, testing and measuring instruments.....	55
Table 6-5	Cleaning agents: Gearbox unit Güdel: coupling, input shaft and wedge.....	56
Table 6-6	Special tools, testing and measuring instruments.....	58
Table 7-1	Table of cleaning agents.....	61
Table 7-2	Lubricants: Guideways, racks, and pinions.....	62
Table 7-3	Lubricants: Guideways, racks, and pinions.....	62
Table 7-4	Lubricants: Pre-lubricate guideways and racks.....	63
Table 7-5	Lubricants: Automatic lubrication system FlexxPump.....	64
Table 7-6	Lubricants: Automatic lubrication system FlexxPump: Pre-lubricate guideways and racks.....	64
Table 7-7	Lubricants: Automatic lubrication system Memolub.....	65
Table 7-8	Lubricants: Automatic lubrication system Memolub.....	65
Table 7-9	Lubricants: SKF-Vogel automatic lubrication system.....	65
Table 7-10	Lubricant table.....	66
Table 7-11	Conversion table: Operating hours at the respective duty cycle.....	68
Table 7-12	Maintenance intervals in shift operation (5 days a week).....	69
Table 7-13	Maintenance intervals in shift operation (7 days a week).....	69
Table 7-14	Special tools, testing and measuring instruments.....	70
Table 7-15	Lubricants: Ball-bearing cycle.....	72
Table 7-16	Lubricants: Bearing of the guide pulley.....	74
Table 7-17	Wear characteristics of the cog belt.....	76
Table 7-18	Distinguishing characteristics of wear: Guide unit.....	84
Table 7-19	Z-axis slings: Sizes.....	86

Table 7-20	Z-axis slings: Sizes.....	98
Table 7-21	Z-axis slings: Sizes.....	103
Table 7-22	Strain relief: Cable fitting / ChainFix version.....	112
Table 7-23	Size of lifting screw.....	117
Table 7-24	Tightening torques for gearbox screws: Güdel gearbox unit	122
Table 7-25	Cleaning agents: Gearbox unit Güdel: Coupling and motor shaft.....	127
Table 7-26	Weight and tolerances for the elastomer coupling.....	128
Table 7-27	Special tools, testing and measuring instruments.....	130
Table 7-28	Cleaning agents: Gearbox unit Güdel: coupling, input shaft and wedge.....	131
Table 7-29	Special tools, testing and measuring instruments.....	133
Table 7-30	Z-axis slings: Sizes.....	137
Table 7-31	Cog belt values.....	142
Table 7-32	Tooth flank backlash: Güdel gearbox unit.....	148
Table 7-33	Tooth flank backlash: Paper strip (alternative method)	150
Table 7-34	Maintenance table.....	157
Table 8-1	Size of lifting screw.....	174
Table 8-2	Lubricants: Gearbox unit Güdel.....	178
Table 8-3	Tightening torques for gearbox screws: Güdel gearbox unit	181
Table 8-4	Lubricants: Gearbox unit Güdel: elastomer gear rim of the coupling.....	182
Table 8-5	Special tools, testing and measuring instruments.....	185
Table 8-6	Distinguishing characteristics of wear: Pinion.....	188
Table 8-7	Distinguishing characteristics of wear: Bearing.....	188
Table 8-8	Distinguishing characteristics of wear: Clamping set	188
Table 8-9	Tightening torques of screws of casing cover.....	191
Table 8-10	Distinguishing characteristics of wear: Elastomer gear rim ...	193
Table 9-1	Service departments Americas	203
Table 9-2	Service departments in Asia.....	204
Table 9-3	Service departments in Europe	205
Table 9-4	Service departments for all other countries	207
Table 9-5	Service departments outside of business hours	207
Table 10-1	Torque table for zinc-plated screws lubricated with Molykote (MoS ₂) grease	210

Table 10-2	Torque table for black oiled and non-lubricated screws.....	211
Table 10-3	Torque table for stainless steel screws lubricated with Molykote (MoS2) grease	212
Table 10-4	Torque table for clamping sets.....	213

Index

A

Aligning	
Gearbox flange	49, 124
Input shaft	51, 126
Assembling	
Bumper unit	195
Attaching	
Slings	117, 174
Slings: Motor	116, 172
Axis	
moving	31

B

Ball-bearing cycle	
Lubricating	72
Replace the guideway	93
Bearing	
Replacing	188
Replacing guide pulley	135
Replacing: Güdel gearbox unit	121
Replacing: Guide pulley	138
Belt anchorage	
Removing: 2nd level, fixed	80, 82
Removing: 2nd level, rotating	79, 81
Belt monitor	
32	
Belt tension	
Setting	140
Blocking	
Drive pinion: Güdel gearbox unit	147
Bumper unit	
Installing	47, 106, 195, 197
Mounting	196
Replacing	194

C

- Cable
 - Relieving strain 111
- Checking
 - Tooth flank backlash 147
 - Tooth flank backlash: Alternative measuring method 150
- Clamping set
 - Replacing 188
 - Replacing: Güdel gearbox unit 121
- Cleaning agents 61
- Collision
 - Behavior afterward 194
 - Further procedure 194
- Coupling
 - Installing 56, 131
 - Mounting 52, 127
 - Removing 119
 - Replacing 119
 - Replacing: Güdel gearbox unit 121
- Crash
 - Behavior afterward 194
- Customer feedback 169

D

- Design
 - Sizes 3-5 29
- Disassembling
 - Limit stop 91
- Drive pinion
 - Blocking: Güdel gearbox unit 147
- Duty cycle 68

E

- Eccentric
 - Setting the tooth flank backlash .. 146
- Elastomer gear rim
 - Replacing 193
- Energy chain
 - Inserting 108
 - Installing 114
 - Removing 107
 - Replacing 107
- Explanation of abbreviations 14
- Explanation of symbols 14
- extend
 - Vertical axis 87, 99

F

- Feedback 169
- Feedback on the instructions 169
- Final tasks 83, 115, 134, 183

G

Gear backlash	
Setting: Güdel gearbox unit ..	191
Gearbox	
Replacing: Güdel gearbox unit ...	116, 121
Gearbox flange	
Aligning	49, 124
Replacing	186
General inspection	72
Güdel gearbox unit	
Installing	122, 181
Removing	121, 177
Setting the gear backlash	191
Guide pulley	
Lubricate bearings	74
Replace bearings	135
Guideway	
Lubricating	71
Replacing	96
Guideway of the ball-bearing cycle	
Replacing	93

H

Hazard warnings	21
-----------------------	----

I

Identification of lubrication points ...	63
Initial assembly	48, 123
Input shaft	
Aligning	51, 126
Inserting	
Energy chain	108
Installation instructions	20
Installing	
Bumper unit	47, 106, 197
Coupling	56, 131
Energy chain	114
Güdel gearbox unit	122, 181
Locking bolt ..	33, 78, 85, 96, 136
Motor	48, 56, 123, 131, 182
Intended purpose	27

L

Laying down	
Telescopic axis	39, 88, 100
Liability	20
Limit stop	
Disassembling	91
Lines	
Relieving strain	111
Locking bolt	
Installing	33, 78, 85, 96, 136
Removing	92
Lubricants	61
Replacing	178
Replacing: Güdel gearbox unit	172
Lubricating	
Ball-bearing cycle	72
Guide pulley: Bearing	74
Lubricating pinion	
Replacing	75
Lubrication	
Guideway	71
Pinion	71
Rack	71
Lubrication cycle	62

M

Maintenance tasks	
After 150 hours	71
After 2,250 hours	72
After 22,500 hours	76
After 31,500 hours	135
After 6,750 hours	75
Measurement method	
Alternative: Check the tooth	
flank backlash	150
Measuring instruments	70
Module	148
Monitoring equipment	23
Motor	
Attaching slings	116, 172
Installing	48, 56, 123, 131, 182
Mounting	52, 127
Removing	119, 175
Replacing	184
Motor flange	
Replacing	186
Mounting	
Bumper unit	196
Coupling	52, 127
Motor	52, 127
Moving the axis	31
MSDS	25
○	
Occupational safety	20
Oil	
Replacing	172
Operation	15
Original spare part	59, 170
O-ring	
Replacing	188

P

Pinion	
Lubricating	71
Replacing	188
positioning	
Axis	31
Preparing	
Z-axis	44, 104
Protective equipment	23
Protective measures	20
Purpose of the document	13

R

Rack	
Lubricating	71
Rack quality	148
Removing	
Belt anchorage: 2nd level, fixed ...	80, 82
Belt anchorage: 2nd level, rotat-	79, 81
Coupling	119
Energy chain	107
Güdel gearbox unit	121, 177
Locking bolt	92
Motor	119, 175
Replacing	
Ball-bearing cycle	84
Bearing	188
Bearing guide pulley	135
Bumper unit	194
Clamping set	188
Clamping set: Güdel gearbox	121
unit	121
Cog belt	76
Coupling	119
Coupling: Güdel gearbox unit	121
Elastomer gear rim	193
Energy chain	107
Gearbox flange	186
Güdel gearbox unit	116, 121
Guide carriage of the ball-bearing	94
cycle size 2-5	94
Guide pulley: Bearing	138
Guideway	96
Guideway of the ball-bearing cy-	93
cle	93
Lubricants	172, 178
Lubricating pinion	75
Motor	184
Motor flange	186
O-ring	188
Pinion	188
Storage: Güdel gearbox unit	121

Replacing guide carriage of the ball-bearing cycle size 2-5	94
Replacing the ball-bearing cycle ..	84
Replacing the cog belt	76
Residual danger	15
Retraction	
Z-axis	45, 104
S	
Safety data sheet	25
Service departments	203
Setting	
Belt tension	140
Gear backlash: Güdel gearbox unit	191
Tooth flank backlash	144
Tooth flank backlash: Eccentric ..	146
Setting up	
Telescopic axis	39, 88, 100
Slings	
Attaching: Güdel gearbox unit	117, 174
Attaching: Motor	116, 172
Attaching: Z-axis, sizes 2-5	38, 43, 86, 98, 103, 137
Spare part	59, 170
Special tools	70
State of the art	15
Strain relief	
Attaching	111
Symbol	22
T	
Telescopic axis	
Laying down	39, 88, 100
Setting up	39, 88, 100
Testing instruments	70
Third-party product	59, 170
Tightening torque	59, 170
Tightening torques	
Clamping sets	213
Screws	210
Tooth flank backlash	
Checking	147
Checking: Alternative measuring method	150
Setting	144
Setting: Eccentric	146
Setting: Exact method	148
Torques	209
Transport	35
Tribocorrosion	62
V	
Vertical axis	
extend	87, 99
W	
Warning symbols	22
Warranty	20
Z	
Z-axis	
Preparing	44, 104
Retracting	45, 104

Version	5.0
Author	chrgal
Date	08.07.2019
GÜDEL AG	
Industrie Nord	
CH-4900 Langenthal	
Switzerland	
Phone	+41 62 916 91 91
Fax	+41 62 916 91 50
E-mail	info@ch.gudel.com
www.gudel.com	

GÜDEL

GÜDEL AG

Industrie Nord

CH-4900 Langenthal

Switzerland

Phone +41 62 916 91 91

info@ch.gudel.com

www.gudel.com