


## ASSEMBLY INSTRUCTIONS

### Conversion kit FlexxPump 40lmod / 40lB



Project / Order:

Bill of materials:

Serial number:

Year of manufacture:

© GÜDEL

Translation of the original instructions

This manual contains standard illustrations that may deviate from the original. In the case of special models, options, or technical changes, the scope of delivery may differ from the descriptions here. Reprinting the instructions, in whole or in part, requires our permission. Subject to change due to technical improvements.

## Revision history

Version	Date	Description
1.0	08.03.2019	Basic version

Table - I      Revision history



## Table of contents

<b>1</b>	<b>EC declaration of conformity</b>	<b>11</b>
<b>2</b>	<b>General</b>	<b>13</b>
2.1	<b>Further applicable documentation</b> .....	<b>13</b>
2.2	<b>Purpose of the document</b> .....	<b>13</b>
2.3	<b>Explanation of symbols/abbreviations</b> .....	<b>13</b>
<b>3</b>	<b>Safety</b>	<b>15</b>
3.1	<b>General</b> .....	<b>15</b>
3.1.1	Product safety .....	15
3.1.2	Personnel qualifications .....	15
3.1.2.1	Operating companies .....	16
3.1.2.2	Transport specialists .....	16
3.1.2.3	Fitters .....	16
3.1.2.4	Commissioning technicians .....	17
3.1.2.5	Operators .....	17
3.1.2.6	Manufacturer's technicians .....	17
3.1.2.7	Maintenance technicians .....	18
3.1.2.8	Service technicians .....	18
3.1.2.9	Disposal specialists .....	18
3.1.3	Disregarding safety regulations .....	19
3.1.4	Installation instructions .....	19
3.2	<b>Hazard symbols in the manual</b> .....	<b>20</b>
3.2.1	Hazard warnings .....	20
3.2.2	Explanation of warning symbol .....	21
3.3	<b>Fundamentals of safety</b> .....	<b>22</b>
3.3.1	Separating protective equipment, monitoring equipment .....	22
3.3.2	Product-specific hazards .....	22

3.3.3	Material safety data sheets (MSDS)	23
<b>4</b>	<b>Product description</b>	<b>25</b>
<b>4.1</b>	<b>Use</b>	<b>25</b>
4.1.1	Intended use	25
4.1.2	Non-intended use	25
<b>4.2</b>	<b>Product designation</b>	<b>26</b>
<b>4.3</b>	<b>Technical data</b>	<b>28</b>
4.3.1	Dimensions and connections 40I mod	29
4.3.2	Dimensions and connections 40IB	30
4.3.3	Temperature ranges	31
4.3.4	IP protection class	31
4.3.5	Operating pressure	31
4.3.6	Lubricant amount	31
4.3.7	Shelf life of Güdel HI lubricant	31
<b>5</b>	<b>Design, function</b>	<b>33</b>
<b>5.1</b>	<b>Design</b>	<b>33</b>
5.1.1	Structure of the 40I mod	33
5.1.2	Detailed design of FlexxPump 40I mod	34
5.1.3	Structure of the 40IB	35
5.1.4	Detailed design of FlexxPump 40IB	36
<b>5.2</b>	<b>Function</b>	<b>37</b>
5.2.1	Functional description	37
5.2.2	40I mod	37
5.2.3	40IB	37
5.2.4	Display elements	38
5.2.5	40IB	39
5.2.5.1	Control elements	39

<b>6</b>	<b>Commissioning</b>	<b>41</b>
6.1	<b>Introduction</b> .....	41
6.1.1	Safety .....	41
6.1.2	Personnel qualifications .....	41
6.2	<b>Transport</b> .....	41
6.3	<b>Packaging symbols</b> .....	41
6.4	<b>Repairing damaged packaging</b> .....	42
6.5	<b>Intermediate storage</b> .....	42
6.6	<b>Conversion</b> .....	43
6.6.1	Prerequisites .....	43
6.6.2	Special tools, testing and measuring instruments .....	44
6.6.3	Disassembling the Memolub .....	45
6.6.4	Mounting attachments .....	47
6.6.5	40I mod .....	49
6.6.5.1	Preparing material .....	49
6.6.5.2	Installing the FlexxPump .....	50
	Prepare the FlexxPump .....	50
	Install the FlexxPump .....	52
6.6.5.3	Connecting electrical equipment .....	54
	Normal cable .....	54
	Y-cable .....	55
6.6.5.4	Adapting PLC .....	57
6.6.6	40IB .....	59
6.6.6.1	Preparing material .....	59
6.6.6.2	Preparing material .....	59
6.6.6.3	Installing the FlexxPump .....	60
	Insert battery .....	60
	Prepare the FlexxPump .....	62
	Install the FlexxPump .....	64
6.6.6.4	Connecting electrical equipment .....	66
6.6.7	Disposing of the Memolub .....	67

<b>6.7</b>	<b>Lubrication recommendation</b> .....	<b>68</b>
6.7.1	General information .....	68
6.7.2	Basics .....	69
6.7.3	Calculation formulas .....	70
<b>6.8</b>	<b>Initial commissioning</b> .....	<b>71</b>
6.8.1	40I mod .....	71
6.8.1.1	Switching on the FlexxPump 40I mod .....	71
6.8.2	40IB .....	72
6.8.2.1	Switching on the FlexxPump 40IB .....	72
	Lubrication cycle .....	73
	Special dispensing .....	73
<b>7</b>	<b>Operation</b> .....	<b>75</b>
7.1	<b>General</b> .....	<b>75</b>
7.2	<b>Personnel</b> .....	<b>75</b>
<b>8</b>	<b>Maintenance</b> .....	<b>77</b>
8.1	<b>Introduction</b> .....	<b>77</b>
8.1.1	Safety .....	77
8.1.2	Personnel qualifications .....	78
8.2	<b>Consumables and auxiliary agents</b> .....	<b>79</b>
8.2.1	Cleaning agents .....	79
8.2.1.1	Table of cleaning agents .....	79
8.2.2	Lubricants .....	79
8.2.2.1	Lubrication .....	80
	Automatic lubrication system .....	80
8.2.2.2	Lubricant table .....	80
8.3	<b>Maintenance tasks</b> .....	<b>81</b>
8.3.1	Checking automatic lubrication system .....	81
8.3.2	Replacing the cartridge .....	82
8.3.3	Replacing the battery 40IB .....	84
8.4	<b>Maintenance table</b> .....	<b>87</b>



<b>8.5</b>	<b>Intervention report: Maintenance</b> .....	<b>89</b>
<b>8.6</b>	<b>Feedback on the instructions</b> .....	<b>93</b>
<b>9</b>	<b>Repairs</b> .....	<b>94</b>
<b>9.1</b>	<b>Introduction</b> .....	<b>94</b>
9.1.1	Safety .....	94
<b>9.2</b>	<b>Repairs</b> .....	<b>94</b>
<b>9.3</b>	<b>Malfunctions / Troubleshooting</b> .....	<b>95</b>
9.3.1	40IB .....	96
9.3.1.1	Empty EI .....	96
9.3.1.2	Overcurrent E2 .....	96
9.3.1.3	Operating voltage too low E3 .....	97
9.3.1.4	System malfunction .....	97
9.3.1.5	Functional check .....	98
9.3.2	40I mod .....	98
9.3.2.1	System malfunction .....	98
<b>9.4</b>	<b>Intervention report: Repairs</b> .....	<b>99</b>
<b>9.5</b>	<b>Service departments</b> .....	<b>101</b>
<b>10</b>	<b>Decommissioning, storage</b> .....	<b>102</b>
<b>10.1</b>	<b>Introduction</b> .....	<b>102</b>
10.1.1	Personnel qualifications .....	102
<b>10.2</b>	<b>Storage conditions</b> .....	<b>102</b>
<b>10.3</b>	<b>Decommissioning</b> .....	<b>104</b>
10.3.1	Shutdown .....	104
10.3.2	Cleaning, rust-proofing .....	104
10.3.3	Transport securing devices .....	104
10.3.4	Identification .....	105

<b>11</b>	<b>Disposal</b>	<b>107</b>
11.1	<b>Introduction</b> .....	<b>107</b>
11.1.1	Safety .....	107
11.1.2	Personnel qualifications .....	107
11.2	<b>Disposal</b> .....	<b>108</b>
11.3	<b>Waste management compliant assemblies</b> .....	<b>109</b>
11.3.1	Disassembly .....	109
11.3.2	Material groups .....	110
11.4	<b>Disposal facilities, authorities</b> .....	<b>110</b>
<b>12</b>	<b>Spare parts supply</b>	<b>111</b>
12.1	<b>Service departments</b> .....	<b>113</b>
12.2	<b>Explanations regarding the spare parts list</b> .....	<b>119</b>
12.2.1	Parts list .....	119
12.2.2	Position drawings .....	119
	<b>List of illustrations</b>	<b>120</b>
	<b>List of tables</b>	<b>121</b>
	<b>Index</b>	<b>123</b>
	<b>Appendix</b>	
	<b>Layout</b>	
	<b>Spare parts lists</b>	

# I EC declaration of conformity

The manufacturer: GÜDEL AG  
Industrie Nord  
CH-4900 Langenthal

hereby declares that the machine:

Product, type  
Serial number  
Parts list  
Year of manufacture

corresponds to the applicable requirements of the Machinery Directive (2006/42/EC).

Authorized representative responsible for compiling the technical documentation:

Alain Knuchel Tel. +41 (0)62 916 92 31

Langenthal,



Markus Ruprecht  
CEO



Alain Knuchel  
General Manager  
Robotics



## 2 General

Read the entire manual before working with the product. The manual contains important information for your personal safety. The manual must be read and understood by all persons who work on the product in any of the product life phases.

### 2.1 Further applicable documentation

All documents delivered with this manual are further applicable documentation. They must be observed in addition to this operating manual for the safe handling of the product.

### 2.2 Purpose of the document

These assembly instructions describe the conversion of the product.

The instructions contain the information required for converting the product as intended.

### 2.3 Explanation of symbols/abbreviations

The following symbols and abbreviations are used in this manual:




Symbol/Abbreviation	Use	Explanation
	For cross-reference	See
	Possibly for cross-reference	Page
Fig.	Designation of graphics	Figure
Table	Designation of tables	Table
	In the tip	Information or tip

Table 2-1 Explanation of symbols/abbreviations



## 3 Safety

### 3.1 General

Read the entire manual before working with the product. The manual contains important information for your personal safety. The manual must be read and understood by all persons who work on the product in any of the product life phases.

#### 3.1.1 Product safety

*Residual danger*

The product is built using state-of-the-art technology. It was designed and constructed in accordance with the accepted safety regulations. However, some residual danger remains during its operation.

There is danger to the personal safety of the operator as well as for the product and other property.

*Operation*

When operating the product, always observe this manual and ensure that the system is always in perfect working order.

#### 3.1.2 Personnel qualifications



#### **⚠ WARNING**

##### **Lack of safety training**

Incorrect behavior of untrained or insufficiently trained technicians can result in severe or fatal injuries!

Before technicians work on safety-related aspects of the product:

- Ensure that the technicians are trained with regard to safety
- Train and instruct the technicians specifically for their area of responsibility

Only appropriately trained and authorized technicians are allowed to work on the product.

Persons are authorized if:

- they are familiar with the relevant safety regulations for their area of responsibility
- they have read and understood this manual
- they meet the requirements for an area of responsibility
- they were assigned an area of responsibility by the operator

The technician is responsible to third parties in his area of responsibility.

During a training session or instruction, the technician may only work on the product under the supervision of an experienced manufacturer's technician.

### 3.1.2.1 **Operating companies**

The operating company is responsible for ensuring that:

- the product is used as intended
- the product is sufficiently lubricated at all times
- all safety aspects are complied with
- the product is put out of operation if the functioning of the safety equipment is not fully guaranteed
- the technician working on the product is appropriately trained
- the technician is provided with personal protective equipment
- the operating manual is available to the technician at the operation site of the product at all times
- the technicians are kept up-to-date regarding best practice
- the technicians are informed about technical progress, modifications, and the like.
- the contracted cleaning staff only work under the supervision of a maintenance technician

### 3.1.2.2 **Transport specialists**

The transport specialist:

- is able to transport loads safely
- is able to use slings safely and properly
- is able to secure the load properly
- has experience in transportation

### 3.1.2.3 **Fitters**

The fitter:

- has very good mechanical and/or electrical knowledge
- is flexible
- has assembly experience



### **3.1.2.4 Commissioning technicians**

The commissioning technician:

- has good programming knowledge
- has mechanical and/or electrical knowledge
- is flexible

The commissioning technician is responsible for the following tasks:

- commissioning the product
- testing the functions of the product

### **3.1.2.5 Operators**

The operator:

- was trained and instructed by the operating company or the manufacturer
- has very good knowledge of the user interface and the operating elements
- has process knowledge which is specifically geared to the product

The operator is responsible for the following tasks:

- switching the control system of the product on and off
- creating production readiness
- monitoring the production process
- localizing minor malfunctions

### **3.1.2.6 Manufacturer's technicians**

The manufacturer's technician:

- is employed on site at the premises of the manufacturer or representative
- has very good mechanical and/or electrical knowledge
- has good software knowledge
- has maintenance, service and repair experience
- has experience with Güdel products

The manufacturer's technician is responsible for the following tasks:

- performing mechanical and electrical maintenance work in accordance with the manual
- performing mechanical and electrical service work in accordance with the manual
- cleaning the product
- replacing spare parts
- localizing and fixing malfunctions

### 3.1.2.7 Maintenance technicians

The maintenance technician:

- was trained by the operating company or the manufacturer
- has very good mechanical and/or electrical knowledge
- has software knowledge
- has maintenance experience
- bears responsibility for the safety of the cleaning staff

The maintenance technician is responsible for the following tasks:

- performing mechanical and electrical maintenance work in accordance with the manual
- cleaning the product
- replacing spare parts
- monitoring and instructing the cleaning staff in the safety zone during the cleaning process

### 3.1.2.8 Service technicians

The service technician:

- was trained by the operating company or the manufacturer
- has very good mechanical and/or electrical knowledge
- has software knowledge
- has service and repair experience
- is flexible

The service technician is responsible for the following tasks:

- performing mechanical and electrical service work in accordance with the manual
- replacing spare parts

### 3.1.2.9 Disposal specialists

The disposal specialist:

- is able to separate waste
- is familiar with the country-specific disposal regulations
- has experience in environmentally-friendly disposal
- works carefully and safely

### 3.1.3 Disregarding safety regulations



#### **⚠ DANGER**

#### **Disregarding safety regulations**

Disregarding safety regulations can result in damage to property, severe or fatal injuries.

- Always comply with the safety regulations

#### *Liability*

Güdel shall not be held liable under any of the following circumstances:

- The installation regulations were disregarded
- Included protective equipment was not installed
- Included protective equipment was modified
- Included monitoring equipment was not installed
- Included monitoring equipment was modified
- The product was not used as intended
- The maintenance work was not performed in the specified intervals, or was carried out incorrectly.

### 3.1.4 Installation instructions

#### *Protective measures*

The operating company is responsible for ensuring safe conditions in the vicinity of the product. In particular, he must ensure compliance with the general safety regulations, guidelines and standards. Before commissioning the system the operating company must check whether all the protective measures have been implemented. These must cover all hazards. This is the only way to ensure that application of the product conforms to CE regulations.

As stipulated by the Machinery Directive, the protective measures must:

- Correspond to best practices
- Comply with the required safety category

#### *Modifications*

The product must never be modified or used in a manner contrary to its intended use. 🔄 📄 25

#### *General rules for occupational safety*

The generally accepted occupational safety rules must be observed and implemented.

## 3.2 Hazard symbols in the manual

### 3.2.1 Hazard warnings

The hazard warnings are defined for the following four types of danger levels:

#### DANGER



#### **DANGER**

DANGER refers to hazards with a high risk of severe physical injury or immediate fatality.

#### WARNING



#### **WARNING**

WARNING refers to hazards with a moderate risk of severe physical injury or potential fatality.

#### CAUTION



#### **CAUTION**

CAUTION refers to hazards with a slight risk of moderate physical injury.







#### **NOTE**

#### **NOTE**

NOTE refers to hazards that can lead to property damage.

### 3.2.2 Explanation of warning symbol

Hazard warnings for personal injuries contain the symbol of the corresponding hazard.

Symbol	Explanation of symbols
	Hazards due to general causes
	Hazards resulting from automatic startup
	Hazards due to falling axles
	Hazards due to heavy components
	Hazards due to environmental pollution
	Hazards from leaking batteries

## 3.3 Fundamentals of safety

### 3.3.1 Separating protective equipment, monitoring equipment



#### ⚠ WARNING

##### Missing separating protective equipment and monitoring equipment

Missing or modified separating protective equipment and monitoring equipment may result in damage to property or serious injuries!

- Do not remove or modify separating protective equipment and monitoring equipment
- After commissioning the system, correctly attach all the separating protective equipment and monitoring equipment

For more information on separating safety and monitoring equipment, refer to the documentation on the complete system.

### 3.3.2 Product-specific hazards



#### ⚠ CAUTION

##### Leaking batteries

Battery fluids and their fumes are hazardous to the environment, corrosive and poisonous! They cause injury to persons and damage to property!

Observe the following points:

- Make sure there is good ventilation in closed rooms before repairing leaks
- Wear safety goggles and gloves
- Prevent battery fluids from getting into the drinking water supply
- Use only dry cleaning cloths without detergents
- Dispose of batteries in an environmentally friendly manner

**⚠ CAUTION**



**Oil, greases**

Oils and greases are harmful to the environment!

- The oils and greases must not get into the drinking water supply. Take appropriate measures
- Observe the country-specific safety data sheets
- Oils and greases must be disposed of as hazardous waste, even if the total quantity is small

**3.3.3**

**Material safety data sheets (MSDS)**

Safety data sheets contain safety information about the materials. They are country-specific. Safety data sheets are issued, for example, for materials such as oils, greases, cleaning agents, etc. The operating company is responsible for obtaining safety data sheets for all materials used.

Safety data sheets can be obtained as follows:

- Suppliers of chemicals usually supply their substances together with safety data sheets
- Safety data sheets are available on the Internet.  
(Enter "msds" and the name of the material in a search engine. Safety information about the material will be displayed.)

Read the safety data sheets carefully. Follow all the instructions. We recommend that you store the safety data sheets for future reference.



The safety data sheet for Güdel HI can be found in the download area of our company Web site <http://www.gudel.com>





## **4 Product description**

### **4.1 Use**

#### **4.1.1 Intended use**

The automatic lubrication system FlexxPump 40I mod / 40IB is designed exclusively for lubricating Güdel guideways and Güdel gear teeth. It may only be used as a replacement for the Memolub automatic lubrication system.

Any other or additional use is not considered to be intended use. The manufacturer assumes no liability for any resulting damage. All risks are borne solely by the user.

#### **4.1.2 Non-intended use**

The product is not intended for:

- Lubrication of runners, bearing or other elements
- Operation in potentially explosive areas
- Lubrication of elements in or on automobiles
- Operation outside of the performance specifications provided by Güdel
- Operation outside of permissible temperature range
- Using lubricants with properties other than the ones specified

Any use other than the specified intended use will be considered improper use and is forbidden!

Do not make any modifications to the product.

## 4.2 Product designation

The product has a type plate.




Fig. 4-1

Type plate

- |   |               |   |  |
|---|---------------|---|--|
| A | Serial number | D | Pump type  |
| B | Item number   | E | Build year (the first two digits of the serial number) |
| C | Product name  |   |  |

The type plate is attached to the right side of the casing. The hydraulic outputs are indicated by engraved numbers.




Fig. 4-2

*Product designations*

- A *Type plate*
- B *Numbers of the hydraulic outputs*

### 4.3 Technical data

For the following data, refer to the layout(s) in the appendix.

- Dimensions
- Weight
- Strokes of the individual axes
- Gearbox type
- Gearbox ratios
- Motors

*Emission sound  
pressure level*

The emission sound pressure level depends on the machine properties and the operating conditions. Generally the emissions sound pressure level  $L_{pA}$  is  $\leq 80\text{dB(A)}$ , measured at a distance of 1 m from the safety fence and 1.6 m above ground level. The measurement is performed according to the ISO 11202 standard. The measured value is time-averaged over a machine specific cycle and offset with correction factors for room and environment noise correction. The measured value contains measuring uncertainty of  $\pm 4\text{dB(A)}$  (accuracy grade 3) and applies for a single machine, measured separately.

### 4.3.1 Dimensions and connections 40I mod

The FlexxPump 40I mod weighs approx. 1500 g and has the following dimensions:




Fig. 4-3 Dimensions and connections 40I mod

- A Hydraulic output
- B Connection plug M12x1

**Connections** Hydraulic:

- One connection for hydraulic hoses with a diameter of 6/3 mm

Electrical: The four-pole connection size M12x1 transmits the following signals:

- Control signals
- Operating voltage

**Interfaces**

The FlexxPump 40I mod features an integrated microprocessor. It is controlled via a programmable logic controller (PLC).

**Operating voltage**

Operating voltage	Operating power	Peak power I <sub>max</sub>	Standby current	Peak output power
24 VDC +/- 5%	200 mA	350 mA	<20 mA	300 mA

Table 4-1 Operating voltage

## 4.3.2 Dimensions and connections 401B

The FlexxPump 401B weighs approx. 1500 g and has the following dimensions:




Fig. 4-4 Dimensions and connections 401B

- A Hydraulic output
- B Connection plug M12x1

**Connections**

**Hydraulic:**

- One connection for hydraulic hoses with a diameter of 6/3 mm

**Electrical:** The four-pole connection size M12x1 transmits the following signals:

- Error signals

**Interfaces**

Error signal can be displayed optically, if an LED cable is attached.

**Operating voltage**

The operating voltage is 3 VDC.

### 4.3.3 Temperature ranges

The following temperature ranges and humidity apply:

Product life phase	Temperature range	Air humidity
Transport	-10 to +60 °C	
Operation	-20 to +70 °C	Up to and at 85 %, condensation formation is not permissible
Storage	-10 to +40 °C	Up to 75 %

Table 4-2 Temperature ranges: FlexxPump

### 4.3.4 IP protection class

The product conforms to the protection class IP65.

### 4.3.5 Operating pressure

The operating pressure is 70 bar and is monitored electronically by counter-pressure measurement.

### 4.3.6 Lubricant amount

The cartridge contains 400 cm<sup>3</sup> of lubricant. The empty level is monitored by an integrated reed contact.

### 4.3.7 Shelf life of Güdel HI lubricant

The date of filling of the lubricant is shown on the lubricant cartridge. The Güdel HI lubricant has a shelf life of two years from date of filling. This applies to sealed original containers stored under the required storage conditions.





## 5 Design, function

### 5.1 Design

#### 5.1.1 Structure of the 40I mod

The product consists of the following assemblies:




Fig. 5-1

Structure of the 40I mod

A	Fastening screws	E	Screw
B	Bracket	F	Hydraulic hose
C	FlexxPump 40I mod	G	Progressive distributor
D	Adapter cable	H	Plug-thread connector

## 5.1.2 Detailed design of FlexxPump 401 mod

The FlexxPump 401 mod consists of the following components:




Fig. 5-2 Detailed design of FlexxPump 401 mod

- |   |                        |   |  |
|---|------------------------|---|--|
| A | Vent locking mechanism | E | Connection plug for supply and communication with control system |
| B | Covering               | F | LCD display  |
| C | Cartridge              | G | Active surface   |
| D | Casing                 | H | Hydraulic output   |

### 5.1.3 Structure of the 40IB

The product consists of the following assemblies:




Fig. 5-3

Structure of the 40IB

- |   |                  |   |                         |
|---|------------------|---|-------------------------|
| A | Fastening screws | F | Screw                   |
| B | Bracket          | G | Hydraulic hose          |
| C | FlexxPump 40IB   | H | Progressive distributor |
| D | LED cable        | I | Plug-thread connector   |
| E | Battery          |   |                         |

## 5.1.4 Detailed design of FlexxPump 401 B

The FlexxPump 401 B consists of the following components:




Fig. 5-4

Detailed design of FlexxPump 401 B

A	Vent locking mechanism, including magnetic peg	E	Battery
B	Covering	F	LCD display
C	Cartridge	G	Active surface
D	Casing	H	Hydraulic output

## **5.2 Function**

### **5.2.1 Functional description**

The automatic lubrication system is a lubrication system for Güdel components. The FlexxPump feeds the lubricant from the cartridge into the lines. Depending on the design, the lubricant is distributed through splitters, combined through Y-segments, or distributed directly to the lubrication area. Rack and pinions are lubricated by lubricating pinions; guideways are lubricated by lubricating elements.

The FlexxPump outputs a signal in case of overpressure, if the cartridge is empty and for each piston stroke. This makes it possible to process such information further.

### **5.2.2 40I mod**

A PLC feeds and controls the FlexxPump. If the sensor on the progressive distributor reports an error, the type of error is evaluated by the PLC and shown on the HMI during the lubrication procedure. The PLC and the HMI are not included in the scope of delivery.

### **5.2.3 40IB**

A battery feeds the FlexxPump. The magnetic peg controls the supply of lubricant. If an LED cable (accessories) is connected to the FlexxPump, it emits an optical signal in case of malfunction. However, the type of error is shown on the display.

## 5.2.4 Display elements

The LCD displays indicates malfunctions and operating states of the pump types 401 mod/401B. On the pump type 401 mod, the display is only active during the lubrication procedure. It does not show anything during standstill.



The flashing interval of the green LEDs lets you distinguish between the pump types 401 mod / 401B during operation:

- 5 seconds, 401 mod
- 60 seconds, 401B




Fig. 5-5

Display element and malfunctions

A	Digit display	E	Fault message for overcurrent
B	LED red	F	Fault message for operating voltage too low
C	LED green	G	Fault message; internal electrical error
D	Fault message for "Empty"	H	Fault message; internal mechanical error

Digit display

The digit display serves for communication.

- LED*      The LED indicates the function:
- The green LED lights up during the lubrication cycle
  - The green and red LEDs glow for 5 seconds after activation to check their own status  
Only pump type 40IB
  - The green LED flashes if there is no error  
Only pump type 40IB
  - The red LED flashes every 5 seconds if there is an error  
Only pump type 40IB

*Malfunction message*      The malfunction message indicates the type of error. More detailed information → 95

## 5.2.5      40IB

### 5.2.5.1      Control elements

The magnetic peg is magnetic and integrated into the vent locking mechanism. Remove the vent locking mechanism to use the magnetic peg. Touch the active surface with it to perform the following actions:

- Switch the FlexxPump on and off
- Set lubrication cycle
- Perform functional check




Fig. 5-6

*Magnetic peg*

- A      Vent locking mechanism
- B      Active surface
- C      Magnetic peg





## 6 Commissioning

### 6.1 Introduction

#### 6.1.1 Safety

Only perform the tasks described in this chapter after you have read and understood the chapter "Safety". ➔ 15  
It concerns your personal safety!



#### **⚠ WARNING**

##### **Automatic startup**

During work on the product, there is danger of the machine starting up automatically. This can lead to severe or fatal injuries!

Before working in the danger area:

- Secure vertical axes (if equipped) against falling.
- Switch off the superordinate main power supply. Secure it against being switched on again (main switch for the complete system)
- Before switching on the system again, make sure that no one is in the danger area

#### 6.1.2 Personnel qualifications

Only appropriately trained and authorized technicians are allowed to commission the product.

### 6.2 Transport

Avoid strong impacts and shocks while transporting the automatic lubrication system.

### 6.3 Packaging symbols

A lithium battery is also included with the product. The packaging unit is marked by one of the following or similar transport information labels. Observe these at all times.




Fig. 6-1

Transport information

- A Transport information for lithium battery for airplane transport
- B Transport information for lithium battery for truck transport

Both transport information labels warn against fire hazard due to damaged lithium batteries. Packaging units marked with one of these transport information labels:

- Must be handled with care
- May only be transported when not damaged
- Must be repaired appropriately if damaged → Chapter 6.4, 42

## 6.4 Repairing damaged packaging

Repair damaged packaging units as follows:

- 1 Remove packaging unit
- 2 Check batteries
- 3 In case of damaged batteries:
  - 3.1 Contact manufacturer by phone number on the transport information
  - 3.2 Follow manufacturer instructions
- 4 If batteries are undamaged:
  - 4.1 Repackage batteries
  - 4.2 Attach transport information for lithium battery to packaging unit

The packaging unit is repaired.

## 6.5 Intermediate storage

Observe the storage conditions if the product needs to be stored for a certain amount of time before assembly. → 102

## 6.6 Conversion

### 6.6.1 Prerequisites

Dispose of the packaging in accordance with the local waste regulations.

➔ 107

*Checking the delivery*

Check the scope of delivery based on the shipping papers. Check the product for damage. Report transport damage promptly.

*Interfaces*

Check whether the required interfaces are available and ready for use. Order information on the connecting cable.  
The following interfaces are needed:

Interface	40I mod	40IB
Lubricating pinion for gear teeth and Lubricating element for guideway rail	X	X
Connecting cable M12x1, 4-pole with the corresponding length	X	
PLC	X	

Table 6-1 Interfaces

*Assembly site*

The following prerequisites apply to the assembly site:

- The original Memolub lubrication system must be completely available
- Sufficiently rigid
- In order to minimize condensation, the device must not be subjected to direct sunlight and/or radiation heat

## 6.6.2 Special tools, testing and measuring instruments




Ensure that you have the following special tools, testing and measuring instruments at hand:


Tool	Use	Item number
Allen key size 4+5	Installing the conversion kit	-
Wrench size 14+17	Installing the conversion kit	-

Table 6-2 Special tools, testing and measuring instruments

### 6.6.3 Disassembling the Memolub

Disassemble the Memolub as follows:




<b>1</b>	
	<b>1</b> Switch off the system and secure it with a padlock against being switched on again
<b>2</b>	 <p>Control cable</p>
	<b>2</b> Disconnect the control cable from the Memolub (only pump type 40I mod)
<b>3</b>	 <p>Memolub Progressive distributor Nut</p>
	<b>3</b> Remove the Memolub from the progressive distributor


<b>4</b>	 <p>Progressive distributor</p> <p>Elbow pipe</p>
<b>4</b> Remove the elbow pipe	

The Memolub has been disassembled.


### 6.6.4 Mounting attachments

Mount the attachments as follows:

<b>1</b>	 <p>Plug-thread connector</p>  <p>Progressive distributor Plug-thread connector</p>
<b>1</b>	Mount the plug-thread connector
<b>2</b>	 <p>Fastening screws</p>
<b>2</b>	Remove the fastening screws



**3**    **Unpack the new fastening screws and angle**



**4**    **Install the bracket**

The attachments have been installed.



## 6.6.5 40I mod

### 6.6.5.1 Preparing material

Prepare the following material:




Fig. 6-2

*Prepare material*

- A *Cartridge*
- B *PU foam*
- C *Manual*

## 6.6.5.2 Installing the FlexxPump

### ⚠ CAUTION



#### Danger from spring tension

The covering contains a spring with tension. The covering jumps up when opened. This can lead to minor injuries!

Make sure that no extremities are in the danger area. Carefully remove the covering.


#### Prepare the FlexxPump

Prepare the FlexxPump as follows:

Prerequisite: The material is prepared

Prerequisite: The battery is inserted in the FlexxPump 401B

<b>1</b>	
	<p><b>1</b> Prepare the cartridge according to the following steps Observe the included instructions for the cartridge</p>
<b>2</b>	
	<p><b>2</b> Remove the transport securing device</p>




The FlexxPump is prepared.

## Install the FlexxPump


Install the FlexxPump as follows:

1




Screws

Assembly version 1:




FlexxPump  
Bracket

Assembly version 2:




**1** Mount the FlexxPump to the bracket with screws (ansure accessibility to the active surface of the pump type 401B and LCD display)

2



Hose

**2** Unpack the hose



The FlexxPump is assembled.

## 6.6.5.3 Connecting electrical equipment

The conversion kit can be used with two different versions of connecting cables. Choose the procedure for connecting the electrical equipment based on the connecting cable.

- Normal cable
- Y-cable

### Normal cable





Güdel recommends using a 1 A delay-action fuse for protecting the supply and control cable.




To connect the pump type 401 mod, only use the supplied adapter cable.

Connect the electrical equipment as follows:

<b>1</b>	
	<b>1</b> Prepare the adapter cable
<b>2</b>	
	<b>2</b> Connect the adapter cable to the FlexxPump

**3**



Control cable

Adapter cable

**3** Connect the adapter cable with the original control cable

The electrical equipment has been connected.

### Y-cable




To connect the pump type 40I mod, only use the supplied adapter cable.






Güdel recommends using a 1 A delay-action fuse for protecting the supply and control cable.

Connect the electrical equipment as follows:


**I**



**I** Prepare the adapter cable

<p><b>2</b></p>	 <p>Y-plug Memolub</p>
	<p>2 Disconnect the Y-plug from the Memolub</p>
<p><b>3</b></p>	
	<p>3 Replace the Memolub with the FlexxPump ↻ 50</p>
<p><b>4</b></p>	
	<p>4 Open Y-plug on the machine side</p>
<p><b>5</b></p>	
 <p>PIN 2 black Y-plug</p>	<p>5 Loosen PIN 2 black from the Y-plug, tie to the side and insulate</p>
<p><b>6</b></p>	
	<p>6 Install the Y-plug</p>
<p><b>7</b></p>	
 <p>Y-plug</p>	<p>7 Connect Y-plug and FlexxPump cable</p>





The electrical equipment has been connected.

#### 6.6.5.4 Adapting PLC

When installing the 40I mod pump type, the following adaptations need to be made in the PLC program.

### NOTE

#### Not adapted software

Not adapted PLC system can lead to damage or failures on the lubrication system 40I mod!

- Adapt the software of the PLC before the commissioning.



Exactly 0.15 cm<sup>3</sup> lubricant per hydraulic output is emitted during each pump actuation process. With these specifications the PLC can calculate the remaining volume and display it accordingly. A programed message "Cartridge nearly empty" is recommended by Güdel as of a remaining lubricant volume of less than 20 cm<sup>3</sup>.

## Procedure

Once 24 VDC operating voltage is applied to PIN 1 and 2 of the connection socket of the FlexxPump 401 mod, the FlexxPump 401 mod carries out a feed stroke. It is necessary for that that the pump is supplied with voltage for the duration of at least 20 seconds.

To initiate another feed stroke, the voltage supply has to be switched off and switched back on after at least 5 seconds.

The PLC programing needs to be adapted and checked during the conversion from a Memolub lubrication system to a FlexxPump 401 mod lubrication system. Please contact a Güdel service department..

## 6.6.6 40IB

### 6.6.6.1 Preparing material

Prepare the following material:



Fig. 6-3 Battery

### 6.6.6.2 Preparing material

Prepare the following material:




Fig. 6-4 Prepare material

- A Cartridge
- B PU foam
- C Manual

## 6.6.6.3 Installing the FlexxPump

### ⚠ CAUTION



#### Danger from spring tension

The covering contains a spring with tension. The covering jumps up when opened. This can lead to minor injuries!

Make sure that no extremities are in the danger area. Carefully remove the covering.

### Insert battery

### ⚠ CAUTION






#### Leaking lubricants

A plug or battery that protrudes the battery compartment can lead to leakage of the cartridge. Lubricant is hazardous to the environment.

- Make sure that the plug and the battery are completely stowed.

Insert the battery as follows:



<b>2</b>	 <p>Battery</p> <p>FlexxPump</p>
<b>2</b> Insert new battery	
<b>3</b>	 <p>Plug and battery</p> <p>FlexxPump</p>
<b>3</b> Stow the plug and battery in the battery compartment	




The battery is inserted.


## Prepare the FlexxPump

Prepare the FlexxPump as follows:

Prerequisite: The material is prepared

Prerequisite: The battery is inserted in the FlexxPump 401B





<b>1</b>	
<p><b>1</b> Prepare the cartridge according to the following steps Observe the included instructions for the cartridge</p>	
<b>2</b>	
<p><b>2</b> Remove the transport securing device</p>	
<b>3</b>	
<p><b>3</b> Install the PU foam in the cartridge</p>	




The FlexxPump is prepared.

## Install the FlexxPump

Install the FlexxPump as follows:

<b>1</b>	 <p>Assembly version 1:</p>  <p>Assembly version 2:</p> 
<b>1</b>	<p>Mount the FlexxPump to the bracket with screws (ansure accessibility to the active surface of the pump type 401B and LCD display)</p>
<b>2</b>	 <p>2 Unpack the hose</p>





The FlexxPump is assembled.

## 6.6.6.4 Connecting electrical equipment




Fig. 6-5

Connecting electrical equipment

A	FlexxPump 401B	D	Connector pin assignment
B	Connection plug for LED cable	E	Hydraulic output
C	Socket of LED cable		

Connect the electrical equipment as follows:

- I** Connect the LED cable:
  - I.1** PIN 1: without assignment
  - I.2** PIN 2: without assignment
  - I.3** PIN 3: Mass (GND), 0 V, color blue
  - I.4** PIN 4: Output signal, color black
- 2** Route the LED cable securely  
(The red LED must be visible for the operator while working)

The electrical equipment has been connected.

## 6.6.7 Disposing of the Memolub




Fig. 6-6

*Disposing of the Memolub*

- A Memolub
- B Elbow pipe
- C Old screw

Dispose of the components as follows:

- I Please dispose of the component according to the Disposal chapter:  
➔ 107

The components have been disposed of.

## 6.7 Lubrication recommendation

### 6.7.1 General information

#### NOTE

##### Lubricating film missing

A missing lubricating film on guideways and racks leads to damage to the product. This results in operational failure.

- Ensure that there is always a lubricating film on guideways and racks during operation
- Perform the described tasks at the specified times
- Perform lubrication work at the latest when the first signs of tribocorrosion (reddish discoloration of the track) are visible
- Adjust lubrication interval if necessary

The running surfaces of guideways, racks as well as the drive pinions need to be lubricated. A precise recommendation on the lubrication quantity needed cannot be made, because that depends on various factors. The calculations listed here are based on empirical values and lead to reference values. The lubrication quantity needs to be checked regularly and needs to be adapted if necessary.

The following non-conclusive factors determine the lubrication quantity:

- Kilometers traveled by the axle
- Degree of contamination of the axle
- Power-on time of the entire system
- Ambient temperature
- Number of lubrication points
- Elements used in the lubrication system



Güdel recommends to program the HMI user interface so that the operator of the entire system can adjust the lubrication quantity to the operating conditions. The operator is always responsible for adequate and properly functioning lubrication.

## 6.7.2 Basics

Average lubricant requirement at a lubrication point (U)

The following lubricant quantities should be dispensed at least per lubrication point. These are empirical values from Güdel. These values can be met only approximatively due to the number of outputs of the pumps and the installed splitters.

Size	Average lubricant requirement per lubrication point (U)
1-5	0.30 cm <sup>3</sup> / 100 km
6-7	0.40 cm <sup>3</sup> / 100 km

Table 6-3 Average lubricant requirement per lubrication point (U)

Recommended lubrication quantity (P<sub>i</sub>)

The recommended lubrication quantity P<sub>i</sub> can be found in the following table.

System	Size 1-5	Sizes 6-7
3 lubrication points (e.g. EP, TMF, TMO)	0.9 cm <sup>3</sup> / 100 km	1.2 cm <sup>3</sup> / 100 km
6 lubrication points (e.g. ZP)	1.8 cm <sup>3</sup> / 100 km	2.4 cm <sup>3</sup> / 100 km
4 lubrication points (e.g. X-axis FP)	1.2 cm <sup>3</sup> / 100 km	1.6 cm <sup>3</sup> / 100 km

Table 6-4 Recommended lubrication quantity (P<sub>i</sub>)

## 6.7.3 Calculation formulas

The emptying time of cartridge PI needs to be determined. With multiple axles per FlexxPump, the axle most traveled needs to be taken into consideration for the calculation (on linear gantries, this is typically the Y-axis).

The following specifications of your application are needed:

- Average velocity of the axle ( $v_m$ ) in m/s
- Operation time ( $t$ ) of the system per day in hours
- Power-on time (POT) in %

The following values need to be calculated for PI:

Value	Formula	Unit
Running performance of the axle per day (V)	$v_m \times t \times \text{POT} \times 0.036$	km/day
Recommended lubrication quantity per day (P)	$(V \times P_t) / 100$	cm <sup>3</sup> /day
Emptying time of cartridge (PI)	Cartridge volume / $(P \times 30)$	months

Table 6-5 Calculation formulas: Emptying time of the cartridge (PI)

## 6.8 Initial commissioning



Check the connections of the hydraulic system before starting up the product.

### 6.8.1 40I mod

#### 6.8.1.1 Switching on the FlexxPump 40I mod

Switch on the FlexxPump 40I mod as follows:

- 1 Switch on and operate the FlexxPump 40I mod via PLC
- 2 In case of malfunctions:
  - 2.1 Rectify malfunctions according to Malfunctions / Troubleshooting  
➡ 95
  - 2.2 Adjust control if necessary
  - 2.3 Repeat process from step 1

The FlexxPump 40I mod is switched on.

In some cases the LCD will display "PAU" if the FlexxPump 40I mod is switched on. This display is not relevant.

Saved information is not lost when switched off.

#### Lubrication recommendation for pump type 40I mod

Güdel recommends the following lubrication cycles:

Type	Lubrication recommendation
3 times (e.g. EP or TM)	1 lubrication cycle after 144 h or 100 km <sup>1)</sup>
6 times (e.g. linear gantry)	1 lubrication cycle after 72 h or 100 km <sup>1)</sup>
10 times (e.g. AG)	1 lubrication cycle after 72 h or 100 km <sup>1)</sup>

Table 6-6 Recommended lubrication cycles

<sup>1)</sup> = whichever occurs first, however, at the latest, if first traces of tribocorrosion (reddish discoloration of the guideway or gear teeth) appear.

## 6.8.2 401B

### 6.8.2.1 Switching on the FlexxPump 401B




Fig. 6-7

Display sequence of display LCD

A	LED red	E	Lubrication quantity P2
B	Operating voltage in volt (3 VDC)	F	Sequence of display
C	Number of hydraulic outputs	G	FlexxPump switched on
D	Emptying time P1 of cartridge in months		

Switch on the FlexxPump 401B as follows:

- 1 Touch the active surface with the magnetic peg
- 2 Wait for LED to flash 3x
- 3 Remove magnetic peg

The FlexxPump is switched on.

The FlexxPump starts the lubrication cycle immediately after being switched on.



### Lubrication cycle




Fig. 6-8

Lubrication cycle

- A LED green
- B Pressure of Hydraulic Output 1.1 in bar
- C Pressure of Hydraulic Output 1.2 in bar

The green LED glows during the lubrication cycle. The displayed pressure corresponds to the pressure from the hydraulic output to the lubrication point. The next lubrication cycle starts according to the setting of the lubrication cycle.

### Special dispensing

The special dispensing serves to feed smaller amounts of lubricant for testing and experimentation purposes.

Carry out the special dispensing as follows:

Prerequisite: The FlexxPump is switched on

- 1 Touch the active surface with the magnetic peg
- 2 Wait for LED to flash 2x
- 3 Remove magnetic peg

Special dispensing is carried out.



## 7 Operation

### 7.1 General

Only operate the product after observing the installation instructions.

For information on operating the product, refer to the appropriate chapter of the documentation for the complete system.

### 7.2 Personnel



#### **⚠ WARNING**

##### **Training of operating personnel**

Incorrect behavior of untrained, or insufficiently trained, operating personnel can lead to severe injury or damage to property!

Before the operating personnel begin working with the product:

- Train and instruct the operating personnel
- Point out dangers in the work area to the operating personnel
- Check the qualifications of operating personnel before approving them
- Keep the operating personnel up-to-date in regard to best practices. Also inform them about technical progress, modifications, etc.

⇒ If these measures are not complied with, you alone as the operating company are liable for damages that may result!



## 8 Maintenance

### 8.1 Introduction

*Maintenance tasks*

The listed tasks have to be carried out at the prescribed time intervals. If they are not carried out at the specified intervals or improperly, all warranty is voided. Observing these obligations is a significant condition so that the product performing without malfunction as well as its long service life.

*Work sequences*

Perform the work sequences in the order described. Perform the described tasks at the specified times. This ensures a long service life for your product.

*Original spare parts*

Only use original spare parts. ➔ 📄 III

#### 8.1.1 Safety

Only perform the tasks described in this chapter after you have read and understood the chapter "Safety". ➔ 📄 15  
It concerns your personal safety!



#### **⚠ WARNING**

##### **Automatic startup**

During work on the product, there is danger of the machine starting up automatically. This can lead to severe or fatal injuries!

Before working in the danger area:

- Secure vertical axes (if equipped) against falling.
- Switch off the superordinate main power supply. Secure it against being switched on again (main switch for the complete system)
- Before switching on the system again, make sure that no one is in the danger area



## ⚠ WARNING

### Falling axes, workpieces

Falling axes or workpieces can cause physical damage, serious or fatal injuries!

- Set down any workpieces before working in the danger area
- Never enter the area below suspended axes and workpieces
- Secure suspended axes using the stipulated equipment
- Check the belts of the telescope axes for signs of breakage and tears



## ⚠ WARNING

### Heavy components

Components can be very heavy. Improper handling can cause severe or fatal injuries!

- Use appropriate lifting units
- Use suitable means to secure the components against tipping over
- Only remove the safety devices after the product has been completely assembled

## 8.1.2 Personnel qualifications

Only appropriately trained and authorized technicians are allowed to work on the product.

## 8.2 Consumables and auxiliary agents

### 8.2.1 Cleaning agents

Use a soft rag or cloth for cleaning tasks. Only use permissible cleaning agents.

#### 8.2.1.1 Table of cleaning agents

Cleaning agents	Location of application
mild universal cleaner free from aromatic compounds (e.g. Motorex OPAL 5000)	Automatic lubrication system: Pump, lines, other components

This table does not purport to be exhaustive.

Table 8-1 Table of cleaning agents

### 8.2.2 Lubricants

#### NOTE

##### Unsuitable lubricants

Using unsuitable lubricants can cause damage to the machine!

- Only use the lubricants listed
- If uncertain, please contact our service departments

For more information on the lubricants, refer to the tables below. For further information, refer to the chapter "Maintenance tasks" and the respective third party documentation.

*Special Güdel lubricants*

If special lubricants have been delivered ex-works at the request of the customer, you can find the relevant specifications in the spare parts list.

*Alternative manufacturers*

The following tables show the specifications of the lubricants. Please inform your manufacturer accordingly. They will then suggest an alternative from their product range.

*Low temperatures / food grade*

Observe the application range limits of lubricants according to the safety data sheet.

## 8.2.2.1 Lubrication

### Lubrication cycle

Güdel recommends a lubrication cycle of 150 h or 100 km, whichever occurs first. With automatic lubrication it may not be possible to set this lubrication cycle exactly. In this case, select the nearest lubrication cycle. Perform lubrication work as soon as the first signs of tribocorrosion (reddish discoloration of the track) are visible.

### Automatic lubrication system

The following lubrication systems and lubricants are provided for the automatic lubrication of the product:



Fig. 8-1 Automatic lubrication system FlexxPump

Lubrication ex works	Specification	Lubrication quantity	Location of application	Category
Mobil Glygoyle 460 NSF no.136467	CLP PG 460 in accordance with DIN 51502		Automatic lubrication system FlexxPump	oil

Table 8-2 Lubricants: Automatic lubrication system FlexxPump

## 8.2.2.2 Lubricant table

Lubrication ex works	Specification	Lubrication quantity	Location of application	Category
Mobil Glygoyle 460 NSF no.136467	CLP PG 460 in accordance with DIN 51502		Automatic lubrication system FlexxPump	oil

This table does not purport to be exhaustive.

Table 8-3 Lubricant table



## 8.3 Maintenance tasks

### 8.3.1 Checking automatic lubrication system



Fig. 8-2 *Inspect automatic lubrication system*

#### Cleaning agents

mild universal cleaner free from aromatic compounds (e.g. Motorex OPAL 5000)

Table 8-4 *Cleaning agents: Automatic lubrication system: Pump, lines, other components*

Check the automatic lubrication system in accordance with the following table.

Inspection point	Description	Measures
Contamination	Check the components for contamination: <ul style="list-style-type: none"> <li>• Pump</li> <li>• Lines</li> <li>• other components</li> </ul>	Immediately clean away any contamination
Loss of lubricant	Check system and its surroundings for traces: <ul style="list-style-type: none"> <li>• Puddles of oil and oil spills on the floor or in the drip sheets</li> <li>• Leaks, torn or pinched lines</li> </ul>	<ul style="list-style-type: none"> <li>• Remove puddles of oil and oil spills on the floor or in the drip sheets</li> <li>• Replace defective and pinched lines</li> </ul>
Function	Check function	Replace defective components immediately

Table 8-5 *Inspection table*

## NOTE

### Lubricating film missing

A missing lubricating film on guideways and racks leads to damage to the product. This results in operational failure.

- Ensure that there is always a lubricating film on guideways and racks during operation
- Perform the described tasks at the specified times
- Perform lubrication work at the latest when the first signs of tribocorrosion (reddish discoloration of the track) are visible
- Adjust lubrication interval if necessary

## 8.3.2 Replacing the cartridge

Replace the cartridge if the malfunction message "Empty" appears.

For pump type 401B, replace the battery at the same time.

### ⚠ CAUTION



#### Danger from spring tension

The covering contains a spring with tension. The covering jumps up when opened. This can lead to minor injuries!

Make sure that no extremities are in the danger area. Carefully remove the covering.

### ⚠ CAUTION



#### Residual amounts in empty cartridges

Empty cartridges contain lubricant residues. Oils and greases are harmful to the environment!

- Dispose of the cartridge in an environmentally friendly manner ➔ 107



Use only original Güdel cartridges. Never refill the cartridges.




Fig. 8-3

Replacing cartridge

- A Vent locking mechanism
- B Covering
- C Cartridge

- D O-ring
- E Retaining cover

Lubrication ex works	Specification	Lubrication quantity
<ul style="list-style-type: none"> <li>➔ Chapter 8.2.2.1,</li> <li>📄 80</li> </ul>	<ul style="list-style-type: none"> <li>➔ Chapter 8.2.2.1,</li> <li>📄 80</li> </ul>	400 cm <sup>3</sup>

Table 8-6

Lubricants: Automatic lubrication system FlexxPump

Replace the cartridge as follows:

- 1 Remove the vent locking mechanism in the direction of the arrow
- 2 Switch off FlexxPump
- 3 Remove the covering by turning in the direction of the arrow
- 4 Remove empty cartridge
- 5 Only pump type 401B:  
Replacing the battery → Chapter 8.3.3, 84
- 6 Remove the retaining cover from the new cartridge
- 7 Lubricate the O-ring slightly
- 8 Insert new cartridge (make sure the cartridge fits in properly)
- 9 Put on the covering and turn hand-tight in the direction of the arrow
- 10 Switching on the FlexxPump → Chapter 6.8, 71
- 11 Insert vent locking mechanism and secure

The cartridge is replaced.

### 8.3.3 Replacing the battery 401B



#### ⚠ CAUTION

##### Leaking batteries

Battery fluids and their fumes are hazardous to the environment, corrosive and poisonous! They cause injury to persons and damage to property!

Observe the following points:

- Make sure there is good ventilation in closed rooms before repairing leaks
- Wear safety goggles and gloves
- Prevent battery fluids from getting into the drinking water supply
- Use only dry cleaning cloths without detergents
- Dispose of batteries in an environmentally friendly manner

**NOTE**

**Empty battery**

A battery charge lasts for one cartridge only and for a maximum of 3 years (PI  $\leq$  36 months). An empty battery causes material damage to the entire plant due to inadequate lubrication.

- Replace the battery simultaneously with the cartridge
- Use only Güdel batteries. Only then can a sufficient battery charge be guaranteed.
- Immediately replace the battery when error message E3 appears



The FlexxPump contains a capacitor. The capacitor stores the supply voltage for 30 seconds. Strictly wait for 30 seconds before attaching the plug to the new battery. Only then will the capacitor be fully discharged and the error message E3 is reset correctly.




Fig. 8-4

Replacing the battery 40IB

- A Battery
- B Plug

Replace the battery as follows:

Prerequisite: The cartridge is removed ➔ Chapter 8.3.2, 82

- 1 Remove battery
- 2 Loosen plug
- 3 Wait for 30 seconds
- 4 Attach plug to new battery
- 5 Insert new battery
- 6 Install cartridge
- 7 Switching on the FlexxPump ➔ Chapter 6.8, 71
- 8 Carry out a special dispensing ➔ 73

The battery is replaced.

## 8.4 Maintenance table

Maintenance work	Maintenance cycle [h]	Duration [min]	Target readership	Lubricants Cleaning agents	Further information
Replacing the cartridge	2,250	10	The manufacturer's technicians Maintenance technicians	Mobil Glygoyle 460 NSF no.136467	➔ Chapter 8.3.2, 82
Replacing the battery 40IB			Maintenance technicians The manufacturer's technicians		➔ Chapter 8.3.3, 84
Checking automatic lubrication system	11,250		The manufacturer's technicians Maintenance technicians	mild universal cleaner free from aromatic compounds (e.g. Motorex OPAL 5000)	➔ Chapter 8.3.1, 81

This table does not purport to be exhaustive.

Table 8-7 Maintenance table





## 8.5 Intervention report: Maintenance

ASSEMBLY INSTRUCTIONS Conversion kit FlexxPump 40I mod / 40IB

Project / Order:  
Bill of materials:  
Serial number:  
Year of manufacture:

Company :  
Address :  
Location :  
Country :

Complete the intervention report after every intervention. You can overwrite the data each time you complete the report. Send the intervention report to Güdel electronically. Use the "Send" button. Sending only works if you have completed the operator details in the intervention report as specified in the Maintenance chapter. Save the generated XML file as a backup. Copy the empty intervention report and scan it in after completing it if you are not working electronically. Send it to [service@ch.gudel.com](mailto:service@ch.gudel.com) after every intervention.

Maintenance work	Maintenance cycle [h]	Effective operating hours <sup>1</sup>	Name <sup>2</sup>	Comments <sup>3</sup>	Date
Replacing the cartridge	2,250				
Replacing the battery 40IB					

Effective operating hours<sup>1</sup> :  
Name<sup>2</sup> :  
Comments<sup>3</sup> :


Service hours [h] of the entire system according to service hour counter in the control panel / Service hours [h] or kilometers [km] of the corresponding axis  
First and last name of the service or maintenance technician  
Amount of contamination, anomalies, defects, replaced components



## Intervention report: Maintenance

ASSEMBLY INSTRUCTIONS Conversion kit FlexxPump 40I mod / 40IB

Project / Order:  
Bill of materials:  
Serial number:  
Year of manufacture:



Complete the intervention report after every intervention. You can overwrite the data each time you complete the report. Send the intervention report to Güdel electronically. Use the "Send" button. Sending only works if you have completed the operator details in the intervention report as specified in the Maintenance chapter. Save the generated XML file as a backup. Copy the empty intervention report and scan it in after completing it if you are not working electronically. Send it to [service@ch.gudel.com](mailto:service@ch.gudel.com) after every intervention.

Maintenance work	Maintenance cycle [h]	Effective operating hours <sup>1</sup>	Name <sup>2</sup>	Comments <sup>3</sup>	Date
Checking automatic lubrication system	11,250				

This table does not purport to be exhaustive.

Effective operating hours<sup>1</sup> :  
Name<sup>2</sup> :  
Comments<sup>3</sup> :

Service hours [h] of the entire system according to service hour counter in the control panel / Service hours [h] or kilometers [km] of the corresponding axis  
First and last name of the service or maintenance technician  
Amount of contamination, anomalies, defects, replaced components



## 8.6 Feedback on the instructions

Your feedback helps us to keep improving these instructions. Thank you!

[mailto: docufeedback@ch.gudel.com](mailto:docufeedback@ch.gudel.com)

Please provide the following information with your feedback:

- Identification number of the instructions
- Product, type
- Project number, order number
- Material number / serial number
- Year of manufacture
- Location of the product (country, ambient conditions, etc.)
- Photos, comments, feedback with clear reference to the section in the instructions
- Your contact data for clarifications if necessary

You can find most of the information on the type plate or the title page of the instructions. The identification number of the instructions is given on each page, as shown here:




Fig. 8-5 Identification number of the instructions

## 9 Repairs

### 9.1 Introduction

*Work sequences*

Perform the work sequences in the order described. Perform the described tasks at the specified times. This ensures a long service life for your product.

*Original spare parts*

Only use original spare parts. ➔ 📄 III

#### 9.1.1 Safety

Only perform the tasks described in this chapter after you have read and understood the chapter "Safety". ➔ 📄 15  
It concerns your personal safety!



#### ⚠️ WARNING

##### **Automatic startup**

During work on the product, there is danger of the machine starting up automatically. This can lead to severe or fatal injuries!

Before working in the danger area:

- Secure vertical axes (if equipped) against falling.
- Switch off the superordinate main power supply. Secure it against being switched on again (main switch for the complete system)
- Before switching on the system again, make sure that no one is in the danger area

### 9.2 Repairs

Always replace the complete FlexxPump, splitter, Y-segments, or hoses with new ones in case of defects. Send the defective FlexxPump back to Güdel for repairs.

### 9.3 Malfunctions / Troubleshooting

Malfunction	Cause	Measure
Lubrication system does not lubricate	Cartridge missing/ empty or air in FlexxPump; pump function stopped	Insert new cartridge or vent FlexxPump; the pump continues running without change
Lubrication system does not lubricate	The measured counterpressure was too high three times in a row. Hydraulic connections or hoses may be blocked, hoses too long, and/ or lubricant too stiff/ hard. Pump function has been stopped.	Remove cause of the counterpressure, switch off the power supply to the FlexxPump and switch it on again. The fault is set to zero. The FlexxPump starts up again.
Lubrication system does not lubricate	Various causes	<ul style="list-style-type: none"> <li>• Switch off the power supply to the FlexxPump and switch it on again. This does not delete the data memory.</li> <li>• Contact the service department if the problem reoccurs</li> </ul>

Table 9-1 Malfunctions / Troubleshooting

## 9.3.1 401B

### 9.3.1.1 Empty E1

The red LED flashes every 5 seconds. The FlexxPump stops operating.

Malfunction	Cause	Measure
Empty E1	<ul style="list-style-type: none"> <li>• Cartridge is missing or empty</li> <li>• Air in FlexxPump</li> </ul>	<ul style="list-style-type: none"> <li>• Insert or replace cartridge, perform functional check if necessary</li> <li>• Carry out a special dispensing ➡ 73</li> </ul>

Table 9-2 Empty E1

### 9.3.1.2 Overcurrent E2

The red LED flashes every 5 seconds. Pressure too high (>70 bar). The FlexxPump stops operating.

Malfunction	Cause	Measure
Overcurrent E2	Line or lubrication point is blocked: <ul style="list-style-type: none"> <li>• Lubricant too stiff</li> <li>• Lubrication point blocked</li> <li>• Hoses too long</li> </ul>	Remove blockage

Table 9-3 Overcurrent E2

Remove the blockage as follows:

- 1 Switch off FlexxPump
- 2 Analyze blockage
- 3 Remove blockage
- 4 Switching on the FlexxPump ➡ Chapter 6.8, 71
- 5 Evaluate success
- 6 If there are deviations: Repeat process from step 1

The blockage is removed.



### 9.3.1.3 Operating voltage too low E3

The red LED flashes every 5 seconds. Operating voltage too low. FlexxPump stops operating.

Malfunction	Cause	Measure
Operating voltage too low E3	<ul style="list-style-type: none"> <li>No voltage or voltage too low (40I mod)</li> <li>Battery weak or empty (40IB)</li> <li>Corrosion on motor and sheet</li> <li>Defective gearbox or motor</li> </ul>	<ul style="list-style-type: none"> <li>Correct the operating voltage (40I mod)</li> <li>Replace the battery (40IB)</li> </ul> <p>If unsuccessful: Send FlexxPump to Güdel</p>

Table 9-4 Overcurrent E3



If the error message E3 continues to be displayed despite correct voltage, switching on and off and special dispensing, return the FlexxPump to Güdel. No meaningful analysis of the problem can be carried out for the FlexxPump 40IB without the battery. Always include the battery when returning the pump! Add the following additional information, providing as much detail as possible:

- Ambient conditions (temperature, degree of soiling, etc)
- Operating date (from... until...)
- Lubricant

### 9.3.1.4 System malfunction

In case of system malfunctions, switch the device off and on again. This does not delete the data memory.

Fix system malfunctions as follows:

- 1 Switch off FlexxPump
  - 1.1 Touch the active surface with the magnetic peg
  - 1.2 Wait for LED to flash 3x
  - 1.3 Remove magnetic peg  
(Display switches to "OFF")

2 Switching on the FlexxPump → Chapter 6.8, 71

The system malfunctions are fixed.

### 9.3.1.5 Functional check

The switched on FlexxPump 401B can release lubricant for test purposes.

Perform the functional check as follows:

- 1 Touch the active surface with the magnetic peg
- 2 Wait for LED to flash 2x
- 3 Remove magnetic peg
- 4 Evaluate success ➡ 73

The functional check is complete.

## 9.3.2 401 mod

### 9.3.2.1 System malfunction

In case of system malfunctions, switch the device off and on again. This does not delete the data memory.

Fix system malfunctions as follows:



- 1 Switch off FlexxPump via PLC
- 2 Switch on FlexxPump via PLC

The system malfunctions are fixed.





## 9.5 Service departments

If you have questions, please contact the service departments.   113

## 10 Decommissioning, storage

### 10.1 Introduction

Only perform the tasks described in this chapter after you have read and understood the chapter "Safety". ➔ 15

It concerns your personal safety!

#### 10.1.1 Personnel qualifications

Only appropriately trained and authorized technicians are allowed to work on the product.

### 10.2 Storage conditions

#### ⚠ CAUTION



##### Leaking batteries

Battery fluids and their fumes are hazardous to the environment, corrosive and poisonous! They cause injury to persons and damage to property!

Observe the following points:

- Make sure there is good ventilation in closed rooms before repairing leaks
- Wear safety goggles and gloves
- Prevent battery fluids from getting into the drinking water supply
- Use only dry cleaning cloths without detergents
- Dispose of batteries in an environmentally friendly manner

#### ⚠ CAUTION



##### Leaking fluids

During storage, substances that are hazardous to the environment can leak!

- Hazardous substances must be prevented from entering the drinking water supply. Take appropriate measures
- Observe the country-specific safety data sheets
- Oils and greases must be disposed of as hazardous waste, even if the total quantity is small

<i>Room</i>	Store the product in a dry location. For information on the required space and the floor capacity, refer to the layout. Use a covering to protect the product against dust and dirt.
<i>Temperature</i>	The ambient temperature must remain between -10 and +40 °C. Make sure that the product is not subjected to great temperature fluctuations.
<i>Air humidity</i>	The air humidity must be below 75%.

## 10.3 Decommissioning

### 10.3.1 Shutdown

#### WARNING



#### Falling axes, workpieces

Falling axes or workpieces can cause physical damage, serious or fatal injuries!

- Set down any workpieces before working in the danger area
- Never enter the area below suspended axes and workpieces
- Secure suspended axes using the stipulated equipment
- Check the belts of the telescope axes for signs of breakage and tears




Do not empty the lubrication lines and the gearbox when shutting down the product.

To shut down the product, proceed as follows:

- 1 Switch off FlexxPump
- 2 Remove cartridge
- 3 Cut the power supply (plug of the battery for pump type 401B)

The product has been shut down.

### 10.3.2 Cleaning, rust-proofing

Clean away any dirt and dust from the product. Clean the product thoroughly. Dispose of any cloths soaked in oil or grease in an environmentally friendly manner.  107

Apply corrosion protection to all bright parts.

### 10.3.3 Transport securing devices

On unbraked motors, mount the transport securing devices.



### **10.3.4 Identification**

Label the product with the following data:

- Date of decommissioning
- Internal machine number/name
- Additional data as per internal guidelines



## II Disposal

### II.1 Introduction

Observe the following during disposal:

- Adhere to the country-specific regulations
- Separate the material groups
- Dispose of the materials in an environmentally friendly way
- Recycle waste if possible

#### II.1.1 Safety

Only perform the tasks described in this chapter after you have read and understood the chapter "Safety". ➔ 15  
It concerns your personal safety!



#### **⚠ WARNING**

##### **Automatic startup**

During work on the product, there is danger of the machine starting up automatically. This can lead to severe or fatal injuries!

Before working in the danger area:

- Secure vertical axes (if equipped) against falling.
- Switch off the superordinate main power supply. Secure it against being switched on again (main switch for the complete system)
- Before switching on the system again, make sure that no one is in the danger area

#### II.1.2 Personnel qualifications

Only appropriately trained and authorized technicians are allowed to work on the product.

## 11.2 Disposal

Your product consists of the following units:

- Packaging
  - Contaminated materials / auxiliary agents (oil paper)
  - Wood
  - Plastic (film)
- Consumables
  - Lubricants (oils/greases)
  - Batteries
- Base unit
  - Metals (steel/aluminum)
  - Plastics (thermoplasts/duroplasts)
  - Contaminated materials / auxiliary agents (felt / cleaning cloths)
  - Electrical material (cables)

## 11.3 Waste management compliant assemblies

### 11.3.1 Disassembly

#### CAUTION



#### **Oil, greases**

Oils and greases are harmful to the environment!

- The oils and greases must not get into the drinking water supply. Take appropriate measures
- Observe the country-specific safety data sheets
- Oils and greases must be disposed of as hazardous waste, even if the total quantity is small

#### CAUTION



#### **Leaking batteries**

Battery fluids and their fumes are hazardous to the environment, corrosive and poisonous! They cause injury to persons and damage to property!

Observe the following points:

- Make sure there is good ventilation in closed rooms before repairing leaks
- Wear safety goggles and gloves
- Prevent battery fluids from getting into the drinking water supply
- Use only dry cleaning cloths without detergents
- Dispose of batteries in an environmentally friendly manner

Disassemble the product as follows:

Prerequisite: Prior to disassembly, shut down the product

- 1 Remove the connecting elements (cables / energy chains)
- 2 Disassemble assemblies
- 3 Disassembly the assemblies and separate the different materials

The product has now been disassembled.

## 11.3.2 Material groups

Dispose of the material groups in accordance with the following table:

Material	Disposal method
Contaminated materials / auxiliary agents	Hazardous waste
Wood	Municipal waste
Plastic	Collecting point or municipal waste
Lubricants	Collecting point disposal in accordance with the safety data sheets ➡ 23
Batteries	Battery collection
Metals	Scrap metal collection
Electrical material	Electrical waste

Table 11-1 Disposal: material groups

## 11.4 Disposal facilities, authorities

The disposal facilities and authorities differ from country to country. Observe the local laws and regulations concerning disposal.

## **I2 Spare parts supply**





## 12.1 Service departments

---



Have the following information available for service inquiries:

- Product, type (as per type plate)
  - Project number, order number (as per type plate)
  - Serial number (as per type plate)
  - Material number (as per type plate)
  - Location of the system
  - Contact person at the operating company
  - Description of the issue
  - Drawing number (if applicable)
- 

### Regular inquiries

If you have questions relating to service, please use the service form at [www.gudel.com](http://www.gudel.com) or contact the responsible service department:

---



For all other countries not included in the following list, please contact the service department in Switzerland.

---



Customer with special agreements should contact the service department specified in the contract.

---

Americas

Country	Relevant service department	Phone	E-mail
Brazil	Güdel Lineartec Comércio de Automação Ltda. Rua Américo Brasiliense nº 2170, cj. 506 Chácara Santo Antonio CEP 04715-005 São Paulo Brazil	+55 11 99590 8223	info@br.gudel.com
Argentina	Güdel TSC S.A. de C.V. Gustavo M. Garcia 308 Col. Buenos Aires N.L. 64800 Monterrey Mexico	+52 81 8374 2500 107	service@mx.gudel.com
Mexico			
Canada	Güdel Inc. 4881 Runway Blvd. Ann Arbor, Michigan 48108 United States	+1 734 214 0000	service@us.gudel.com
United States			

Table 12-1 Service departments Americas

Asia

Country	Relevant service department	Phone	E-mail
China	Güdel International Trading Co. Ltd. Block A, 8 Floor, C2 BLDG, No. 1599 New Jin Qiao Road Pudong 201206 Shanghai China	+86 21 5055 0012	info@cn.gudel.com
China press automation	Güdel Jier Automation Ltd. A Zone 16th Floor JIER Building 21th Xinxu Road 250022 Jinan China	+86 531 81 61 6465	service@gudeljier.com
India	Güdel India Pvt. Ltd. Gat No. 458/459 Mauje Kasar Amboli Pirangut, Tal. Mulshi 412 111 Pune India	+91 20 679 10200	service@in.gudel.com

Country	Relevant service department	Phone	E-mail
Korea	Güdel Lineartec Inc. 11-22 Songdo-dong Yeonsu-Ku Post no. 406-840 Incheon City South Korea	+82 32 858 05 41	gkr.service@gudel.co.kr
Taiwan	Güdel Lineartec Co. Ltd. No. 99, An-Chai 8th St. Hsin-Chu Industrial Park TW-Hu-Ko 30373 Hsin-Chu Taiwan	+88 635 97 8808	info@tw.gudel.com
Thailand	Güdel Lineartec Co. Ltd. 19/28 Private Ville Hua Mak Road Hua Mak Bang Kapi 10240 Bangkok Thailand	+66 2 374 0709	service@th.gudel.com

Table 12-2 Service departments in Asia

Europe

Country	Relevant service department	Phone	E-mail
Denmark	Güdel AG Gaswerkstrasse 26 Industrie Nord 4900 Langenthal Switzerland	+41 62 916 91 70	service@ch.gudel.com
Finland			
Greece			
Norway			
Sweden			
Switzerland			
Turkey			

Country	Relevant service department	Phone	E-mail
Bosnia and Herzegovina	Güdel GmbH Schöneringer Strasse 48 4073 Wilhering Austria	+43 7226 20690 0	service@at.gudel.com
Croatia			
Austria			
Romania			
Serbia			
Slovenia			
Hungary			
Slovakia	Güdel a.s. Holandská 4 63900 Brno Czech Republic	+420 602 309 593	info@cz.gudel.com
Czech Republic			
Portugal	Güdel Spain C/Industria 60 Local 7 08025 Barcelona Spain	+34 93 476 03 80	info@es.gudel.com
Spain			
France	Güdel SAS Tour de l'Europe 213 3 Bd de l'Europe 68100 Mulhouse France	+33 1 6989 80 16	info@fr.gudel.com
Germany	Güdel Germany GmbH Industriepark 107 74706 Osterburken Germany	+49 6291 6446 792	service@de.gudel.com
Germany intralogistics	Güdel Intralogistics GmbH Gewerbegebiet Salzhub 11 83737 Irschenberg Germany	+49 8062 7075 0	service-intralogistics@de.gudel.com

Country	Relevant service department	Phone	E-mail
Italy	Güdel S.r.l. Via per Cernusco, 7 20060 Bussero (Mi) Italy	+39 02 92 17 021	info@it.gudel.com
Belgium	Güdel Benelux Eertmansweg 30 7595 PA Weerselo The Netherlands	+31 541 66 22 50	info@nl.gudel.com
Luxembourg			
The Netherlands			
Estonia	Gudel Sp. z o.o. ul. Legionów 26/28 43-300 Bielsko-Biała Poland	+48 33 819 01 25	serwis@pl.gudel.com
Latvia			
Lithuania			
Poland			
Ukraine			
Russia	Gudel Russia Yubileynaya 40 Office 1902 445057 Togliatti Russia	+7 848 273 5544	info@ru.gudel.com
Belarus			
Ireland	Güdel Lineartec (U.K.) Ltd. Unit 5 Wickmans Drive, Banner Lane Coventry CV4 9XA West Midlands United Kingdom	+44 24 7669 5444	service@uk.gudel.com
United Kingdom			

Table 12-3 Service departments in Europe

All other countries

Country	Relevant service department	Phone	E-mail
All other countries	Güdel AG Gaswerkstrasse 26 Industrie Nord 4900 Langenthal Switzerland	+41 62 916 91 70	service@ch.gudel.com

Table 12-4 Service departments for all other countries

### Inquiries outside of business hours

If you have service inquiries outside of business hours, please contact the following service departments:

Europe	Güdel AG Gaswerkstrasse 26 Industrie Nord 4900 Langenthal Switzerland	+41 62 916 91 70	service@ch.gudel.com
Americas	Güdel Inc. 4881 Runway Blvd. Ann Arbor, Michigan 48108 United States	+1 734 214 0000	service@us.gudel.com

Table 12-5 Service departments outside of business hours



## List of illustrations

Fig. 4 -1	Type plate .....	26
Fig. 4 -2	Product designations .....	27
Fig. 4 -3	Dimensions and connections 40I mod .....	29
Fig. 4 -4	Dimensions and connections 40IB .....	30
Fig. 5 -1	Structure of the 40I mod .....	33
Fig. 5 -2	Detailed design of FlexxPump 40I mod .....	34
Fig. 5 -3	Structure of the 40IB .....	35
Fig. 5 -4	Detailed design of FlexxPump 40IB .....	36
Fig. 5 -5	Display element and malfunctions .....	38
Fig. 5 -6	Magnetic peg .....	39
Fig. 6 -1	Transport information .....	42
Fig. 6 -2	Prepare material .....	49
Fig. 6 -3	Battery .....	59
Fig. 6 -4	Prepare material .....	59
Fig. 6 -5	Connecting electrical equipment .....	66
Fig. 6 -6	Disposing of the Memolub .....	67
Fig. 6 -7	Display sequence of display LCD .....	72
Fig. 6 -8	Lubrication cycle .....	73
Fig. 8 -1	Automatic lubrication system FlexxPump .....	80
Fig. 8 -2	Inspect automatic lubrication system .....	81
Fig. 8 -3	Replacing cartridge .....	83
Fig. 8 -4	Replacing the battery 40IB .....	85
Fig. 8 -5	Identification number of the instructions .....	93
Fig. 12 -1	Explanation of symbols .....	119



## List of tables

Table -I	Revision history.....	3
Table 2-I	Explanation of symbols/abbreviations.....	13
Table 4-I	Operating voltage.....	29
Table 4-2	Temperature ranges: FlexxPump.....	31
Table 6-I	Interfaces.....	43
Table 6-2	Special tools, testing and measuring instruments.....	44
Table 6-3	Average lubricant requirement per lubrication point (U).....	69
Table 6-4	Recommended lubrication quantity (Pt).....	69
Table 6-5	Calculation formulas: Emptying time of the cartridge (PI)....	70
Table 6-6	Recommended lubrication cycles.....	71
Table 8-I	Table of cleaning agents.....	79
Table 8-2	Lubricants: Automatic lubrication system FlexxPump.....	80
Table 8-3	Lubricant table.....	80
Table 8-4	Cleaning agents: Automatic lubrication system: Pump, lines, other components.....	81
Table 8-5	Inspection table.....	81
Table 8-6	Lubricants: Automatic lubrication system FlexxPump.....	82
Table 8-7	Maintenance table.....	87
Table 9-I	Malfunctions / Troubleshooting.....	95
Table 9-2	Empty EI.....	96
Table 9-3	Overcurrent E2.....	96
Table 9-4	Overcurrent E3.....	97
Table 11-I	Disposal: material groups.....	110
Table 12-I	Service departments Americas.....	114
Table 12-2	Service departments in Asia.....	114
Table 12-3	Service departments in Europe.....	115
Table 12-4	Service departments for all other countries.....	117
Table 12-5	Service departments outside of business hours.....	118



## Index

### A

Adapting	
PLC .....	57
Air humidity .....	31, 103
Assembly site .....	43
Attachments	
Mounting .....	47
Automatic lubrication system	
Checking .....	81

### B

Battery	
Inserting .....	60
Lithium .....	41, 42
Replacing .....	84

### C

Cable	
normal .....	54
Y .....	55
Calculate	
Lubrication quantity .....	70
Cartridge	
Emptying time PI .....	70
Lubricant amount .....	31
maximum storage period .....	31
Checking	
Automatic lubrication system	81
Delivery .....	43
Function: : FlexxPump 402/402B	73
Cleaning .....	104
Cleaning agents .....	79
Connecting	
Electrical equipment: FlexxPump	
40I mod .....	54
Electrical equipment: FlexxPump	
40IB .....	66
Connections	
FlexxPump 40I mod .....	29
FlexxPump 40IB .....	30
Control elements .....	39
Customer feedback .....	93

<b>D</b>		<b>F</b>	
Decommissioning .....	102	Feedback .....	93
Delivery		Feedback on the instructions .....	93
Checking .....	43	FlexxPump	
Dimensions		Mounting .....	52, 64
FlexxPump 401 mod .....	29	Preparing .....	50, 62
FlexxPump 401B .....	30	FlexxPump 401 mod	
Disassembling .....	109	Connecting electrical equipment	
Memolub .....	45	.....	54
Product .....	109	Power On .....	71
Display .....	38	FlexxPump 401B	
Display elements .....	38	Connecting: Electrical equipment	
Disposal .....	107	.....	66
Memolub .....	67	Power On .....	72
Disposal facilities .....	110	FlexxPump 402/402B	
		Check function .....	73
<b>E</b>		FlexxPump 402B	
E1		Replace battery .....	84
Malfunction .....	96	Function	
E2		check: FlexxPump 402/402B ..	73
Malfunction .....	96	Functional check 401B .....	98
E3		Functional description .....	37
Malfunction .....	97		
Electrical equipment		<b>G</b>	
Connecting: FlexxPump 401 mod		Güdel HI	
.....	54	Shelf life .....	31
Connecting: FlexxPump 401B			
.....	66	<b>H</b>	
Emission noise level .....	28	Hazard warnings .....	20
Emptying time P1			
Cartridge .....	70	<b>I</b>	
Explanation of abbreviations .....	13	Identification .....	105
Explanation of symbols .....	13	Initial commissioning .....	71
		Installation instructions .....	19
		Intended purpose .....	25
		Interfaces .....	43

<b>L</b>		<b>O</b>	
Liability .....	19	Occupational safety .....	19
Lithium battery .....	41, 42	Operation .....	15, 75
Lubricant		Original spare part .....	77, 94
Shelf life .....	31	<b>P</b>	
Lubricants .....	79	Packaging	
Quantity in cartridge .....	31	Repair .....	42
Lubrication cycle .....	73, 80	Packaging symbols .....	41
Lubrication quantity		Personnel qualifications .....	41
Calculate .....	70	PLC	
<b>M</b>		Adapting .....	57
Magnetic peg .....	39	Power On	
Maintenance tasks .....	77	FlexxPump 40I mod .....	71
Malfunctions .....	95	FlexxPump 40IB .....	72
Empty EI .....	96	Preparing	
Operating voltage too low E3 .....	97	FlexxPump .....	50, 62
Overcurrent E2 .....	96	Pressure	
System malfunction 40IB .....	97	maximum .....	31
System malfunction 40I mod ..	98	Operation .....	31
Maximum		Product	
Pressure .....	31	Disassembling .....	109
Maximum storage period		Shutdown .....	104
Güdel HI .....	31	Protection class .....	31
Measuring instruments .....	44	Protective equipment .....	22
Memolub		Protective measures .....	19
Disassembling .....	45	Pump types	
Disposal .....	67	FlexxPump 40I mod .....	34
Monitoring equipment .....	22	FlexxPump 40IB .....	36
Mounting .....	43	Purpose of the document .....	13
Attachments .....	47		
FlexxPump .....	52, 64		
MSDS .....	23		

<b>R</b>		<b>T</b>	
Repairs .....	94	Technical data .....	28
Replacing		Temperature .....	103
Battery .....	84	Temperature range .....	31
Cartridge .....	82	Testing instruments .....	44
FlexxPump .....	94	Training of operating personnel ..	75
Hoses .....	94	Transport .....	41
Splitter .....	94	Transport information .....	41
Y-segments .....	94	Tribocorrosion .....	80
Replacing cartridge .....	82	Troubleshooting .....	95
Residual danger .....	15	Type plate .....	26
<b>S</b>		<b>U</b>	
Safety data sheet .....	23	Use	
Service departments .....	113	Non-intended .....	25
Shelf life		<b>W</b>	
Güdel HI lubricants .....	31	Warning symbols .....	21
Shutdown .....	104	Warranty .....	19
Product .....	104	<b>Y</b>	
Spare part .....	77, 94	Y-cable .....	55
Spare parts list .....	119		
Special dispensing .....	73		
Special tools .....	44		
State of the art .....	15		
Storage .....	102		
Storage conditions .....	102		
Symbol .....	21		

## Appendix

The appendix of these assembly instructions contains the following documents:

- Layout
- Spare parts lists





# Layout



## Spare parts lists



Version	I.1
Author	romkal
Date	08.03.2019
GÜDEL AG	
Industrie Nord	
CH-4900 Langenthal	
Switzerland	
Phone	+41 62 916 91 91
Fax	+41 62 916 91 50
E-mail	<a href="mailto:info@ch.gudel.com">info@ch.gudel.com</a>
<a href="http://www.gudel.com">www.gudel.com</a>	

# GÜDEL

GÜDEL AG  
Industrie Nord  
CH-4900 Langenthal  
Switzerland  
Phone +41 62 916 91 91  
[info@ch.gudel.com](mailto:info@ch.gudel.com)  
[www.gudel.com](http://www.gudel.com)